





# کاتالوگ قطعات یدکی

1103R02701861/1



| SAMAND                                                                              |                                         | B01<br>Fiche 1 | MASTER INDEX                                                                          |                                                |
|-------------------------------------------------------------------------------------|-----------------------------------------|----------------|---------------------------------------------------------------------------------------|------------------------------------------------|
|    | ENGINE                                  | 1.C            |    | ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE 2.C |
|     | FLYWHEEL AND CLUTCH                     | 1.D            |    | FACIA, TRIM, SEATS AND FIXINGS 2.F             |
|    | GEARBOX                                 | 1.E            |    | ACCESSORIES AND PAINT 2.H                      |
|    | AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS | 1.F            | Numeric Index 2.I                                                                     |                                                |
|    | STEERING                                | 1.G            |                                                                                       |                                                |
|    | BRAKES AND BRAKE CONTROLS               | 1.H            |                                                                                       |                                                |
|   | FUEL, EXHAUST AND EMISSION SYSTEM       | 1.I            |  |                                                |
|  | COOLING, HEATING AND AIR CONDITIONING   | 1.J            |                                                                                       |                                                |
|  | ELECTRICAL AND INSTRUMENTS              | 1.K            |                                                                                       |                                                |

# SAMAND

## B02 Fiche 1

## DESCRIPTIVE INDEX "Absorber." TO "Clip-injection harness"

|                                                  |         |                                                    |         |                                               |         |                                        |         |
|--------------------------------------------------|---------|----------------------------------------------------|---------|-----------------------------------------------|---------|----------------------------------------|---------|
| Absorber.....                                    | 1. F 05 | Box.-first aid.....                                | 2. H 02 | Bracket.-sensor.....                          | 1. I 05 | Cap.....                               | 1. K 08 |
| Absorber.-rear.....                              | 1. F 10 | Box.-glovebox-lower.....                           | 2. F 03 | Bracket.-sleeve.....                          | 1. H 07 | Cap.....                               | 1. J 10 |
| Actuator.-door locks-front.....                  | 2. C 18 | Box.-glovebox-upper.....                           | 2. F 02 | Bracket.-starter.....                         | 1. K 06 | Cap.....                               | 1. F 11 |
| Actuator.-fuel filler.....                       | 2. D 09 | Box.-main-fusebox assy.....                        | 1. L 03 | Bracket.-tail light-body mounted-lh.....      | 1. K 09 | Cap.....                               | 2. F 05 |
| Actuator.-rear door lock.....                    | 2. D 04 | Box.-protection-lh.....                            | 2. F 10 | Bracket.-trunk lock cable-upper.....          | 2. D 08 | Cap.....                               | 2. C 16 |
| Adhesive.....                                    | 2. D 10 | Box.-protection-rh.....                            | 2. F 11 | Bracket.-upper.....                           | 1. K 04 | Cap.....                               | 2. C 17 |
| Adjusting mechanism.-with atc-valeo.....         | 1. J 13 | Bracket.....                                       | 1. K 02 | Brake drum.-drum brake.....                   | 1. H 03 | Cap.....                               | 2. D 18 |
| Air box.-rh.....                                 | 2. C 10 | Bracket.....                                       | 1. J 04 | Brake pads.-bendix-front-asbestos free.....   | 1. H 02 | Cap.-23mm diameter-30mm long.....      | 1. C 14 |
| Air con compressor.-sandén.....                  | 1. J 05 | Bracket.....                                       | 1. J 06 | Brake shoe.-brake-asbestos free-bendix.....   | 1. H 03 | Cap.-hub.....                          | 1. F 09 |
| Air vent.-centre.....                            | 1. J 14 | Bracket.....                                       | 1. M 06 | Brush assy.-starter motor-assembly.....       | 1. K 07 | Cap.-inner.....                        | 2. F 08 |
| Air vent.-centre console-rear-lh.....            | 2. F 06 | Bracket.....                                       | 1. G 08 | Buffer.....                                   | 1. F 08 | Cap.-panel-fusebox assy-grey.....      | 2. F 02 |
| Alternator.-mitsubishi, valeo-assembly-80.....   | 1. K 04 | Bracket.....                                       | 1. I 08 | Buffer.-26mm-rubber.....                      | 1. J 06 | Cap.-pocket moulding-inner rh.....     | 2. F 09 |
| Anti roll bar.-anti-roll bar-diameter 17.....    | 1. F 08 | Bracket.....                                       | 1. K 08 | Buffer.-26mm-rubber.....                      | 1. J 09 | Cap.-push-9mm diameter.....            | 1. G 05 |
| Anti roll bar.-diameter 22.....                  | 1. F 04 | Bracket.....                                       | 1. C 10 | Buffer.-79 mm.....                            | 1. F 02 | Cap.-push-9mm diameter.....            | 1. G 07 |
| Arm.-front swivel-lh.....                        | 1. F 03 | Bracket.....                                       | 1. K 10 | Buffer.-clutch-pedal.....                     | 1. D 04 | Cap.-rectangular-front floor.....      | 2. E 04 |
| Arm.-suspension-lh.....                          | 1. F 09 | Bracket.....                                       | 1. K 13 | Buffer.-glovebox.....                         | 2. F 02 | Cap.-valve.....                        | 1. J 11 |
| Arm.-windscreen wiper-lh.....                    | 2. D 12 | Bracket.....                                       | 1. J 15 | Buffer.-mounting-rh.....                      | 2. C 02 | Cd changer.....                        | 1. M 04 |
| Armrest.-assembly-rear seat-grey.....            | 2. G 03 | Bracket.....                                       | 2. F 14 | Buffer.-rebound.....                          | 1. F 09 | Centralising tool.-centralising.....   | 2. H 02 |
| Ash tray assy.-centre console-front.....         | 2. F 05 | Bracket.-bracket.....                              | 1. E 07 | Buffer.-trunk hinge.....                      | 2. D 07 | Centre console.-rear.....              | 2. F 06 |
| Ash tray assy.-centre console-rear.....          | 2. F 06 | Bracket.-bracket-centre console-rear.....          | 2. F 07 | Buglar alarm.-burglar alarm.....              | 1. L 06 | Chain.-oil pump.....                   | 1. C 11 |
| Assembly.-battery-painted.....                   | 1. L 08 | Bracket.-cable retained.....                       | 1. D 03 | Bumper assy.-front bumper -assembly.....      | 2. D 15 | Clip.....                              | 1. I 03 |
| Assembly.-engine and gearbox.....                | 2. C 11 | Bracket.-caliper -lh.....                          | 1. H 02 | Bumper assy.-rear-assembly.....               | 2. D 16 | Clip.....                              | 1. H 04 |
| Assembly.-front end.....                         | 2. C 05 | Bracket.-cd player-lh.....                         | 1. M 04 | Bush.....                                     | 1. F 04 | Clip.....                              | 1. I 06 |
| Assembly.-radiator support-twin-blower assy..... | 1. J 07 | Bracket.-column.....                               | 1. G 03 | Bush.....                                     | 1. F 07 | Clip.....                              | 1. H 07 |
| Assembly.-seat back.....                         | 2. C 10 | Bracket.-control.....                              | 1. K 17 | Bush.....                                     | 1. G 08 | Clip.....                              | 1. G 08 |
| Assembly.-trunk floor.....                       | 2. C 07 | Bracket.-crossmember.....                          | 1. F 08 | Bush.....                                     | 1. F 09 | Clip.....                              | 1. H 08 |
| Assembly.-trunk lid.....                         | 2. D 18 | Bracket.-diameter 22.....                          | 1. F 04 | Bush.....                                     | 2. D 02 | Clip.....                              | 1. H 09 |
| Badge.....                                       | 1. C 06 | Bracket.-ducting adapter-lower.....                | 1. J 14 | Bush.....                                     | 2. F 08 | Clip.....                              | 1. I 10 |
| Badge.-front bumper.....                         | 2. E 03 | Bracket.-ecu protection box.....                   | 1. K 03 | Bush.....                                     | 2. F 09 | Clip.....                              | 1. C 13 |
| Balance weight.-steel wheel-10gm.....            | 1. F 11 | Bracket.-exhaust support.....                      | 1. I 09 | Bush.-14 x 15.....                            | 1. K 06 | Clip.....                              | 1. L 17 |
| Ball.-locking-8mm diameter.....                  | 1. E 07 | Bracket.-front bumper -lh.....                     | 2. C 05 | Bush.-20mm diameter.....                      | 1. G 06 | Clip.....                              | 1. L 18 |
| Battery cable.-battery-negative.....             | 1. L 07 | Bracket.-front door.....                           | 2. C 16 | Bush.-bearing cup-hexagonal head-6 x 100..... | 1. C 06 | Clip.....                              | 2. C 02 |
| Battery terminal.-positive.-alternator.....      | 1. K 05 | Bracket.-front door-lh.....                        | 2. F 08 | Bush.-centralising-16 x 25.5.....             | 1. K 04 | Clip.....                              | 2. D 02 |
| Battery.....                                     | 1. L 07 | Bracket.-front door-rh.....                        | 2. F 09 | Bush.-centralising-16 x 25.5.....             | 1. J 05 | Clip.....                              | 2. D 07 |
| Bearing.....                                     | 1. F 07 | Bracket.-front seat.....                           | 2. C 06 | Bush.-centring.....                           | 1. C 03 | Clip.....                              | 2. C 13 |
| Bearing.-25 x 47-15.....                         | 1. E 05 | Bracket.-fuel-tank-assembly-lh.....                | 1. I 06 | Bush.-centring.....                           | 1. F 06 | Clip.....                              | 2. C 14 |
| Bearing.-alternator.....                         | 1. K 05 | Bracket.-gearchange.....                           | 1. E 09 | Bush.-flexible.....                           | 2. C 02 | Clip.-16-18 x 4,7.....                 | 1. I 08 |
| Bearing.-bearing.....                            | 1. F 03 | Bracket.-heat-tailpipe.....                        | 1. I 11 | Bush.-fork-top.....                           | 1. D 02 | Clip.-30mm diameter-heater assy.....   | 1. J 16 |
| Bearing.-differential.....                       | 1. F 06 | Bracket.-lh.....                                   | 2. D 14 | Bush.-front.....                              | 1. F 03 | Clip.-6.2mm-rear-harness.....          | 1. L 04 |
| Bearing.-exterior.....                           | 1. F 09 | Bracket.-lh.....                                   | 2. D 15 | Bush.-front.....                              | 1. F 08 | Clip.-backrest to body.....            | 2. G 06 |
| Bearing.-needle.....                             | 1. E 06 | Bracket.-lh.....                                   | 2. D 16 | Bush.-front seat-outer.....                   | 2. F 16 | Clip.-brake vacuum-swivel.....         | 1. H 05 |
| Bearing.-thrust.....                             | 1. F 02 | Bracket.-lower.....                                | 2. H 02 | Bush.-front seat-outer.....                   | 2. F 17 | Clip.-clamp.....                       | 1. F 04 |
| Bearing.-thrust-clutch-20.5mm-valeo.....         | 1. D 02 | Bracket.-no1-rear door-lh-lower.....               | 2. F 10 | Bush.-lower.....                              | 1. F 10 | Clip.-double.....                      | 1. G 06 |
| Block & pipe.....                                | 1. I 12 | Bracket.-no1-rear door-rh.....                     | 2. F 11 | Bush.-manifold-6 x 13-48.....                 | 1. I 09 | Clip.-ecu protection box.....          | 1. K 03 |
| Block & pipe-35mm diameter.....                  | 1. C 06 | Bracket.-oil pump.....                             | 1. C 11 | Bush.-pedal.....                              | 1. H 04 | Clip.-exhaust-rubber.....              | 1. I 09 |
| Block & pipe-bracket-gearchange.....             | 1. E 09 | Bracket.-parcel shelf.....                         | 2. C 10 | Bush.-retaining-gearchange.....               | 1. E 09 | Clip.-fastening.....                   | 1. I 11 |
| Block & pipe-cylinder block.....                 | 1. C 03 | Bracket.-pedal.....                                | 1. H 04 | Bush.-stoneguard to body.....                 | 2. C 11 | Clip.-harness.....                     | 1. L 09 |
| Block & pipe-drain-14mm diameter.....            | 1. J 09 | Bracket.-pedal-brake.....                          | 1. D 04 | Button.-door lock.....                        | 2. F 08 | Clip.-harness-17 x 14.....             | 1. J 08 |
| Block & pipe-rest.....                           | 1. G 05 | Bracket.-pipe-lh.....                              | 1. H 08 | Button.-door lock.....                        | 2. F 09 | Clip.-harness-17mm diameter.....       | 1. M 02 |
| Block & pipe-rest.....                           | 1. G 07 | Bracket.-pressure relief valve-with atc-valeo..... | 1. J 02 | Button.-door lock.....                        | 2. F 10 | Clip.-harness-275mm.....               | 1. L 15 |
| Block & pipe-spring.....                         | 1. C 08 | Bracket.-rear door.....                            | 2. C 17 | Button.-door lock.....                        | 2. F 11 | Clip.-harness-harness-6.2mm-6.2mm..... | 1. L 11 |
| Body assy.-less doors, trunk lid and bonnet..... | 2. C 04 | Bracket.-rear seat.....                            | 2. C 07 | Button.-heater control-valeo.....             | 1. J 17 | Clip.-harness-harness-6.2mm-6.2mm..... | 1. L 12 |
| Body side.-lh.....                               | 2. C 08 | Bracket.-relay support.....                        | 1. L 04 | Button.-seat belt.....                        | 2. G 04 | Clip.-harness-harness-6.2mm-6.2mm..... | 1. L 13 |
| Box.....                                         | 2. F 04 | Bracket.-retaining lug.....                        | 1. I 03 | Cable guide.-speedo cable.....                | 1. K 14 | Clip.-harness-injection harness.....   | 1. K 02 |
| Box.-ecu protection box.....                     | 1. K 03 | Bracket.-rh.....                                   | 2. C 02 | Camshaft.....                                 | 1. C 07 | Clip.-injection harness.....           | 1. L 10 |



| SAMAND                                      |         | B03<br>Fiche 1                            |         | DESCRIPTIVE INDEX "Clip.-injector" TO "Hose.-evacuation-with atc-valeo" |         |                                               |         |
|---------------------------------------------|---------|-------------------------------------------|---------|-------------------------------------------------------------------------|---------|-----------------------------------------------|---------|
| Clip.-injector                              | 1. I 04 | Door assy.-rear-lh                        | 2. C 17 | Fixing clip.-bonnet release                                             | 2. C 14 | Glass.-tinted.-front door-lh                  | 2. D 02 |
| Clip.-linkage                               | 1. D 04 | Door casing.-front door-lh-grey           | 2. F 08 | Fixing clip.-brake servo-harness-1.50mm                                 | 1. H 05 | Glass.-windscreen                             | 2. D 10 |
| Clip.-lumber support                        | 2. F 16 | Door casing.-front door-rh-grey           | 2. F 09 | Fixing clip.-cable-stop                                                 | 1. D 04 | Grill.-air                                    | 2. D 18 |
| Clip.-lumber support                        | 2. F 17 | Door casing.-rear door-lh-grey            | 2. F 10 | Fixing clip.-clamping-top                                               | 1. J 14 | Grill.-air intake                             | 1. J 12 |
| Clip.-metal                                 | 1. I 07 | Door casing.-rear door-rh-grey            | 2. F 11 | Fixing clip.-console to brkt-clamping-top                               | 2. F 07 | Grill.-loudspeaker-front door-lh              | 2. F 08 |
| Clip.-metal-32mm diameter                   | 1. C 14 | Door panel.-rear-lh                       | 2. C 17 | Fixing clip.-cover panel to fascia                                      | 2. F 02 | Grill.-loudspeaker-front door-rh              | 2. F 09 |
| Clip.-metal-diameter 60-100                 | 1. I 02 | Dowel                                     | 1. C 03 | Fixing clip.-drive shaft-bearing                                        | 1. F 07 | Grill.-loudspeaker-parcel shelf               | 2. F 15 |
| Clip.-negative terminal                     | 1. L 07 | Dowel                                     | 1. F 07 | Fixing clip.-fastening-steel                                            | 1. J 12 | Grill.-radiator                               | 2. D 15 |
| Clip.-plastic                               | 1. J 12 | Dowel.-10mm x 13mm                        | 1. J 11 | Fixing clip.-harness-1.50mm                                             | 1. M 02 | Grill.-screen demist-lh                       | 1. J 14 |
| Clip.-push clip head liner                  | 2. F 14 | Dowel.-12 x 15                            | 1. E 03 | Fixing clip.-hub bearing                                                | 1. F 03 | Grommet                                       | 1. H 05 |
| Clip.-rear door lock                        | 2. D 04 | Dowel.-3.3 x 15                           | 1. E 07 | Fixing clip.-key 13x6-7                                                 | 1. C 04 | Grommet.-diameter int. 12.6                   | 1. I 12 |
| Clip.-spare wheel                           | 2. H 02 | Dowel.-3.5 x 25                           | 1. F 06 | Fixing clip.-lock barrel                                                | 2. C 18 | Grommet.-diameter interior = 68,5 thickness = | 1. J 04 |
| Clip.-swivel                                | 1. I 05 | Dowel.-4.1 x 15                           | 1. C 12 | Fixing clip.-m8 x 125-engine and gearbox                                | 2. C 11 | Grommet.-door lock front-black                | 2. C 18 |
| Clip.-water outlet                          | 1. J 10 | Dowel.-5mm x 25mm                         | 1. E 05 | Fixing clip.-mounting                                                   | 1. H 09 | Grommet.-front bulkhead                       | 2. G 07 |
| Clock.-digital clock                        | 1. K 18 | Dowel.-7 x 51-fork-top                    | 1. D 02 | Fixing clip.-rear door lock                                             | 2. D 04 | Grommet.-headrest                             | 2. F 16 |
| Clutch plate housing.-front                 | 1. H 02 | Dowel.-8x15                               | 1. C 04 | Fixing clip.-retaining                                                  | 1. I 12 | Grommet.-headrest                             | 2. F 17 |
| Clutch plate housing.-pressure plate        | 1. D 02 | Dowel.-accelerator cable                  | 1. I 12 | Fixing clip.-speed-3.5 x 10                                             | 1. K 15 | Grommet.-speedo cable                         | 1. K 14 |
| Clutch plate.-friction plate-200mm-asbestos | 1. D 02 | Dowel.-centralising-13 x 33               | 1. G 09 | Fixing clip.-stop                                                       | 1. E 06 | Grommet.-valeo-with atc                       | 1. J 02 |
| Compressor clutch.-pulley-sanden            | 1. J 05 | Dowel.-fixing                             | 2. C 02 | Fixing clip.-stop plate                                                 | 1. E 07 | Handle.-black                                 | 2. F 16 |
| Condenser                                   | 1. J 06 | Dowel.-guide                              | 1. C 11 | Fixing clip.-swivel                                                     | 1. I 04 | Handle.-black                                 | 2. F 17 |
| Connecting rods.-connecting set 4           | 1. C 05 | Dowel.-piston                             | 1. C 05 | Fixing clip.-trim pad-foot heater                                       | 2. F 03 | Handle.-black                                 | 2. F 18 |
| Control cable                               | 1. D 03 | Dowel.-push-rod                           | 1. H 04 | Fixing clip.-trunk lid                                                  | 2. D 18 | Handle.-front door-lh                         | 2. C 18 |
| Control cable                               | 1. I 12 | Dowel.-stop                               | 1. E 08 | Fixing clip.-valve                                                      | 1. C 08 | Handle.-grab-front door-lh                    | 2. F 08 |
| Control cable.-bonnet release               | 2. C 14 | Drive belt.-114 teeth                     | 1. C 07 | Fixing clip.-wheelhouse carpet                                          | 2. G 06 | Handle.-grab-front door-rh                    | 2. F 09 |
| Control cable.-handbrake-centre             | 1. H 07 | Drive belt.-alternator-l = 1660           | 1. K 04 | Floor carpet.-front floor                                               | 2. G 05 | Handle.-grab-rear door-lh                     | 2. F 10 |
| Control cable.-heater control               | 1. J 17 | Drive belt.-alternator-l = 1660           | 1. G 09 | Floor carpet.-trunk backrest                                            | 2. G 06 | Handle.-grab-rear door-rh                     | 2. F 11 |
| Control cable.-speedo cable                 | 1. K 14 | Drive shaft.-lh                           | 1. F 07 | Fluid gauge                                                             | 1. I 06 | Handle.-grab-roof.-grey                       | 2. F 14 |
| Control cable.-trunk lid lock               | 2. D 08 | Dryer.-with harness                       | 1. J 06 | Fluid gauge.-engine oil                                                 | 1. C 12 | Handle.-rear door-lh                          | 2. D 04 |
| Control unit.-engine management system      | 1. K 03 | Ducting.-centre                           | 1. J 14 | Fluid.-gamme pro                                                        | 1. H 06 | Harness.-brake wear                           | 1. L 09 |
| Control unit.-temperature 96/118 bitron     | 1. J 08 | Ducting.-rear passenger-lh-centre console | 2. F 07 | Fluid.-gearbox.-75w80w                                                  | 1. E 02 | Harness.-engine-sajem                         | 1. L 10 |
| Converter                                   | 1. J 09 | Electrical cable.-radio aerial            | 1. M 06 | Foam pad-balance spring                                                 | 2. D 07 | Harness.-front door-lh                        | 1. L 11 |
| Cooling fan.-blade engine cooling-200w-9    | 1. J 08 | Engine bearing.-half-standard-set of 8    | 1. C 05 | Foam pad-battery tray-foam                                              | 1. L 08 | Harness.-front door-rh                        | 1. L 12 |
| Cover.-battery clamp-negative               | 1. L 07 | Engine bearing.-standard                  | 1. C 04 | Foam pad-door lock                                                      | 2. D 04 | Harness.-front fascia                         | 1. L 17 |
| Cover.-brake vacuum-protection              | 1. H 05 | Engine sump                               | 1. C 12 | Foam pad-door lock                                                      | 2. C 18 | Harness.-headlamp-front panel                 | 1. M 02 |
| Cover.-front seat backrest-grey             | 2. G 02 | Engine.-new-mark 16a                      | 1. C 02 | Foam pad-exterior mirror                                                | 2. D 14 | Harness.-heated rear window                   | 1. L 15 |
| Cover.-main-harness                         | 1. L 14 | Evaporator.-r134-valeo-with atc           | 1. J 02 | Foam pad-foam                                                           | 2. F 08 | Harness.-heater control-standard-behr         | 1. L 16 |
| Cover.-rear squab-grey                      | 2. G 03 | Fender.-front-lh                          | 2. C 12 | Foam pad-foam                                                           | 2. F 09 | Harness.-main-front                           | 1. L 14 |
| Cover.-roof.-grey                           | 2. F 14 | Fender.-rear quarter-lh                   | 2. C 10 | Foam pad-interior lamp-self adhesive                                    | 1. L 18 | Harness.-rear door-lh                         | 1. L 13 |
| Cover.-sleeve                               | 1. G 08 | Filter                                    | 1. C 12 | Foam pad-support-windscreen washer                                      | 2. D 13 | Harness.-roof lamp                            | 1. L 18 |
| Crankshaft                                  | 1. C 04 | Filter.-air intake                        | 1. J 13 | Fuel tank.-fuel                                                         | 1. I 06 | Hazard triangle                               | 2. H 02 |
| Crossmember.-suspension                     | 1. F 08 | Filter.-element                           | 1. I 02 | Fuse.-5 amp                                                             | 1. L 03 | Headrest.-front-grey                          | 2. F 18 |
| Crown wheel & pinion.-assembly              | 1. E 06 | Filter.-element-petrol                    | 1. I 08 | G/box selectors.-gearbox assy-1 + 2                                     | 1. E 07 | Heater control.-heater control-valeo          | 1. J 17 |
| Crown wheel & pinion.-assembly              | 1. F 06 | Fixing clip                               | 1. J 08 | G/box selectors.-gearchange-short                                       | 1. E 09 | Heating.-matrix                               | 1. J 16 |
| Cylinder head.-cylinder head                | 1. C 06 | Fixing clip                               | 1. L 17 | Gaiter.-gear lever                                                      | 2. F 06 | Hinge.-armrest-grey                           | 2. G 03 |
| Cylinder                                    | 1. C 03 | Fixing clip                               | 2. G 03 | Gear lever knob.-gear lever                                             | 1. E 09 | Hinge.-assembly-rh                            | 2. C 13 |
| Cylinder.-brake-rh-bendix                   | 1. H 03 | Fixing clip                               | 2. G 05 | Gear                                                                    | 1. C 07 | Hinge.-centre console-rear                    | 2. F 06 |
| Cylinder.-rh                                | 1. H 02 | Fixing clip                               | 2. F 08 | Gear.-drive-3rd-25 teeth-25 x 32                                        | 1. E 05 | Hinge.-front door-lh upper                    | 2. C 16 |
| Cylinder.-steering rack                     | 1. G 06 | Fixing clip                               | 2. F 09 | Gear.-driven gear-38 teeth-11 x 38                                      | 1. E 06 | Hinge.-fuel filler                            | 2. D 09 |
| Dash assy.-assembly                         | 2. F 02 | Fixing clip                               | 2. F 10 | Gear.-oil pump-contr pinn-22 teeth                                      | 1. C 04 | Hinge.-rear door upper-lh                     | 2. C 17 |
| Deflector-radiator                          | 1. J 08 | Fixing clip                               | 2. F 11 | Gear.-pinion                                                            | 1. G 06 | Hinge.-trunk lid.-lh                          | 2. D 07 |
| Differential.-housing-77mm diameter         | 1. F 06 | Fixing clip                               | 2. F 12 | Gear.-set-16/10 teeth-77mm diameter                                     | 1. F 06 | Horn.-high tone                               | 1. L 05 |
| Diodes-assembly-alternator                  | 1. K 05 | Fixing clip                               | 2. F 15 | Gear.-starter motor                                                     | 1. K 07 | Hose                                          | 2. D 12 |
| Door assy                                   | 2. D 07 | Fixing clip                               | 2. F 16 | Gear.-tachometer-worm drive-22 teeth                                    | 1. E 08 | Hose.-air hose                                | 1. I 02 |
| Door assy                                   | 2. C 13 | Fixing clip                               | 2. F 17 | Glass.-exterior mirror -lh                                              | 2. D 14 | Hose.-brake vacuum                            | 1. H 05 |
| Door assy.-front-lh                         | 2. C 16 | Fixing clip.-8 x 6-2,8                    | 1. I 07 | Glass.-rear screen-tinted                                               | 2. D 11 | Hose.-evacuation-with atc-valeo               | 1. J 02 |

| SAMAND                                     |         |                                           | B04<br>Fiche 1 | DESCRIPTIVE INDEX "Hose-filler" TO "Pump-non abs-diameter 20.60" |         |                                          |         |
|--------------------------------------------|---------|-------------------------------------------|----------------|------------------------------------------------------------------|---------|------------------------------------------|---------|
| Hose-filler                                | 1. I 07 | Light-fog-front lh                        | 1. K 11        | Nut-flanged head-6 x 100                                         | 1. L 03 | Pipe-fuel feed                           | 1. I 08 |
| Hose-freon air con                         | 1. J 04 | Light-headlamp-assembly-front lh-with     | 1. K 08        | Nut-flanged head-6 x 100                                         | 1. L 08 | Pipe-heater assy                         | 1. J 16 |
| Hose-fuel return                           | 1. I 08 | Light-interior-rear                       | 1. K 12        | Nut-flanged head-m6 x 100                                        | 1. L 14 | Pipe-high pressure                       | 1. G 08 |
| Hose-heater assy                           | 1. J 16 | Light-open warning-front & rear-door      | 1. K 13        | Nut-flanged-m6 x 100-12                                          | 2. D 03 | Pipe-l = 425                             | 1. H 08 |
| Hose-l = 445-flexible                      | 1. H 08 | Link                                      | 1. I 03        | Nut-hexagonal head-5 x 80                                        | 1. H 06 | Pipe-non catalyst-down pipe              | 1. I 09 |
| Hose-oil vapour                            | 1. C 13 | Link.-+ finger                            | 1. E 07        | Nut-hexagonal-6 x 100                                            | 1. I 05 | Pipe-oil guide                           | 1. C 12 |
| Hose-vacuum union                          | 1. I 04 | Link.-accelerator drum                    | 1. I 12        | Nut-hub fixing-30 x 1.50                                         | 1. F 09 | Pipe-set-lhd                             | 1. G 06 |
| Hose-vacuum union                          | 1. I 05 | Link.-battery clamp-120mm                 | 1. L 08        | Nut-m10                                                          | 1. G 07 | Pipe-water outlet                        | 1. J 11 |
| Hose-water intake                          | 1. J 10 | Link.-bonnet                              | 2. C 13        | Nut-m10                                                          | 2. D 16 | Piston-dia. 16x25                        | 1. C 11 |
| Hose-windscreen washer-bent                | 2. D 13 | Link.-door lock-front lh                  | 2. C 18        | Nut-m11                                                          | 1. C 03 | Piston-engine set with pistons           | 1. C 05 |
| Housing body                               | 1. H 07 | Link.-door lock-rear lh                   | 2. D 04        | Nut-m12 x 150-12-26                                              | 1. E 07 | Piston-steering rack                     | 1. G 05 |
| Housing body-blower assy-with atc-valeo    | 1. J 15 | Link-lever-gearchange                     | 1. E 09        | Nut-m5 x 80-6-15                                                 | 1. I 06 | Piston-steering rack                     | 1. G 07 |
| Housing body-water outlet                  | 1. J 11 | Link-trunk lock actuator                  | 2. D 08        | Nut-m6 x 100                                                     | 1. I 07 | Plate-brake-lh-bendix                    | 1. H 03 |
| Housing-heater assy-valeo                  | 1. J 15 | Lock-bonnet                               | 2. C 14        | Nut-m6 x 100                                                     | 1. K 09 | Plug/cover                               | 1. L 03 |
| Hub                                        | 1. F 02 | Lock-front door lock-lh                   | 2. C 18        | Nut-m6 x 100                                                     | 1. J 10 | Plug/cover                               | 1. G 10 |
| Ignition coil-ignition                     | 1. K 02 | Lock-rear door lock-lh                    | 2. D 04        | Nut-m6-caged                                                     | 2. D 12 | Plug/cover                               | 2. F 04 |
| Ignition harness-ignition                  | 1. K 02 | Lock-seat belt                            | 2. G 04        | Nut-regulator fixing-flanged-m6 x 100-12                         | 2. D 05 | Plug/cover-armrest-grey                  | 2. G 03 |
| Indicator-fuel                             | 1. K 15 | Lock-trunk lid                            | 2. D 08        | Nut-self locking-12 x 175                                        | 1. F 08 | Plug/cover-centre console-rear           | 2. F 06 |
| Injector-sagem                             | 1. I 04 | Manifold-exhaust                          | 1. I 09        | Nut-self locking-14 x 150                                        | 1. J 05 | Plug/cover-cylinder head                 | 1. C 06 |
| Instrument cluster-kmh                     | 1. K 15 | Manifold-mgi with gasket                  | 1. I 03        | Nut-self locking-m14                                             | 1. F 02 | Plug/cover-ecu protection box            | 1. K 03 |
| Isolator-waterproof-front door-lh          | 2. F 08 | Module-heater module-with atc-valeo       | 1. J 13        | Nut-self locking-m14                                             | 1. G 02 | Plug/cover-fuel filler                   | 2. D 09 |
| Isolator-waterproof-front door-lh          | 2. F 09 | Motor-200w                                | 1. J 08        | Nut-self locking-m14                                             | 1. F 05 | Plug/cover-radiator-1.4 bar              | 1. J 09 |
| Isolator-waterproof-rear door-rh           | 2. F 11 | Motor-air intake-with atc-valeo           | 1. J 13        | Nut-self locking-m16                                             | 1. F 10 | Plug/cover-reservoir                     | 1. H 06 |
| Jack handle                                | 2. H 02 | Motor-windscreen wiper-assembly           | 2. D 12        | Nut-self locking-m6 x 100-8                                      | 1. E 09 | Plug/cover-windscreen washer bottle      | 2. D 13 |
| Key blade                                  | 1. G 04 | Moulding                                  | 1. C 04        | Nut-self locking-m8                                              | 1. G 03 | Potentiometer-sagem                      | 1. I 05 |
| Kit-alternator                             | 1. K 05 | Mudguard-upper-front lh                   | 2. D 17        | Nut-self locking-m8                                              | 1. H 04 | Protecting plate                         | 1. F 03 |
| Kit-assembly-rear silencer                 | 1. I 10 | Nut                                       | 1. J 04        | Nut-self locking-m8 x 125                                        | 1. I 03 | Protecting plate                         | 1. L 03 |
| Kit-brake cylinder                         | 1. H 02 | Nut                                       | 1. M 06        | Nut-shaft-20 x 150-11                                            | 1. E 05 | Protecting plate-d post upper            | 2. F 12 |
| Kit-brake lever assy                       | 1. H 03 | Nut-10 x 150                              | 2. C 02        | Nut-shaft-20 x 150-11                                            | 1. E 06 | Protecting plate-ring                    | 1. G 07 |
| Kit-brake servo-teves                      | 1. H 05 | Nut-10 x 150-self locking                 | 1. F 03        | Nut-steering lhd-square-12 x 150-18-16                           | 1. G 06 | Protecting plate-steering lhd            | 1. G 06 |
| Kit-compressor-sanden                      | 1. J 05 | Nut-4.2-speed                             | 2. D 15        | Nut-stoneguard to body-with base-m7 x                            | 2. C 11 | Protecting plate-upper                   | 2. D 15 |
| Kit-exhaust olive-assembly-front           | 1. I 09 | Nut-4.2-speed                             | 2. D 17        | Nut-stop-17mm                                                    | 1. E 03 | Protector                                | 1. F 02 |
| Kit-fixing kit                             | 1. F 02 | Nut-6 x 100                               | 1. I 02        | Nut-with base-m7 x 100-6-14                                      | 2. C 16 | Protector                                | 1. F 05 |
| Kit-hub                                    | 1. F 09 | Nut-8 x 125                               | 1. F 04        | Nut-with base-m7 x 100-6-14                                      | 2. C 17 | Protector-assembly-fixing kit            | 1. F 07 |
| Kit-kit                                    | 1. F 03 | Nut-8 x 125                               | 1. H 07        | Nut-with washer-m6                                               | 2. D 04 | Protector-bleed screw-girling            | 1. H 02 |
| Kit-repair                                 | 1. E 04 | Nut-bearing-m7-7 x 100                    | 1. F 07        | Nut-with washer-m6                                               | 2. C 18 | Protector-clutch-cable                   | 1. D 03 |
| Kit-repair                                 | 1. C 12 | Nut-caged-6 x 100                         | 1. J 13        | Nut-with washer-m6-manifold-lower                                | 1. I 11 | Protector-elbow ducting-dash air vent-lh | 1. J 14 |
| Kit-starter motor-assembly                 | 1. K 07 | Nut-cap-6 x 100                           | 1. C 06        | Nut-with washer-m6-manifold-lower                                | 2. D 09 | Protector-front door-outer lh            | 2. D 06 |
| Lamp                                       | 1. K 08 | Nut-centre console-bracket-rear           | 2. F 07        | Nut-with washer-m6-manifold-lower                                | 2. D 13 | Protector-gearchange-linkage             | 1. E 09 |
| Lamp                                       | 1. K 09 | Nut-clamping                              | 1. J 14        | Nut-with washer-m6-manifold-lower                                | 2. D 18 | Protector-steering                       | 1. G 03 |
| Lamp                                       | 1. K 10 | Nut-fascia to body-hexagonal head-10 x 18 | 2. F 02        | Oil pump-oil pump-housing                                        | 1. C 11 | Protector-steering rack                  | 1. G 05 |
| Lamp                                       | 1. K 11 | Nut-flange-5 x 80                         | 1. K 03        | Panel                                                            | 2. G 04 | Protector-steering rack                  | 1. G 07 |
| Lamp                                       | 1. K 12 | Nut-flange-5 x 80                         | 1. K 06        | Panel-adjuster-seat belt-b/c post upper                          | 2. F 12 | Protectors                               | 2. C 03 |
| Lamp                                       | 1. K 13 | Nut-flange-5 x 80                         | 1. J 08        | Panel-front                                                      | 2. C 09 | Protectors-20 x 28                       | 1. I 02 |
| Lever                                      | 1. D 02 | Nut-flange-5 x 80                         | 2. G 03        | Panel-front seat                                                 | 2. C 06 | Protectors-alternator-diameter 8mm       | 1. K 04 |
| Lever-accelerator control                  | 1. I 12 | Nut-flange-5 x 80                         | 2. D 08        | Panel-radiator support                                           | 1. J 07 | Protectors-dash                          | 2. G 07 |
| Lever-bonnet release                       | 2. C 14 | Nut-flange-6 x 100                        | 1. I 08        | Panel-radiator support                                           | 2. C 05 | Protectors-diameter 8.2 x 54 x 13.2      | 1. F 09 |
| Lever-handbrake                            | 1. H 07 | Nut-flange-6 x 100                        | 1. G 10        | Panel-rear axle                                                  | 2. C 07 | Protectors-half                          | 1. I 12 |
| Lever-rear door lock                       | 2. D 04 | Nut-flange-6 x 100                        | 1. J 15        | Panel-rear quarter inner-lh                                      | 2. C 10 | Protectors-rear door lower hinge         | 2. C 17 |
| Lever-return-gearchange-lower              | 1. E 09 | Nut-flange-m6                             | 1. G 08        | Parcel shelf-grey                                                | 2. F 15 | Protectors-steering rack                 | 1. G 07 |
| Lever-starter motor-assembly               | 1. K 07 | Nut-flange-m8                             | 1. K 04        | Pedal assy-accelerator                                           | 1. I 12 | Protectors-upper-front spring            | 1. F 02 |
| Lever-wiper road set                       | 2. D 12 | Nut-flange-m8                             | 1. H 05        | Pedal assy-brake                                                 | 1. H 04 | Protectors-water pump                    | 1. I 03 |
| Lifting jack-set of                        | 2. H 02 | Nut-flange-m8                             | 1. H 08        | Pedal assy-clutch                                                | 1. D 04 | Pulley-crankshft                         | 1. C 04 |
| Light-assembly-high mounted stop           | 1. K 10 | Nut-flange-m8                             | 1. I 10        | Pipe                                                             | 1. C 03 | Pump                                     | 1. C 14 |
| Light-assembly-tail light-trunk mounted-rh | 1. K 09 | Nut-flange-m8 x 125                       | 1. I 09        | Pipe-filler without reducer                                      | 1. I 07 | Pump-non abs-diameter 20.60              | 1. H 06 |

| SAMAND                                              |         | B05<br>Fiche 1                                   |         | DESCRIPTIVE INDEX "Pump.-oil-assembly" TO "Shaft.-shaft-1-2-3-4" |         |                                                    |         |
|-----------------------------------------------------|---------|--------------------------------------------------|---------|------------------------------------------------------------------|---------|----------------------------------------------------|---------|
| Pump.-oil-assembly.....                             | 1. C 11 | Rubbing strip.-front bumper -lh .....            | 2. D 15 | Screw.-duct to bracket-4.2 x 13-front panel-.....                | 2. F 07 | Screw.-shouldered-m7 x 100-25 .....                | 1. C 14 |
| Pump.-petrol.....                                   | 1. I 08 | Rubbing strip.-front fender-lh .....             | 2. E 02 | Screw.-ecu to support-m5 x 0.80 .....                            | 1. K 03 | Screw.-shouldered-m8 x 125-20 .....                | 1. D 02 |
| Pump.-steering.....                                 | 1. G 09 | Rubbing strip.-rear bumper-middle .....          | 2. D 16 | Screw.-electric aerial to body-m6 x 100 I20 .....                | 1. M 06 | Screw.-shouldered-m8 x 125-20 .....                | 1. H 08 |
| Pump.-windscreen washer.....                        | 2. D 13 | Safety catch .....                               | 2. C 13 | Screw.-engine harness-m5 x 0.80 .....                            | 1. L 10 | Screw.-socket head-m10 x 150-60 .....              | 1. K 06 |
| Radiator.-new.....                                  | 1. J 09 | Safety catch.-assembly-bonnet.-with spring ..... | 2. C 14 | Screw.-flanged head-m6 x 100-20 .....                            | 1. L 14 | Screw.-steel wheels-m12 x 1.25.....                | 1. F 11 |
| Radio aerial-assembly .....                         | 1. M 06 | Safety catch.-door lock.....                     | 2. D 04 | Screw.-flanged-m6 x 100-22-inner.....                            | 1. K 08 | Screw.-steering lhd-12 x 150-95-cap head.....      | 1. G 06 |
| Radio cassette.....                                 | 1. M 03 | Safety catch.-door lock.....                     | 2. C 18 | Screw.-flanged-m6 x 100-22-inner.....                            | 1. K 11 | Screw.-support fixing-4.2 x 8.5 .....              | 2. D 05 |
| Rail.-lh.....                                       | 2. C 05 | Safety catch.-hoisting.....                      | 2. C 02 | Screw.-flanged-m6 x 100-35 .....                                 | 1. J 13 | Screw.-upper-m16 x 113 .....                       | 1. F 10 |
| Rail.-rear-lh.....                                  | 2. C 06 | Safety catch.-rear-seat belt-lh-grey .....       | 2. F 15 | Screw.-flanged-m6 x 100-35 .....                                 | 1. J 15 | Screw.-wheel arch liner-4.2 x 21 .....             | 2. D 17 |
| Rail.-trunk floor.....                              | 2. C 07 | Safety catch.-seat belt-b/c post lower-lh-.....  | 2. F 12 | Screw.-flanged-m6 x 100-35 .....                                 | 2. C 14 | Screw.-with washer-m6 x 100-20 .....               | 2. G 03 |
| Rear view mirror-electric curved-driver's.....      | 2. D 14 | Safety catch.-trunk lid .....                    | 2. D 08 | Screw.-housing-m6 x 100-23 .....                                 | 1. C 10 | Seal.....                                          | 1. I 04 |
| Regulator.-assembly-alternator.....                 | 1. K 05 | Screw.....                                       | 1. L 03 | Screw.-link .....                                                | 1. F 04 | Seal.-bearing .....                                | 1. C 03 |
| Regulator.-injector-sagem.....                      | 1. I 04 | Screw.....                                       | 1. J 04 | Screw.-m10 x 1.50.....                                           | 1. F 03 | Seal.-bearing 90x110-7 .....                       | 1. C 04 |
| Regulator.-regulator-fuel feed-mmdcm .....          | 1. I 03 | Screw.....                                       | 2. D 09 | Screw.-m10 x 150-45 .....                                        | 2. C 03 | Seal.-camshaft .....                               | 1. C 07 |
| Regulator.-with atc-valeo .....                     | 1. J 03 | Screw.....                                       | 2. D 14 | Screw.-m2.9 .....                                                | 2. F 05 | Seal.-heater assy .....                            | 1. J 16 |
| Relay.-electric fan.....                            | 1. J 08 | Screw.-10 x 150 .....                            | 1. K 04 | Screw.-m4.5 x 10-trim cover-instrument .....                     | 2. F 02 | Seal.-housing .....                                | 1. J 08 |
| Relay.-electric window lift .....                   | 2. D 03 | Screw.-3.5 x 16 .....                            | 2. F 12 | Screw.-m4.5 x 10-trim cover-instrument .....                     | 2. F 04 | Seal.-interior = 13.5.....                         | 1. J 04 |
| Relay.-injection feed + fuel pump .....             | 1. I 05 | Screw.-3.5-13-self tapping .....                 | 1. K 17 | Screw.-m5 x 80.-centre console-top .....                         | 2. F 06 | Seal.-lever .....                                  | 1. E 07 |
| Relay.-roof lamp timer .....                        | 2. F 02 | Screw.-4.2 x 12 .....                            | 1. G 02 | Screw.-m6 x 100 I20 sll dac500a.....                             | 1. I 11 | Seal.-lh-40 x 58 - 11.3.....                       | 1. F 06 |
| Relay.-starter motor.....                           | 1. K 07 | Screw.-4.2 x 13-front panel-lower .....          | 1. J 14 | Screw.-m6 x 100-12 .....                                         | 1. I 04 | Seal.-reservoir.....                               | 1. H 06 |
| Relay.-starter-black .....                          | 1. L 04 | Screw.-4.2 x 13-front panel-lower .....          | 1. J 17 | Screw.-m6 x 100-12 .....                                         | 2. D 07 | Seal.-rh .....                                     | 1. F 07 |
| Remote control.-r/f remote control-jack knife ..... | 1. G 04 | Screw.-4.2 x 21 .....                            | 2. D 15 | Screw.-m6 x 100-12 .....                                         | 2. C 18 | Seal.-ring-29.1 x 32-1.6.....                      | 1. G 05 |
| Reservoir.-brake hydraulic .....                    | 1. H 06 | Screw.-4.2 x 21 .....                            | 2. D 16 | Screw.-m6 x 100-16 .....                                         | 2. F 15 | Seal.-ring-29.1 x 32-1.6.....                      | 1. G 07 |
| Reservoir.-intermediate .....                       | 1. I 09 | Screw.-4.5 x 15 .....                            | 1. M 05 | Screw.-m6 x 100-20 .....                                         | 1. J 06 | Seal.-seal dia 85.8x88.3x1.25 .....                | 1. C 05 |
| Reservoir.-rear .....                               | 1. I 10 | Screw.-4.5 x 20 .....                            | 1. I 12 | Screw.-m6 x 100-20 .....                                         | 2. D 08 | Seal.-throttle body to manifold-maroon .....       | 1. I 03 |
| Reservoir.-reservoir.....                           | 1. G 10 | Screw.-4.5 x 20 .....                            | 1. J 12 | Screw.-m6 x 100-20 .....                                         | 2. F 10 | Seal.-valve stem .....                             | 1. C 08 |
| Reservoir.-windscreen washer .....                  | 2. D 13 | Screw.-4.8-19 .....                              | 1. I 07 | Screw.-m6 x 100-20 .....                                         | 2. F 11 | Seal.-washer pump to bottle.....                   | 2. D 13 |
| Ring.....                                           | 1. C 05 | Screw.-4.80mm-front panel-lower .....            | 2. F 03 | Screw.-m6 x 100-20 .....                                         | 2. C 12 | Seat adjuster.-height adjustment-lh.....           | 2. F 16 |
| Ring.-tank.....                                     | 1. I 06 | Screw.-5 x 80 -50.....                           | 1. K 02 | Screw.-m6 x 100-25 .....                                         | 2. F 08 | Seat adjuster.-lumber support .....                | 2. F 17 |
| Rivet.....                                          | 2. G 03 | Screw.-6 x 1.00-10-brake cylinder.....           | 1. H 03 | Screw.-m6 x 100-25 .....                                         | 2. F 09 | Seat belt.-front.....                              | 2. G 04 |
| Rivet.....                                          | 2. F 08 | Screw.-6 x 100 .....                             | 1. I 02 | Screw.-m6 x 100-25 .....                                         | 2. D 12 | Seat frame.-front seat-lh.....                     | 2. F 16 |
| Rivet.....                                          | 2. F 09 | Screw.-7/16x20-18 .....                          | 2. G 04 | Screw.-m6 x 100-25 .....                                         | 2. C 13 | Seat frame.-front seat-rh .....                    | 2. F 17 |
| Rivet.....                                          | 2. F 10 | Screw.-bleed .....                               | 1. H 02 | Screw.-m6 x 100-25 .....                                         | 2. C 16 | Seat padding.-front seat backrest .....            | 2. F 17 |
| Rivet.....                                          | 2. F 11 | Screw.-caged-m6 x 100-12 .....                   | 1. I 05 | Screw.-m6 x 100-25 .....                                         | 2. C 17 | Seat padding.-front seat cushion.....              | 2. F 16 |
| Rivet.-4.8 x 13.....                                | 2. F 02 | Screw.-cap head-m10 x 100-21.5 .....             | 1. F 06 | Screw.-m7 x 100-44 .....                                         | 1. F 07 | Seat padding.-rear squab.....                      | 2. G 03 |
| Road wheel.-steel-5.50 j14-14 hole .....            | 1. F 11 | Screw.-cap head-m10 x 150-55 .....               | 1. J 05 | Screw.-m8 x 125 .....                                            | 1. I 03 | Seating.....                                       | 2. F 17 |
| Rocker piston.-valve .....                          | 1. C 08 | Screw.-cap head-m12 x 175-58 .....               | 2. C 02 | Screw.-m8 x 125 - 40.....                                        | 2. F 16 | Seating.-assembly-rear squab-grey .....            | 2. G 03 |
| Roof panel.-assembly .....                          | 2. C 09 | Screw.-cap head-m5 x 80-25 .....                 | 1. H 06 | Screw.-m8 x 125 - 40.....                                        | 2. F 17 | Sensor.-evaporator-with atc-valeo.....             | 1. J 03 |
| Rotor.-alternator .....                             | 1. K 05 | Screw.-cap head-m6 x 100-20 .....                | 2. D 04 | Screw.-m8 x 125-16 .....                                         | 1. L 08 | Sensor.-fluid level .....                          | 1. J 09 |
| Rotor.-starter motor-starter .....                  | 1. K 07 | Screw.-cap head-m7 x 100-16 .....                | 1. E 08 | Screw.-m8 x 125-35.....                                          | 1. I 10 | Sensor.-oil pressure .....                         | 1. C 12 |
| Rubber cover.-glovebox .....                        | 2. F 04 | Screw.-cap head-m7 x 100-18 .....                | 1. G 05 | Screw.-m8 x 125-50.....                                          | 1. E 05 | Sensor.-pressure-sagem .....                       | 1. I 05 |
| Rubber cover.-pedal .....                           | 1. D 04 | Screw.-cap head-m7 x 100-18 .....                | 1. G 07 | Screw.-m8 x 38.....                                              | 1. G 03 | Sensor.-probe-probe .....                          | 1. J 11 |
| Rubber cover.-pedal-assembly .....                  | 1. H 04 | Screw.-cap head-m8 x 125-25 .....                | 2. C 11 | Screw.-manifold heatshield-8 x 125 .....                         | 1. I 09 | Sensor.-tachometer- 3 way.....                     | 1. E 08 |
| Rubber cover.-suspension .....                      | 2. C 02 | Screw.-casing.....                               | 1. C 03 | Screw.-oil filter 20x1.50-27 .....                               | 1. C 12 | Sensor.-unit-mmdcm .....                           | 1. I 03 |
| Rubber seal.-air intake .....                       | 1. J 12 | Screw.-column.....                               | 1. C 07 | Screw.-oil pump-m7 x 100-70 .....                                | 1. C 11 | Sensor.-water temperature-blue .....               | 1. J 08 |
| Rubber seal.-bonnet front .....                     | 2. C 15 | Screw.-column.....                               | 1. F 08 | Screw.-pedal .....                                               | 1. H 04 | Servo unit.....                                    | 1. H 05 |
| Rubber seal.-drip rail-lh.....                      | 2. D 18 | Screw.-column.....                               | 1. G 09 | Screw.-pedal to brkt-4-20 .....                                  | 1. D 04 | Set of barrel.-r/f remote control-jack knife ..... | 1. G 04 |
| Rubber seal.-front door-lh.....                     | 2. D 03 | Screw.-column-m7 x 100-40-20 .....               | 1. E 03 | Screw.-pressure relief valve-with atc-valeo.....                 | 1. J 02 | Shaft.-10 x 14.....                                | 1. H 04 |
| Rubber seal.-front door-lh.....                     | 2. D 06 | Screw.-connecting rod dia 9x100 .....            | 1. C 05 | Screw.-pulley-m14 x 150-70 .....                                 | 1. C 04 | Shaft.-column .....                                | 1. G 03 |
| Rubber seal.-insert-rear door-lh.....               | 2. D 05 | Screw.-console to roof-4.2 x 16.....             | 2. F 14 | Screw.-radiator and fan-22 x 150.....                            | 1. J 08 | Shaft.-connecting .....                            | 1. G 05 |
| Rubber seal.-lh.....                                | 2. D 14 | Screw.-counter sunk-raised head-3.5 x 13.....    | 1. K 15 | Screw.-return-gearchange .....                                   | 1. E 09 | Shaft.-connecting .....                            | 1. G 07 |
| Rubber seal.-rear door-lh.....                      | 2. D 02 | Screw.-crossmember-m8 x 125-20.....              | 1. J 07 | Screw.-rlx 4,5 - 12 .....                                        | 1. J 03 | Shaft.-hypoid set-75 teeth-reinforced .....        | 1. E 06 |
| Rubber seal.-rear screen .....                      | 2. D 11 | Screw.-cylinder head.....                        | 1. C 06 | Screw.-shouldered-m6 x 100-20.....                               | 1. G 10 | Shaft.-hypoid set-75 teeth-reinforced .....        | 1. F 06 |
| Rubber seal.-trunk lid .....                        | 2. D 07 | Screw.-drain .....                               | 1. J 10 | Screw.-shouldered-m7 x 100-22.....                               | 1. E 06 | Shaft.-primary-11/12/23-21 teeth .....             | 1. E 05 |
| Rubber seal.-windscreen .....                       | 2. D 10 | Screw.-drain-thermostat housing .....            | 1. J 11 | Screw.-shouldered-m7 x 100-22.....                               | 1. E 07 | Shaft.-shaft-1-2-3-4 .....                         | 1. E 07 |



| SAMAND                                             |         | B06<br>Fiche 1                                   | DESCRIPTIVE INDEX "Shield." TO "Wiper conrod assy." |                                                  |         |                                          |         |
|----------------------------------------------------|---------|--------------------------------------------------|-----------------------------------------------------|--------------------------------------------------|---------|------------------------------------------|---------|
| Shield.....                                        | 1. E 09 | Switch.-switch.-rear door-rh.....                | 2. F 11                                             | Washer.-14 x 38.....                             | 1. F 02 | Washer.-water pump-asbestos free.....    | 1. C 14 |
| Shield.-front floor.-front.....                    | 2. G 05 | Tensioner.....                                   | 1. K 04                                             | Washer.-32mm diameter.....                       | 1. J 10 | Welch plug.-floor.-round.....            | 2. E 04 |
| Shield.-heat.....                                  | 1. I 11 | Tensioner.....                                   | 1. C 07                                             | Washer.-6 x 22.....                              | 2. D 12 | Wheel cover.-road wheel.....             | 1. F 11 |
| Shield.-manifold.....                              | 1. I 09 | Tensioner.-seat belt-lh.....                     | 2. F 13                                             | Washer.-8 x 22mm-plain.....                      | 1. H 07 | Wheel hub.-disc.....                     | 1. F 03 |
| Shield.-scuttle manifold centre.....               | 2. G 07 | Thermostat.-82 degrees c.....                    | 1. J 11                                             | Washer.-adjustment.....                          | 1. G 06 | Wheel hub.-without abs.....              | 1. F 09 |
| Shield.-tachometer.....                            | 1. E 08 | Thermostat.-less harness-blue.-less atc.....     | 1. J 03                                             | Washer.-adjustment set-39 x 46-ep 0,7 a 2,4..... | 1. E 05 | Wheel trim tool.-wheel trim removal..... | 2. H 02 |
| Shield.-under rear backrest-lh.....                | 2. G 06 | Thrust bearing.-thrust-standard-2.28mm.....      | 1. C 04                                             | Washer.-asbestos free.....                       | 1. C 03 | Window lifter.-front door-lh.....        | 2. D 03 |
| Shield.-waterproof-rear door-lh.....               | 2. F 10 | Torsion bar.-diameter 20-lh.....                 | 1. F 08                                             | Washer.-asbestos free.....                       | 1. C 12 | Window lifter.-rear door-lh.....         | 2. D 05 |
| Sill.-inner-lh.....                                | 2. C 08 | Transmission.-new-reinforced.....                | 1. E 02                                             | Washer.-crinkle-13 x 25.....                     | 2. G 04 | Wiper blade.-lh.....                     | 2. D 12 |
| Slide.-drivers seat.....                           | 2. F 16 | Trim.....                                        | 1. K 10                                             | Washer.-cylinder head cover.....                 | 1. C 06 | Wiper conrod assy.....                   | 2. D 12 |
| Slide.-insert-front door-lh.....                   | 2. D 03 | Trim.-a post lower-lh-grey.....                  | 2. F 13                                             | Washer.-drain screw.....                         | 1. J 11 |                                          |         |
| Slide.-passenger seat.....                         | 2. F 17 | Trim.-air channel -upper.....                    | 1. J 13                                             | Washer.-elastic.....                             | 2. F 10 |                                          |         |
| Slide.-rear door-lh.....                           | 2. D 05 | Trim.-air con controls-centre console-front..... | 2. F 05                                             | Washer.-elastic.....                             | 2. F 11 |                                          |         |
| Socket tool.-socket.....                           | 1. I 08 | Trim.-b/c post upper-lh-grey.....                | 2. F 12                                             | Washer.-elastic.....                             | 2. F 15 |                                          |         |
| Socket.....                                        | 1. C 03 | Trim.-centre console-rear.....                   | 2. F 06                                             | Washer.-flexible-m10 x 21.3-1.....               | 1. K 06 |                                          |         |
| Socket.-centre console-rear.....                   | 2. F 06 | Trim.-dash side cover-lh.....                    | 2. F 03                                             | Washer.-flexible.-8 x 17.....                    | 1. F 04 |                                          |         |
| Socket.-locking.....                               | 1. F 07 | Trim.-door lock knob.....                        | 2. F 10                                             | Washer.-fuel pipe.....                           | 1. I 07 |                                          |         |
| Sound deadening.-a post lower-rh.....              | 2. F 13 | Trim.-door lock knob.....                        | 2. F 11                                             | Washer.-heater assy-heater assy.....             | 1. J 15 |                                          |         |
| Spark plug.-spark-eyquem.....                      | 1. K 02 | Trim.-exterior mirror -inner lh.....             | 2. D 14                                             | Washer.-heater elbow.....                        | 1. J 14 |                                          |         |
| Speaker.-front-doors.....                          | 1. M 05 | Trim.-fascia panel-finisher.-upper.....          | 2. F 02                                             | Washer.-m14.....                                 | 1. G 02 |                                          |         |
| Spring.....                                        | 1. F 02 | Trim.-front door-lh.....                         | 2. C 18                                             | Washer.-m14.....                                 | 1. I 12 |                                          |         |
| Spring.....                                        | 1. E 07 | Trim.-front door-lh.....                         | 2. D 18                                             | Washer.-manifold to downpipe.....                | 1. I 09 |                                          |         |
| Spring.....                                        | 1. J 09 | Trim.-front seat-outer lh-grey.....              | 2. F 18                                             | Washer.-manifold-green.....                      | 1. I 03 |                                          |         |
| Spring.....                                        | 1. C 11 | Trim.-heater control-valeo.....                  | 1. J 17                                             | Washer.-plain-10.2 x 36.....                     | 1. C 07 |                                          |         |
| Spring.-brake-bendix-kit.....                      | 1. H 03 | Trim.-instrument housing.....                    | 1. K 15                                             | Washer.-plain-6 x 18.....                        | 2. C 14 |                                          |         |
| Spring.-cable.....                                 | 1. I 12 | Trim.-map-front door-rh.....                     | 2. F 09                                             | Washer.-plain-7 x 22.....                        | 1. E 06 |                                          |         |
| Spring.-lumber support.....                        | 2. F 16 | Trim.-map-lh.....                                | 2. F 08                                             | Washer.-plain-8 x 16.....                        | 1. K 04 |                                          |         |
| Spring.-lumber support.....                        | 2. F 17 | Trim.-oil pump.....                              | 1. C 11                                             | Washer.-plain-8 x 16.....                        | 1. G 09 |                                          |         |
| Spring.-pedal.....                                 | 1. D 04 | Trim.-rear door-lh.....                          | 2. D 04                                             | Washer.-plain-m10 x 20-2.....                    | 1. J 05 |                                          |         |
| Spring.-piston.....                                | 1. G 05 | Trim.-rear partition.....                        | 2. G 06                                             | Washer.-plain-m10 x 20-2.....                    | 1. E 09 |                                          |         |
| Spring.-piston.....                                | 1. G 07 | Trim.-roof.-front-grey.....                      | 2. F 14                                             | Washer.-plain.....                               | 1. F 05 |                                          |         |
| Spring.-trunk lid.....                             | 2. D 07 | Trim.-steering wheel pad.....                    | 1. G 02                                             | Washer.-plain.-6 x 12.....                       | 1. I 05 |                                          |         |
| Spring.-valve.....                                 | 1. C 08 | Trim.-thickness 12.....                          | 1. H 07                                             | Washer.-plain.-m10.....                          | 2. D 16 |                                          |         |
| Starter motor-assembly-starter-bosch-valeo.....    | 1. K 06 | Trim.-upper.....                                 | 1. C 10                                             | Washer.-plain.-m16.....                          | 1. F 10 |                                          |         |
| Stator.-alternator.....                            | 1. K 05 | Trim.-water-deflector.....                       | 1. J 12                                             | Washer.-planet-16.15 x 36-0.45.....              | 1. F 06 |                                          |         |
| Steering column.-steering.-non-specific key.....   | 1. G 04 | Trim.-with high-level stop lamp-grey.....        | 2. F 15                                             | Washer.-pulley dia 14 thickness 10.....          | 1. C 04 |                                          |         |
| Steering gear.-steering lhd.....                   | 1. G 06 | Union.-tee piece-windscreen washer.....          | 2. D 13                                             | Washer.-seal.....                                | 1. I 02 |                                          |         |
| Steering wheel.....                                | 1. G 02 | Union.-union.....                                | 1. H 08                                             | Washer.-seal-15 x 21-3.....                      | 1. E 07 |                                          |         |
| Striker.-boot floor carpet.....                    | 2. G 06 | Union.-water intake-32mm diameter.....           | 1. C 14                                             | Washer.-seat retaining.....                      | 2. F 16 |                                          |         |
| Subframe.-front.....                               | 2. C 03 | Valve guide.-intake guide repair + 0.590.....    | 1. C 08                                             | Washer.-seat retaining.....                      | 2. F 17 |                                          |         |
| Sun visors-lh-grey.....                            | 2. F 14 | Valve seat.-intake seat repair +0.60.....        | 1. C 08                                             | Washer.-servo.....                               | 1. H 05 |                                          |         |
| Support.-rear lamp-lh.....                         | 2. C 10 | Valve.-assembly.....                             | 1. F 11                                             | Washer.-spring.-4 x 11.2.....                    | 1. J 08 |                                          |         |
| Suspension link.-ball joint-lh.....                | 1. G 07 | Valve.-brake servo-bendix-bosch.....             | 1. H 05                                             | Washer.-spring.-m6 x 18-1,5.....                 | 1. C 10 |                                          |         |
| Suspension link.-ball joint-rh.....                | 1. G 05 | Valve.-intake dia 41.6.....                      | 1. C 08                                             | Washer.-star.....                                | 1. G 05 |                                          |         |
| Suspension link.-pin ball.....                     | 1. F 03 | Valve.-pressure relief-with atc-valeo.....       | 1. J 02                                             | Washer.-star.....                                | 1. G 07 |                                          |         |
| Suspension link.-support.....                      | 2. C 02 | Washer.....                                      | 1. G 03                                             | Washer.-star.....                                | 2. F 08 |                                          |         |
| Switch.....                                        | 1. H 07 | Washer.....                                      | 1. J 04                                             | Washer.-star.....                                | 2. F 09 |                                          |         |
| Switch.-contact-inertia.....                       | 1. I 06 | Washer.....                                      | 1. M 06                                             | Washer.-star-de6.....                            | 1. L 14 |                                          |         |
| Switch.-contact-inertia.....                       | 1. K 16 | Washer.....                                      | 1. F 08                                             | Washer.-star-m6.....                             | 2. F 02 |                                          |         |
| Switch.-electric window lift-front & rear.....     | 1. L 02 | Washer.....                                      | 1. F 09                                             | Washer.-stoneguard to body-engine and.....       | 2. C 11 |                                          |         |
| Switch.-hazzard warning.....                       | 1. K 18 | Washer.....                                      | 1. C 11                                             | Washer.-support.....                             | 1. H 04 |                                          |         |
| Switch.-lighting-direction indicator-steering..... | 1. K 17 | Washer.....                                      | 2. D 08                                             | Washer.-tachometer-8 x 16.....                   | 1. E 08 |                                          |         |
| Switch.-rheostat-panel illumination.....           | 1. G 02 | Washer.-10.2 x 17-13.....                        | 2. C 02                                             | Washer.-tank.....                                | 1. I 06 |                                          |         |
| Switch.-stop light.....                            | 1. H 04 | Washer.-10.2 x 17-13.....                        | 2. F 06                                             | Washer.-thickness 2.775.....                     | 1. C 09 |                                          |         |
| Switch.-switch-rear door-lh.....                   | 2. F 10 | Washer.-13 x 24.....                             | 1. F 03                                             | Washer.-valve spring dia 24.5 x 34.6-0.5.....    | 1. C 08 |                                          |         |

ایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک)





SAMAND

C02

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
STRIPPED ENGINE

Illus Part Number

1 175 05 001


Description

Engine.-new-Mark L6A ..... 1

Quantity

Change Point

Remarks



ZB0018

# MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

# GROUP INDEX

1800 cc PETROL FUEL INJECTED XU7 ..... 1.C 02  
BLOCK ..... 1.C 03  
CAMSHAFT, TIMING BELT ..... 1.C 07  
CON RODS, PISTONS ..... 1.C 05  
CRANKSHAFT, FLYWHEEL ..... 1.C 04  
CYLINDER HEAD ..... 1.C 06  
ENGINE COVERS ..... 1.C 10  
OIL FILLERS, BREATHERS ..... 1.C 13  
OIL PUMP ..... 1.C 11  
STRIPPED ENGINE ..... 1.C 02  
SUMP ..... 1.C 12  
VALVE SHIMS ..... 1.C 09  
VALVES, ROCKER GEAR ..... 1.C 08  
WATER PUMP ..... 1.C 14

# SAMAND

C03

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
BLOCK

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 099 | 01 | 005 |
| 2  | 186 | 03 | 024 |
| 3  | 038 | 06 | 017 |
| 4  | 040 | 09 | 010 |
| 5  | 040 | 09 | 004 |
| 6  | 186 | 03 | 067 |
| 7  | 221 | 07 | 001 |
| 8  | 221 | 07 | 002 |
| 9  | 042 | 02 | 011 |
| 10 | 038 | 06 | 010 |
| 11 | 030 | 04 | 001 |
| 12 | 017 | 10 | 002 |
| 13 | 040 | 17 | 002 |
| 14 | 040 | 17 | 001 |
| 15 | 174 | 03 | 016 |
| 16 | 186 | 01 | 073 |
| 17 | 166 | 10 | 005 |
| 18 | 186 | 07 | 003 |
| 70 | 040 | 01 | 277 |
| 71 | 186 | 03 | 079 |
| 72 | 042 | 02 | 012 |
| 73 | 040 | 09 | 016 |


Description

|                                         |   |
|-----------------------------------------|---|
| Cylinder.....                           | 1 |
| Washer.-asbestos free.....              | 2 |
| Block & pipe-cylinder block.....        | 1 |
| Screw.-casing.....                      | 1 |
| Screw.-22 x 150.....                    | 2 |
| Washer.-asbestos free.....              | 1 |
| Socket.....                             | 1 |
| Socket.....                             | 1 |
| Dowel.....                              | 2 |
| Block & pipe-36mm.....                  | 1 |
| Bush.-centring.....                     | 8 |
| Seal.-bearing.....                      | 2 |
| Screw.-bearing cap.....                 | 8 |
| Screw.-bearing cap.....                 | 2 |
| Nut.-M11.....                           | 2 |
| Washer.-8 x 17-0.8-plain-M8 x 16-3..... | 2 |
| Pipe.....                               | 1 |
| Washer.-engine kit.....                 | 1 |
| Screw.-M8 x 125-35.....                 | 1 |
| Washer.....                             | 2 |
| Dowel.....                              | 2 |
| Screw.-floor.-20mm diameter.....        | 1 |

Quantity

Change Point

Remarks



ZB0017


## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                        |        |
|----------------------------------------|--------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1.C 02 |
| BLOCK.....                             | 1.C 03 |
| CAMSHAFT, TIMING BELT .....            | 1.C 07 |
| CON RODS, PISTONS .....                | 1.C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1.C 04 |
| CYLINDER HEAD.....                     | 1.C 06 |
| ENGINE COVERS .....                    | 1.C 10 |
| OIL FILLERS, BREATHERS .....           | 1.C 13 |
| OIL PUMP .....                         | 1.C 11 |
| STRIPPED ENGINE .....                  | 1.C 02 |
| SUMP.....                              | 1.C 12 |
| VALVE SHIMS.....                       | 1.C 09 |
| VALVES, ROCKER GEAR .....              | 1.C 08 |
| WATER PUMP .....                       | 1.C 14 |



Illus Part Number

|    |            |
|----|------------|
| 1  | 180 01 008 |
| 2  | 065 06 010 |
| 3  | 065 06 002 |
| 4  | 039 02 005 |
| 5  | 040 01 107 |
| 6  | 186 01 076 |
| 7  | 017 02 002 |
| 8  | 017 11 008 |
| 9  | 126 17 003 |
| 10 | 042 07 001 |
| 11 | 188 08 006 |
| 12 | 188 08 007 |
| 12 | 188 09 025 |
| 13 | 188 08 008 |
| 13 | 188 09 010 |
| 13 | 188 09 008 |
| 13 | 188 08 009 |
| 13 | 188 09 007 |
| 13 | 188 08 013 |
| 13 | 188 09 009 |
| 13 | 188 08 014 |
| 14 | 026 01 001 |
| 14 | 026 02 002 |
| 14 | 026 02 005 |
| 14 | 026 02 004 |
| 15 | 065 11 005 |
| 16 | 065 11 002 |
| 17 | 040 01 138 |
| 22 | 040 01 128 |
| 70 | 058 03 003 |
| 71 | 040 01 064 |
| 74 | 042 07 030 |
| 75 | 186 02 003 |

Description

|                                                        |
|--------------------------------------------------------|
| Crankshaft.                                            |
| Gear.-oil pump-contr pinn-22 teeth                     |
| Gear.-21 teeth                                         |
| Pulley.-crankshaft                                     |
| Screw.-pulley-M14 x 150-70                             |
| Washer.-pulley Dia 14 Thickness 10                     |
| Seal.-bearing 90x110-7                                 |
| Seal.-crankshaft 42x62-7                               |
| Moulding,                                              |
| Dowel.-8x15                                            |
| Engine Bearing.                                        |
| Engine Bearing.-half upper 1.856 groove-Yellow.        |
| Engine Bearing.-half upper repair 2.006 groove-Yellow. |
| Engine Bearing.-half lower 1.836 smooth-Blue.          |
| Engine Bearing.-half lower repair 2.020 smooth-Red     |
| Engine Bearing.-half lower 1.986 smooth-Blue.          |
| Engine Bearing.-half lower 1.848 smooth-Black          |
| Engine Bearing.-half lower 1.998 smooth-Black          |
| Engine Bearing.-half lower 1.859 smooth-Green          |
| Engine Bearing.-half lower 2.009 smooth-Green          |
| Engine Bearing.-half lower 1.870 smooth-Red            |
| Thrust Bearing.-thrust-standard-2.28mm                 |
| Thrust Bearing.-thrust 1st repair +0.20                |
| Thrust Bearing.-thrust 3rd repair +0.40                |
| Thrust Bearing.-thrust 2nd repair +0.30                |
| Gear.-new 60 teeth                                     |
| Gear.-gear start 136 teeth                             |
| Screw.-flywheel-M9 x 100-22                            |
| Screw.-cap head-M7 x 100-18                            |
| Fixing Clip.-key 13x6-7                                |
| Screw.-M7 x 100-38                                     |
| Dowel.-6 X 17                                          |
| Washer.-7x13.7-0.8-flexible-7 x 13.7                   |

Quantity  
Change  
Point

Remarks

MPI

1800 cc XU7JP MPI

ZB0021

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

# SAMAND

C05

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
CON RODS, PISTONS

Illus Part Number

1 044 03 001  
2 188 01 010  
2 188 02 007  
2 188 03 006  
3 040 07 003  
4 042 01 004  
5 080 03 022  
6 041 07 001  
7 017 02 003


Description

Connecting Rods.-connecting set 4 ..... 1SET  
Engine Bearing.-half-Standard-set of 8 ..... 1SET  
Engine Bearing.-set 8 1/2 oversize +0.30 ..... 1SET  
Engine Bearing.-set 8 1/2 oversize +0.50 ..... 1SET  
Screw.-connecting rod Dia 9x100 ..... 8  
Dowel.-piston ..... 4  
Ring. .... 1  
Piston.-engine set with pistons ..... 1  
Seal.-seal Dia 85.8x88.3x1.25 ..... 1

Quantity

Change Point

Remarks



ZB002?

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

1800 cc PETROL FUEL INJECTED XU7 ..... 1.C 02  
BLOCK ..... 1.C 03  
CAMSHAFT, TIMING BELT ..... 1.C 07  
CON RODS, PISTONS ..... 1.C 05  
CRANKSHAFT, FLYWHEEL ..... 1.C 04  
CYLINDER HEAD ..... 1.C 06  
ENGINE COVERS ..... 1.C 10  
OIL FILLERS, BREATHERS ..... 1.C 13  
OIL PUMP ..... 1.C 11  
STRIPPED ENGINE ..... 1.C 02  
SUMP ..... 1.C 12  
VALVE SHIMS ..... 1.C 09  
VALVES, ROCKER GEAR ..... 1.C 08  
WATER PUMP ..... 1.C 14



# SAMAND

C06

Fiche 1

## ENGINE 1800 cc PETROL FUEL INJECTED XU7 CYLINDER HEAD

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 091 | 01 | 001 |
| 9  | 186 | 12 | 002 |
| 3  | 040 | 10 | 005 |
| 4  | 186 | 03 | 080 |
| 5  | 038 | 06 | 001 |
| 6  | 040 | 03 | 038 |
| 7  | 030 | 22 | 032 |
| 8  | 170 | 01 | 007 |
| 2  | 186 | 06 | 012 |
| 10 | 170 | 06 | 006 |
| 10 | 170 | 06 | 005 |
| 11 | 174 | 05 | 001 |
| 13 | 030 | 07 | 001 |
| 15 | 186 | 16 | 001 |
| 16 | 003 | 05 | 001 |
| 17 | 174 | 04 | 026 |


Description

Quantity

Change Point

Remarks

|                                               |    |  |  |
|-----------------------------------------------|----|--|--|
| Cylinder Head.-cylinder head .....            | 1  |  |  |
| Washer.-cylinder head cover .....             | 1  |  |  |
| Screw.-cylinder head .....                    | 10 |  |  |
| Washer.-welch-30mm .....                      | 3  |  |  |
| Block & pipe-35mm Diameter .....              | 1  |  |  |
| Screw.-cylinder head .....                    | 10 |  |  |
| Bush.-bearing cup-hexagonal head-6 x 100..... | 10 |  |  |
| Plug/Cover.-cylinder head.....                | 1  |  |  |
| Washer.-cylinder head-asbestos free .....     | 1  |  |  |
| Plug/Cover.-oil filler-Mann .....             | 1  |  |  |
| Plug/Cover.-oil filler-Mecaplast .....        | 1  |  |  |
| Nut.-cap-6 x 100 .....                        | 10 |  |  |
| Bush.-cylinder head-22mm.....                 | 1  |  |  |
| Washer.-set-valves .....                      | 1  |  |  |
| Badge. ....                                   | 1  |  |  |
| Nut.-with base-M7 x 100-6-14 .....            | 10 |  |  |



ZB0016

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                        |         |
|----------------------------------------|---------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1. C 02 |
| BLOCK.....                             | 1. C 03 |
| CAMSHAFT, TIMING BELT .....            | 1. C 07 |
| CON RODS, PISTONS .....                | 1. C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1. C 04 |
| CYLINDER HEAD .....                    | 1. C 06 |
| ENGINE COVERS .....                    | 1. C 10 |
| OIL FILLERS, BREATHERS .....           | 1. C 13 |
| OIL PUMP .....                         | 1. C 11 |
| STRIPPED ENGINE .....                  | 1. C 02 |
| SUMP .....                             | 1. C 12 |
| VALVE SHIMS .....                      | 1. C 09 |
| VALVES, ROCKER GEAR .....              | 1. C 08 |
| WATER PUMP .....                       | 1. C 14 |

# SAMAND

C07

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
CAMSHAFT, TIMING BELT

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 179 | 01 | 011 |
| 3  | 065 | 07 | 005 |
| 5  | 207 | 03 | 004 |
| 6  | 116 | 01 | 003 |
| 7  | 017 | 12 | 003 |
| 8  | 040 | 19 | 001 |
| 10 | 186 | 01 | 077 |
| 11 | 116 | 01 | 010 |
| 70 | 040 | 01 | 273 |
| 71 | 040 | 01 | 030 |




Description

|                                      |   |
|--------------------------------------|---|
| Camshaft.....                        | 1 |
| Gear.....                            | 1 |
| Drive Belt.-14 teeth.....            | 1 |
| Tensioner.....                       | 1 |
| Seal.-camshaft.....                  | 1 |
| Screw.-column.....                   | 1 |
| Washer.-plain-10.2 x 36.....         | 1 |
| Tensioner.-items 5, 6, 7, 8-kit..... | 1 |
| Screw.-cap head-M10 x 150-35.....    | 1 |
| Screw.-shouldered-M8 x 125-25.....   | 1 |

Quantity

Change Point

Remarks



ZB0025

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                        |         |
|----------------------------------------|---------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1. C 02 |
| BLOCK.....                             | 1. C 03 |
| CAMSHAFT, TIMING BELT .....            | 1. C 07 |
| CON RODS, PISTONS.....                 | 1. C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1. C 04 |
| CYLINDER HEAD.....                     | 1. C 06 |
| ENGINE COVERS.....                     | 1. C 10 |
| OIL FILLERS, BREATHERS .....           | 1. C 13 |
| OIL PUMP.....                          | 1. C 11 |
| STRIPPED ENGINE.....                   | 1. C 02 |
| SUMP.....                              | 1. C 12 |
| VALVE SHIMS.....                       | 1. C 09 |
| VALVES, ROCKER GEAR .....              | 1. C 08 |
| WATER PUMP .....                       | 1. C 14 |

# SAMAND

C08

Fiche 1

## ENGINE

1800 cc PETROL FUEL INJECTED XU7

VALVES, ROCKER GEAR

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 096 | 04 | 009 |
| 2  | 096 | 05 | 003 |
| 3  | 006 | 01 | 002 |
| 4  | 058 | 08 | 001 |
| 5  | 038 | 18 | 009 |
| 6  | 121 | 05 | 008 |
| 7  | 186 | 01 | 078 |
| 8  | 017 | 07 | 008 |
| 9  | 154 | 04 | 017 |
| 10 | 154 | 02 | 003 |
| 11 | 190 | 01 | 009 |
| 12 | 190 | 02 | 005 |


Description

|                                                |    |
|------------------------------------------------|----|
| Valve.-intake Dia 41.6 .....                   | 4  |
| Valve.-exhaust Dia 34.5 .....                  | 4  |
| Rocker Piston.-valve .....                     | 8  |
| Fixing Clip.-valve.....                        | 16 |
| Block & pipe-spring.....                       | 8  |
| Spring.-valve .....                            | 8  |
| Washer.-valve spring dia 24.5 x 34.6-0.5.....  | 8  |
| Seal.-valve stem .....                         | 4  |
| Valve Guide.-intake guide repair + 0.590.....  | 4  |
| Valve Guide.-exhaust guide repair + 0.590..... | 4  |
| Valve seat.-intake seat repair +0.60 .....     | 4  |
| Valve seat.-exhaust seat repair + 0.60 .....   | 4  |

Quantity

Change Point

Remarks



ZB0026

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX


|                                        |        |
|----------------------------------------|--------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1.C 02 |
| BLOCK .....                            | 1.C 03 |
| CAMSHAFT, TIMING BELT .....            | 1.C 07 |
| CON RODS, PISTONS .....                | 1.C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1.C 04 |
| CYLINDER HEAD .....                    | 1.C 06 |
| ENGINE COVERS .....                    | 1.C 10 |
| OIL FILLERS, BREATHERS .....           | 1.C 13 |
| OIL PUMP .....                         | 1.C 11 |
| STRIPPED ENGINE .....                  | 1.C 02 |
| SUMP .....                             | 1.C 12 |
| VALVE SHIMS .....                      | 1.C 09 |
| VALVES, ROCKER GEAR .....              | 1.C 08 |
| WATER PUMP .....                       | 1.C 14 |

# SAMAND

C09

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
VALVE SHIMS



| Illus | Part Number | Description                  | Quantity | Change Point | Remarks           |
|-------|-------------|------------------------------|----------|--------------|-------------------|
| 1     | 186 10 206  | Washer.-thickness 2.775..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 178  | Washer.-thickness 2.8.....   | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 207  | Washer.-thickness 2.825..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 208  | Washer.-thickness 2.85.....  | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 179  | Washer.-thickness 2.875..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 209  | Washer.-thickness 2.9.....   | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 210  | Washer.-thickness 2.925..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 180  | Washer.-thickness 2.950..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 211  | Washer.-thickness 2.975..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 212  | Washer.-thickness 3.....     | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 181  | Washer.-thickness 3.025..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 226  | Washer.-thickness 3.05.....  | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 227  | Washer.-thickness 3.075..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 182  | Washer.-thickness 3.1.....   | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 228  | Washer.-thickness 3.125..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 229  | Washer.-thickness 3.15.....  | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 183  | Washer.-thickness 3.175..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 230  | Washer.-thickness 3.2.....   | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 231  | Washer.-thickness 3.225..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 184  | Washer.-thickness 3.25.....  | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 232  | Washer.-thickness 3.275..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 233  | Washer.-thickness 3.3.....   | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 185  | Washer.-thickness 3.325..... | 1        |              | 1800 cc XU7JP MPi |
| 1     | 186 10 234  | Washer.-thickness 3.35.....  | 1        |              | 1800 cc XU7JP MPi |

ZB0019

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

1800 cc PETROL FUEL INJECTED XU7 ..... 1.C 02  
BLOCK ..... 1.C 03  
CAMSHAFT, TIMING BELT ..... 1.C 07  
CON RODS, PISTONS ..... 1.C 05  
CRANKSHAFT, FLYWHEEL ..... 1.C 04  
CYLINDER HEAD ..... 1.C 06  
ENGINE COVERS ..... 1.C 10  
OIL FILLERS, BREATHERS ..... 1.C 13  
OIL PUMP ..... 1.C 11  
STRIPPED ENGINE ..... 1.C 02  
SUMP ..... 1.C 12  
VALVE SHIMS ..... 1.C 09  
VALVES, ROCKER GEAR ..... 1.C 08  
WATER PUMP ..... 1.C 14

# SAMAND

C10

Fiche 1

## ENGINE 1800 cc PETROL FUEL INJECTED XU7 ENGINE COVERS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 126 | 17 | 001 |
| 2  | 126 | 17 | 002 |
| 3  | 126 | 17 | 013 |
| 4  | 181 | 02 | 066 |
| 5  | 040 | 02 | 050 |
| 6  | 040 | 02 | 062 |
| 70 | 040 | 01 | 052 |
| 71 | 040 | 22 | 009 |
| 72 | 040 | 01 | 113 |
| 73 | 186 | 02 | 001 |



Description

Quantity

Change Point

Remarks

|                                                  |   |  |  |
|--------------------------------------------------|---|--|--|
| Trim.-upper .....                                | 1 |  |  |
| Trim.-intermediate.....                          | 1 |  |  |
| Trim.-lower .....                                | 1 |  |  |
| Bracket.....                                     | 1 |  |  |
| Screw.-housing-M6 x 100-23.....                  | 2 |  |  |
| Screw.-housing-M6 x 100-16.....                  | 2 |  |  |
| Screw.-housing-cap head-M6 x 100-23.....         | 2 |  |  |
| Screw.-self tapping-shouldered-M8 x 125-20 ..... | 2 |  |  |
| Screw.-cap head-M6 x 100-20.....                 | 2 |  |  |
| Washer.-spring.-M6 X 18-1,5.....                 | 3 |  |  |



### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                        |         |
|----------------------------------------|---------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1. C 02 |
| BLOCK.....                             | 1. C 03 |
| CAMSHAFT, TIMING BELT .....            | 1. C 07 |
| CON RODS, PISTONS .....                | 1. C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1. C 04 |
| CYLINDER HEAD .....                    | 1. C 06 |
| ENGINE COVERS .....                    | 1. C 10 |
| OIL FILLERS, BREATHERS .....           | 1. C 13 |
| OIL PUMP .....                         | 1. C 11 |
| STRIPPED ENGINE .....                  | 1. C 02 |
| SUMP.....                              | 1. C 12 |
| VALVE SHIMS.....                       | 1. C 09 |
| VALVES, ROCKER GEAR .....              | 1. C 08 |
| WATER PUMP .....                       | 1. C 14 |



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 036 | 01 | 010 |
| 2  | 046 | 01 | 001 |
| 3  | 040 | 22 | 018 |
| 4  | 186 | 24 | 002 |
| 5  | 041 | 10 | 001 |
| 6  | 121 | 07 | 001 |
| 7  | 084 | 02 | 001 |
| 8  | 126 | 39 | 001 |
| 9  | 181 | 13 | 006 |
| 10 | 040 | 22 | 019 |
| 11 | 040 | 22 | 005 |
| 12 | 042 | 12 | 005 |
| 13 | 040 | 09 | 007 |
| 70 | 040 | 01 | 019 |
| 71 | 040 | 22 | 008 |



## Description

## Quantity

## Change Point

## Remarks

|                                       |   |  |  |
|---------------------------------------|---|--|--|
| Pump.-oil-assembly .....              | 1 |  |  |
| Oil Pump.-oil pump-housing .....      | 1 |  |  |
| Screw.-oil pump-M7 x 100-70 .....     | 1 |  |  |
| Washer.....                           | 1 |  |  |
| Piston.-Dia. 16x25 .....              | 1 |  |  |
| Spring.....                           | 1 |  |  |
| Chain.-oil pump.....                  | 1 |  |  |
| Trim.-oil pump .....                  | 1 |  |  |
| Bracket.-oil pump .....               | 1 |  |  |
| Screw.-self tapping-M7 x 85 .....     | 1 |  |  |
| Screw.-M7 x 100-75.....               | 1 |  |  |
| Dowel.-guide.....                     | 1 |  |  |
| Screw.-16x150.....                    | 1 |  |  |
| Screw.-self tapping-M6 x 100-25 ..... | 6 |  |  |
| Screw.-shouldered-M6 x 100-20 .....   | 2 |  |  |



ZB0020

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX



|                                        |        |
|----------------------------------------|--------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1.C 02 |
| BLOCK .....                            | 1.C 03 |
| CAMSHAFT, TIMING BELT .....            | 1.C 07 |
| CON RODS, PISTONS .....                | 1.C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1.C 04 |
| CYLINDER HEAD .....                    | 1.C 06 |
| ENGINE COVERS .....                    | 1.C 10 |
| OIL FILLERS, BREATHERS .....           | 1.C 13 |
| OIL PUMP .....                         | 1.C 11 |
| STRIPPED ENGINE .....                  | 1.C 02 |
| SUMP .....                             | 1.C 12 |
| VALVE SHIMS .....                      | 1.C 09 |
| VALVES, ROCKER GEAR .....              | 1.C 08 |
| WATER PUMP .....                       | 1.C 14 |

# SAMAND

C12

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
SUMP



ZB0023

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 124 | 02 | 008 |
| 3  | 092 | 03 | 007 |
| 4  | 186 | 03 | 067 |
| 5  | 186 | 03 | 026 |
| 7  | 124 | 02 | 001 |
| 8  | 158 | 03 | 007 |
| 9  | 166 | 01 | 006 |
| 10 | 163 | 12 | 001 |
| 13 | 040 | 11 | 001 |
| 15 | 092 | 03 | 010 |
| 16 | 140 | 02 | 010 |
| 19 | 040 | 09 | 005 |
| 21 | 166 | 10 | 003 |
| 22 | 186 | 03 | 028 |
| 23 | 040 | 09 | 012 |
| 24 | 042 | 07 | 008 |
| 26 | 040 | 01 | 142 |
| 70 | 040 | 24 | 001 |
| 73 | 040 | 02 | 087 |
| 74 | 186 | 02 | 045 |
| 75 | 186 | 02 | 022 |
| 76 | 186 | 01 | 174 |

Description

|                                       |    |
|---------------------------------------|----|
| Filter.....                           | 1  |
| Sensor.-oil pressure.....             | 1  |
| Washer.-asbestos free.....            | 1  |
| Washer.-cylinder block-14 X 21-2..... | 1  |
| Filter.-element.....                  | 1  |
| Fluid Gauge.-engine oil.....          | 1  |
| Pipe.-oil guide.....                  | 1  |
| Kit.-repair.....                      | 1  |
| Screw.-oil filter 20x1.50-27.....     | 1  |
| Sensor.....                           | 1  |
| Engine Sump.....                      | 1  |
| Screw.-cylinder block-14 x 125.....   | 1  |
| Pipe.....                             | 1  |
| Washer.-ring.....                     | 1  |
| Screw.-cylinder -block 10x1.00.....   | 1  |
| Dowel.-4.1 x 15.....                  | 1  |
| Screw.-socket head-M7 x 100-50.....   | 2  |
| Screw.-flanged head-M7 x 100-21.....  | 21 |
| Screw.-cap head-M8 x 125-16.....      | 1  |
| Washer.....                           | 5  |
| Washer.-flexible.-8 x 17.....         | 1  |
| Washer.-plain-8 x 16.....             | 1  |

Quantity

Change Point

Remarks

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                        |         |
|----------------------------------------|---------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1. C 02 |
| BLOCK.....                             | 1. C 03 |
| CAMSHAFT, TIMING BELT .....            | 1. C 07 |
| CON RODS, PISTONS.....                 | 1. C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1. C 04 |
| CYLINDER HEAD.....                     | 1. C 06 |
| ENGINE COVERS .....                    | 1. C 10 |
| OIL FILLERS, BREATHERS .....           | 1. C 13 |
| OIL PUMP.....                          | 1. C 11 |
| STRIPPED ENGINE .....                  | 1. C 02 |
| SUMP.....                              | 1. C 12 |
| VALVE SHIMS.....                       | 1. C 09 |
| VALVES, ROCKER GEAR .....              | 1. C 08 |
| WATER PUMP .....                       | 1. C 14 |

# SAMAND

C13

Fiche 1

ENGINE  
1800 cc PETROL FUEL INJECTED XU7  
OIL FILLERS, BREATHERS

Illus Part Number

|    |            |
|----|------------|
| 1  | 108 01 004 |
| 2  | 108 01 003 |
| 3  | 108 09 003 |
| 4  | 025 02 079 |
| 5  | 025 02 080 |
| 70 | 025 03 029 |
| 71 | 025 03 018 |



Description

Quantity

Change Point

Remarks

|                       |   |
|-----------------------|---|
| Hose.-oil vapour..... | 1 |
| Hose.-oil vapour..... | 1 |
| Hose.-oil vapour..... | 1 |
| Clip.....             | 1 |
| Clip.....             | 1 |
| Clip.-metal.....      | 3 |
| Clip.-metal.....      | 3 |



ZB0028




## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                        |         |
|----------------------------------------|---------|
| 1800 cc PETROL FUEL INJECTED XU7 ..... | 1. C 02 |
| BLOCK .....                            | 1. C 03 |
| CAMSHAFT, TIMING BELT .....            | 1. C 07 |
| CON RODS, PISTONS .....                | 1. C 05 |
| CRANKSHAFT, FLYWHEEL .....             | 1. C 04 |
| CYLINDER HEAD .....                    | 1. C 06 |
| ENGINE COVERS .....                    | 1. C 10 |
| OIL FILLERS, BREATHERS .....           | 1. C 13 |
| OIL PUMP .....                         | 1. C 11 |
| STRIPPED ENGINE .....                  | 1. C 02 |
| SUMP .....                             | 1. C 12 |
| VALVE SHIMS .....                      | 1. C 09 |
| VALVES, ROCKER GEAR .....              | 1. C 08 |
| WATER PUMP .....                       | 1. C 14 |



ZB0024

illus Part Number

1 036 06 005  
2 186 09 037  
3 093 11 001  
5 186 03 030  
8 061 04 002  
70 040 22 046  
71 040 22 045  
72 186 02 003  
73 025 08 007

Description

Pump.  
Washer.-water pump-asbestos free  
Union.-water intake-32mm diameter  
Washer.-tank-asbestos free  
Cap.-23mm diameter-30mm long  
Screw.-shouldered-shouldered-M7 x 100-25-M7 x 100-25  
Screw.-socket head-M7 x 100-25  
Washer.-flexible-7 x 13.7  
Clip.-metal-32mm diameter

Quantity

1  
1  
1  
1  
1  
5  
1  
1  
1

Change  
Point

Remarks

**MASTER INDEX**

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index



1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

**GROUP INDEX**

1800 cc PETROL FUEL INJECTED XU7 ..... 1.C 02  
BLOCK ..... 1.C 03  
CAMSHAFT, TIMING BELT ..... 1.C 07  
CON RODS, PISTONS ..... 1.C 05  
CRANKSHAFT, FLYWHEEL ..... 1.C 04  
CYLINDER HEAD ..... 1.C 06  
ENGINE COVERS ..... 1.C 10  
OIL FILLERS, BREATHERS ..... 1.C 13  
OIL PUMP ..... 1.C 11  
STRIPPED ENGINE ..... 1.C 02  
SUMP ..... 1.C 12  
VALVE SHIMS ..... 1.C 09  
VALVES, ROCKER GEAR ..... 1.C 08  
WATER PUMP ..... 1.C 14







## Illus Part Number

|    |            |
|----|------------|
| 1  | 067 04 009 |
| 1  | 067 04 015 |
| 2  | 109 01 012 |
| 2  | 109 01 016 |
| 3  | 027 01 012 |
| 4  | 015 07 004 |
| 5  | 042 09 002 |
| 6  | 030 18 009 |
| 7  | 030 18 008 |
| 8  | 067 03 002 |
| 70 | 042 07 018 |
| 71 | 040 22 009 |

## Description

|                                                         |
|---------------------------------------------------------|
| Clutch Plate Housing.-pressure plate housing- ..... 1   |
| 200mm-Valeo..... 1                                      |
| Clutch Plate Housing.-pressure plate housing- ..... 1   |
| 200mm-Luk..... 1                                        |
| Clutch Plate.-friction plate-200mm-asbestos free-.... 1 |
| Valeo..... 1                                            |
| Clutch Plate.-friction plate-200mm-asbestos free-.... 1 |
| Luk..... 1                                              |
| Bearing.-thrust-clutch-20.5mm-Valeo ..... 1             |
| Lever ..... 1                                           |
| Dowel.-7 X 51-fork-top..... 1                           |
| Bush.-fork-top ..... 1                                  |
| Bush.-fork-bottom ..... 1                               |
| Clutch Plate Housing.-service replacement-kit-..... 1   |
| asbestos free ..... 1                                   |
| Dowel.-6 X 17 ..... 1                                   |
| Screw.-shouldered-M8 x 125-20..... 6                    |

## Quantity

## Change Point

## Remarks

ZC0010

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                            |         |
|----------------------------|---------|
| CLUTCH 1800 PETROL .....   | 1. D 02 |
| CLUTCH .....               | 1. D 02 |
| CLUTCH CONTROL CABLE ..... | 1. D 03 |
| CLUTCH PEDAL.....          | 1. D 04 |

SAMAND

D03

Fiche 1

FLYWHEEL AND CLUTCH  
CLUTCH 1800 PETROL  
CLUTCH CONTROL CABLE

Illus Part Number

1 138 04 011  
3 181 32 010  
4 156 01 005


Description

Control Cable..... 1  
Bracket.-cable retained..... 1  
Protector.-clutch-cable..... 1

Quantity

Change Point

Remarks



ZC0018

# MASTER INDEX

ENGINE 1C  
FLYWHEEL AND CLUTCH 1D  
GEARBOX 1E  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1F  
STEERING 1G  
BRAKES AND BRAKE CONTROLS 1H  
FUEL, EXHAUST AND EMISSION SYSTEM 1I  
COOLING, HEATING AND AIR CONDITIONING 1J  
ELECTRICAL AND INSTRUMENTS 1K  
ENGINE MOUNTINGS, BODY SHELL AND WASH- 2C  
FACIA, TRIM, SEATS AND FIXINGS 2F  
ACCESSORIES AND PAINT 2H  
Numeric Index 2I

# GROUP INDEX

CLUTCH 1800 PETROL ..... 1. D 02  
CLUTCH ..... 1. D 02  
CLUTCH CONTROL CABLE ..... 1. D 03  
CLUTCH PEDAL..... 1. D 04


SAMAND

D04

Fiche 1

FLYWHEEL AND CLUTCH  
CLUTCH 1800 PETROL  
CLUTCH PEDAL

70



Illus Part Number

1 032 02 001  
2 025 09 001  
3 058 05 002  
4 121 08 002  
5 181 04 013  
6 160 04 006  
7 111 10 004  
70 040 05 023


Description

Pedal Assy.-clutch..... 1  
Clip.-linkage ..... 1  
Fixing Clip.-cable-stop ..... 1  
Spring.-pedal ..... 1  
Bracket.-pedal-brake..... 1  
Rubber Cover.-pedal..... 1  
Buffer.-clutch-pedal..... 1  
Screw.-pedal to brkt-4-20..... 4

Quantity

Change Point

Remarks



ZC0012

# MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index


1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

# GROUP INDEX

CLUTCH 1800 PETROL ..... 1.D 02  
CLUTCH ..... 1.D 02  
CLUTCH CONTROL CABLE ..... 1.D 03  
CLUTCH PEDAL ..... 1.D 04

| SAMAND                                           |                                         | E01<br>Fiche 1 | GEARBOX                                        |
|--------------------------------------------------|-----------------------------------------|----------------|------------------------------------------------|
| MASTER INDEX                                     | GROUP INDEX                             |                |                                                |
| ENGINE ..... 1 C                                 |                                         |                |                                                |
| FLYWHEEL AND CLUTCH ..... 1 D                    | MANUAL GEARBOX ..... 1. E 02            |                |                                                |
| GEARBOX ..... 1 E                                | FIRST LINE ..... 1. E 05                |                |                                                |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS.. 1 F    | GEARBOX ASSEMBLY ..... 1. E 02          |                |                                                |
| STEERING..... 1 G                                | GEARBOX REPAIR KIT..... 1. E 04         |                |                                                |
| BRAKES AND BRAKE CONTROLS..... 1 H               | GEARBOX-EXTERNAL FIXINGS ..... 1. E 03  |                |                                                |
| FUEL, EXHAUST AND EMISSION SYSTEM ..... 1 I      | MANUAL GEARBOX HOUSING ..... 1. E 03    |                |                                                |
| COOLING, HEATING AND AIR CONDITIONING..... 1 J   | SECOND LINE ..... 1. E 06               |                |                                                |
| ELECTRICAL AND INSTRUMENTS ..... 1 K             | SELECTOR FORKS ..... 1. E 07            |                |                                                |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-.. 2 C     | SPEEDOMETER DRIVE ..... 1. E 08         |                |                                                |
| FACIA, TRIM, SEATS AND FIXINGS..... 2 F          | SELECTOR MECHANISM ..... 1. E 09        |                |                                                |
| ACCESSORIES AND PAINT ..... 2 H                  | SELECTOR MECANISM-EXTERNAL..... 1. E 09 |                |                                                |
| Numeric Index ..... 2 I                          |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
|                                                  |                                         |                |                                                |
| <a href="http://www.me-en.com">www.me-en.com</a> |                                         |                | پایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک) |

| SAMAND |             |                                                  | E02      | GEARBOX<br>MANUAL GEARBOX<br>GEARBOX ASSEMBLY |         |  |
|--------|-------------|--------------------------------------------------|----------|-----------------------------------------------|---------|--|
|        |             |                                                  | Fiche 1  |                                               |         |  |
| Illus  | Part Number | Description                                      | Quantity | Change Point                                  | Remarks |  |
| 1      | 159 01 004  | Transmission.-new-reinforced.....                | 1        |                                               |         |  |
| 1      | 159 01 001  | Transmission.-Surcharge-worn-not reinforced..... | 1        |                                               |         |  |
| 2      | 077 03 001  | Fluid.-gearbox.-75W80W.....                      | 2LTR     |                                               |         |  |



ZC0019

| MASTER INDEX                                                         |    | GROUP INDEX                     |         |
|----------------------------------------------------------------------|----|---------------------------------|---------|
| ENGINE                                                               | 1C | MANUAL GEARBOX.....             | 1. E 02 |
| FLYWHEEL AND CLUTCH                                                  | 1D | FIRST LINE.....                 | 1. E 05 |
| GEARBOX                                                              | 1E | GEARBOX ASSEMBLY.....           | 1. E 02 |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS                              | 1F | GEARBOX REPAIR KIT.....         | 1. E 04 |
| STEERING                                                             | 1G | GEARBOX-EXTERNAL FIXINGS.....   | 1. E 03 |
| BRAKES AND BRAKE CONTROLS                                            | 1H | MANUAL GEARBOX HOUSING.....     | 1. E 03 |
| FUEL, EXHAUST AND EMISSION SYSTEM                                    | 1I | SECOND LINE.....                | 1. E 06 |
| COOLING, HEATING AND AIR CONDITIONING                                | 1J | SELECTOR FORKS.....             | 1. E 07 |
| ELECTRICAL AND INSTRUMENTS                                           | 1K | SPEEDOMETER DRIVE.....          | 1. E 08 |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-FACIA, TRIM, SEATS AND FIXINGS | 2C | SELECTOR MECHANISM.....         | 1. E 09 |
| ACCESSORIES AND PAINT                                                | 2F | SELECTOR MECANISM-EXTERNAL..... | 1. E 09 |
| Numeric Index                                                        | 2H |                                 |         |
|                                                                      | 2I |                                 |         |

[www.me-en.com](http://www.me-en.com)

پایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک)



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 174 | 06 | 005 |
| 2  | 040 | 20 | 009 |
| 71 | 040 | 02 | 041 |
| 72 | 040 | 01 | 079 |
| 73 | 040 | 22 | 049 |
| 74 | 040 | 22 | 055 |
| 76 | 040 | 22 | 054 |
| 77 | 040 | 01 | 028 |
| 78 | 042 | 02 | 007 |
| 79 | 040 | 02 | 088 |



## Description

|                                             |    |
|---------------------------------------------|----|
| Nut.-stop-17mm.....                         | 1  |
| Screw-column-M7 x 100-40-20.....            | 2  |
| Screw.....                                  | 1  |
| Screw-shouldered-M7 x 100-22.....           | 7  |
| Screw-M7 x 100-35.....                      | 17 |
| Screw-diff case to gearbox-M8 x 125-30..... | 2  |
| Screw-socket head-M8 X 125-55.....          | 1  |
| Screw-socket head-M10 x 150-75.....         | 3  |
| Dowel.-12 x 15.....                         | 2  |
| Screw-M7 x 100-45.....                      | 1  |

## Quantity

## Change Point

## Remarks



ZC0012

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                  |         |
|----------------------------------|---------|
| MANUAL GEARBOX.....              | 1. E 02 |
| FIRST LINE.....                  | 1. E 05 |
| GEARBOX ASSEMBLY.....            | 1. E 02 |
| GEARBOX REPAIR KIT.....          | 1. E 04 |
| GEARBOX-EXTERNAL FIXINGS.....    | 1. E 03 |
| MANUAL GEARBOX HOUSING.....      | 1. E 03 |
| SECOND LINE.....                 | 1. E 06 |
| SELECTOR FORKS.....              | 1. E 07 |
| SPEEDOMETER DRIVE.....           | 1. E 08 |
| SELECTOR MECHANISM.....          | 1. E 09 |
| SELECTOR MECHANISM-EXTERNAL..... | 1. E 09 |

SAMAND

E04

Fiche 1

GEARBOX  
MANUAL GEARBOX  
GEARBOX REPAIR KIT

Illus Part Number  
1 163 06 004


Description

Kit.-repair ..... 1

Quantity

Change Point

Remarks



ZC0014

MASTER INDEX

GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index



1C MANUAL GEARBOX.....1. E 02  
1D FIRST LINE.....1. E 05  
1E GEARBOX ASSEMBLY.....1. E 02  
1F GEARBOX REPAIR KIT.....1. E 04  
1G GEARBOX-EXTERNAL FIXINGS.....1. E 03  
1H MANUAL GEARBOX HOUSING.....1. E 03  
1I SECOND LINE.....1. E 06  
1J SELECTOR FORKS.....1. E 07  
1K SPEEDOMETER DRIVE.....1. E 08  
2C SELECTOR MECHANISM.....1. E 09  
2F SELECTOR MECHANISM-EXTERNAL.....1. E 09  
2H  
2I

# SAMAND

E05

Fiche 1

## GEARBOX MANUAL GEARBOX FIRST LINE



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 102 | 01 | 031 |
| 2  | 027 | 06 | 025 |
| 3  | 186 | 10 | 259 |
| 4  | 065 | 01 | 085 |
| 5  | 065 | 01 | 045 |
| 6  | 065 | 01 | 015 |
| 7  | 186 | 24 | 014 |
| 8  | 065 | 01 | 005 |
| 9  | 065 | 01 | 048 |
| 10 | 174 | 03 | 005 |
| 11 | 065 | 03 | 012 |
| 12 | 102 | 01 | 036 |
| 71 | 042 | 02 | 005 |
| 13 | 186 | 01 | 090 |
| 70 | 040 | 01 | 177 |

### Description

|                                                  |   |
|--------------------------------------------------|---|
| Shaft.-primary-11/12/23-21 teeth.....            | 1 |
| Bearing.-25 x 47-15.....                         | 2 |
| Washer.-adjustment set-39 x 46-EP 0,7 A 2,4..... | 1 |
| Gear.-drive-3rd-25 teeth-25 x 32.....            | 1 |
| Gear.-3rd/4th-27 x 31.....                       | 1 |
| Gear.-drive-32 teeth-32 x 31.....                | 1 |
| Washer.-25 x 39.5.....                           | 1 |
| Gear.-drive-5th-37 teeth-37 x 28.....            | 1 |
| Gear.-5th-22 X 24.....                           | 1 |
| Nut.-shaft-20 x 150-11.....                      | 1 |
| Gear.-sliding-31 teeth-29'.....                  | 1 |
| Shaft.-return-18mm diameter.....                 | 1 |
| Dowel.-5mm x 25mm.....                           | 1 |
| Washer.-shaft-8 x 15-2.....                      | 1 |
| Screw.-M8 x 125-50.....                          | 1 |

### Quantity

### Change Point

### Remarks

ZC0006

PENTEC INTERNATIONAL LTD

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

MANUAL GEARBOX..... 1. E 02  
FIRST LINE..... 1. E 05  
GEARBOX ASSEMBLY..... 1. E 02  
GEARBOX REPAIR KIT..... 1. E 04  
GEARBOX-EXTERNAL FIXINGS..... 1. E 03  
MANUAL GEARBOX HOUSING..... 1. E 03  
SECOND LINE..... 1. E 06  
SELECTOR FORKS..... 1. E 07  
SPEEDOMETER DRIVE..... 1. E 08  
SELECTOR MECHANISM..... 1. E 09  
SELECTOR MECANISM-EXTERNAL..... 1. E 09

# SAMAND

E06

Fiche 1

## GEARBOX MANUAL GEARBOX SECOND LINE

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 143 | 01 | 001 |
|    | 102 | 01 | 069 |
| 1  | 102 | 01 | 070 |
| 2  | 027 | 06 | 008 |
| 3  | 027 | 06 | 010 |
| 4  | 058 | 01 | 054 |
| 5  | 065 | 01 | 066 |
| 6  | 065 | 01 | 042 |
| 7  | 065 | 01 | 061 |
| 8  | 065 | 01 | 037 |
| 9  | 027 | 06 | 050 |
| 10 | 058 | 01 | 053 |
| 11 | 065 | 01 | 006 |
| 12 | 174 | 03 | 005 |
| 70 | 040 | 01 | 079 |
| 71 | 186 | 01 | 175 |


Description

|                                                 |   |
|-------------------------------------------------|---|
| Crown Wheel & Pinion.-assembly .....            | 1 |
| Shaft.-hypoid set-75 teeth-reinforced.....      | 1 |
| Shaft.-19 teeth-19 x 72-reinforced.....         | 1 |
| Bearing.-needle .....                           | 1 |
| Bearing.-shaft-36 x 72-17.5 .....               | 1 |
| Fixing Clip.-stop .....                         | 1 |
| Gear.-driven gear-38 teeth-11 x 38.....         | 1 |
| Gear.-1st/2nd-24 teeth-28 x 24.....             | 1 |
| Gear.-driven gear-2 nd-37 teeth-20 x 37 .....   | 1 |
| Gear.-driven gear-3rd/4th-25 x 32-32 x 31 ..... | 1 |
| Bearing.-shaft-25 x 75 x 16.95 .....            | 1 |
| Fixing Clip.-stop .....                         | 1 |
| Gear.-driven gear-5th-28 teeth-37 x 28 .....    | 1 |
| Nut.-shaft-20 x 150-11.....                     | 1 |
| Screw.-shouldered-M7 x 100-22.....              | 1 |
| Washer.-plain-7 x 22.....                       | 1 |

Quantity

Change Point

Remarks



### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                  |        |
|----------------------------------|--------|
| MANUAL GEARBOX.....              | 1.E 02 |
| FIRST LINE.....                  | 1.E 05 |
| GEARBOX ASSEMBLY.....            | 1.E 02 |
| GEARBOX REPAIR KIT.....          | 1.E 04 |
| GEARBOX-EXTERNAL FIXINGS.....    | 1.E 03 |
| MANUAL GEARBOX HOUSING.....      | 1.E 03 |
| SECOND LINE.....                 | 1.E 06 |
| SELECTOR FORKS.....              | 1.E 07 |
| SPEEDOMETER DRIVE.....           | 1.E 08 |
| SELECTOR MECHANISM.....          | 1.E 09 |
| SELECTOR MECHANISM-EXTERNAL..... | 1.E 09 |

# SAMAND

E07

Fiche 1

## GEARBOX MANUAL GEARBOX SELECTOR FORKS

Illus Part Number


Description

Quantity

Change Point

Remarks

|    |            |                                     |   |  |  |
|----|------------|-------------------------------------|---|--|--|
| 1  | 168 01 005 | G/Box Selectors.-gearbox assy-1 + 2 | 1 |  |  |
| 2  | 168 02 005 | G/Box Selectors.-gearbox assy-3 + 4 | 1 |  |  |
| 3  | 102 01 051 | Shaft.-shaft-1-2-3-4                | 1 |  |  |
| 4  | 058 05 003 | Fixing Clip.-stop plate             | 1 |  |  |
| 5  | 087 03 005 | Ball.-locking-8mm diameter          | 3 |  |  |
| 6  | 121 03 010 | Spring                              | 3 |  |  |
| 7  | 102 01 058 | Shaft.-+ fork-5th                   | 1 |  |  |
| 8  | 168 06 003 | G/Box Selectors.-member reverse     | 1 |  |  |
| 9  | 102 01 026 | Shaft.-reverse-12mm diameter        | 1 |  |  |
| 10 | 087 03 006 | Ball.-locking                       | 1 |  |  |
| 11 | 121 03 011 | Spring.-locking                     | 1 |  |  |
| 12 | 178 01 019 | Link.-+ finger                      | 1 |  |  |
| 13 | 168 03 004 | G/Box Selectors.-selection          | 1 |  |  |
| 14 | 186 03 049 | Washer.-seal-15 x 21-3              | 1 |  |  |
| 15 | 017 05 036 | Seal.-lever                         | 1 |  |  |
| 16 | 181 07 021 | Bracket.-bracket                    | 1 |  |  |
| 17 | 186 03 047 | Washer.-seal-16 x 30-7-11           | 1 |  |  |
| 70 | 042 07 013 | Dowel.-3.3 x 15                     | 2 |  |  |
| 71 | 040 01 079 | Screw.-shouldered-M7 x 100-22       | 1 |  |  |
| 72 | 174 04 042 | Nut.-M12 x 150-12-26                | 1 |  |  |
| 73 | 042 07 027 | Dowel.-3 x 15                       | 1 |  |  |
| 74 | 042 02 014 | Dowel.-4.5 x 22                     | 1 |  |  |
| 75 | 058 01 015 | Fixing Clip.-stop ring-17.5mm       | 1 |  |  |
| 76 | 040 24 003 | Screw.-M7 x 100-22                  | 1 |  |  |
| 77 | 186 01 108 | Washer.-shaft-16 x 28-1             | 1 |  |  |
| 78 | 042 07 012 | Dowel.-4.5 x 25                     | 1 |  |  |
| 79 | 042 07 028 | Dowel.-4.5 x 30                     | 1 |  |  |
| 80 | 042 07 011 | Dowel.-7 x 25                       | 1 |  |  |
| 81 | 042 03 009 | Dowel.-7 x 30                       | 1 |  |  |



ZC0008

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                             |        |
|-----------------------------|--------|
| MANUAL GEARBOX              | 1.E 02 |
| FIRST LINE                  | 1.E 05 |
| GEARBOX ASSEMBLY            | 1.E 02 |
| GEARBOX REPAIR KIT          | 1.E 04 |
| GEARBOX-EXTERNAL FIXINGS    | 1.E 03 |
| MANUAL GEARBOX HOUSING      | 1.E 03 |
| SECOND LINE                 | 1.E 06 |
| SELECTOR FORKS              | 1.E 07 |
| SPEEDOMETER DRIVE           | 1.E 08 |
| SELECTOR MECHANISM          | 1.E 09 |
| SELECTOR MECHANISM-EXTERNAL | 1.E 09 |

# SAMAND

E08

Fiche 1

## GEARBOX MANUAL GEARBOX SPEEDOMETER DRIVE

Illus Part Number

1 065 04 021  
2 065 04 008  
3 092 07 004  
4 186 03 050  
5 186 03 051  
6 042 11 001  
7 114 01 020  
70 040 01 036

Description


Gear.-tachometer-worm drive-22 teeth..... 1  
Gear.-pinion-19 teeth..... 1  
Sensor.-tachometer- 3 way..... 1  
Washer.-tachometer-8 x 16 ..... 1  
Washer.-ring ..... 1  
Dowel.-stop..... 1  
Shield.-tachometer..... 1  
Screw.-cap head-M7 x 100-16..... 1

Quantity

Change Point

Remarks

70



ZC0017

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

MANUAL GEARBOX..... 1. E 02  
FIRST LINE..... 1. E 05  
GEARBOX ASSEMBLY..... 1. E 02  
GEARBOX REPAIR KIT..... 1. E 04  
GEARBOX-EXTERNAL FIXINGS..... 1. E 03  
MANUAL GEARBOX HOUSING..... 1. E 03  
SECOND LINE..... 1. E 06  
SELECTOR FORKS ..... 1. E 07  
SPEEDOMETER DRIVE ..... 1. E 08  
SELECTOR MECHANISM..... 1. E 09  
SELECTOR MECANISM-EXTERNAL ..... 1. E 09





# SAMAND

E09

Fiche 1

## GEARBOX SELECTOR MECHANISM SELECTOR MECANISM-EXTERNAL



ZC0016

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 178 | 01 | 018 |
| 2  | 178 | 01 | 017 |
| 3  | 222 | 01 | 015 |
| 5  | 181 | 07 | 010 |
| 6  | 168 | 04 | 005 |
| 7  | 178 | 01 | 012 |
| 8  | 168 | 03 | 002 |
| 9  | 015 | 02 | 008 |
| 10 | 181 | 07 | 012 |
| 11 | 156 | 03 | 012 |
| 12 | 114 | 01 | 011 |
| 13 | 030 | 22 | 043 |
| 14 | 038 | 01 | 008 |
| 15 | 040 | 01 | 158 |
| 16 | 030 | 22 | 013 |
| 17 | 030 | 24 | 007 |
| 18 | 030 | 22 | 014 |
| 19 | 030 | 18 | 005 |
| 70 | 040 | 22 | 048 |
| 71 | 186 | 01 | 170 |
| 72 | 174 | 07 | 017 |

Description

|                                              |   |
|----------------------------------------------|---|
| Link.-lever-gearchange .....                 | 1 |
| Link.-gearchange .....                       | 1 |
| Gear Lever Knob.-gear lever.....             | 1 |
| Bracket.-gearchange .....                    | 1 |
| G/Box Selectors.-gearchange-short .....      | 2 |
| Link.-gearchange-long .....                  | 1 |
| G/Box Selectors.-return-gearchange-top ..... | 1 |
| Lever.-return-gearchange-lower.....          | 1 |
| Bracket.-control.....                        | 1 |
| Protector.-gearchange-linkage .....          | 1 |
| Shield.....                                  | 1 |
| Bush.-retaining-gearchange .....             | 1 |
| Block & pipe-bracket-gearchange.....         | 1 |
| Screw.-return-gearchange .....               | 1 |
| Bush.-return-gearchange.....                 | 1 |
| Bush.-bracket-gearchange-control.....        | 4 |
| Bush.-bracket-control.....                   | 1 |
| Bush.-gear lever.....                        | 2 |
| Screw.-M8 x 125 - 40.....                    | 1 |
| Washer.-plain-M10 x 20-2.....                | 2 |
| Nut.-self locking-M6 x 100-8.....            | 1 |

Quantity

Change Point

Remarks

### MASTER INDEX



ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                  |         |
|----------------------------------|---------|
| MANUAL GEARBOX.....              | 1. E 02 |
| FIRST LINE .....                 | 1. E 05 |
| GEARBOX ASSEMBLY.....            | 1. E 02 |
| GEARBOX REPAIR KIT .....         | 1. E 04 |
| GEARBOX-EXTERNAL FIXINGS .....   | 1. E 03 |
| MANUAL GEARBOX HOUSING .....     | 1. E 03 |
| SECOND LINE .....                | 1. E 06 |
| SELECTOR FORKS .....             | 1. E 07 |
| SPEEDOMETER DRIVE .....          | 1. E 08 |
| SELECTOR MECHANISM .....         | 1. E 09 |
| SELECTOR MECANISM-EXTERNAL ..... | 1. E 09 |





## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 121 | 01 | 012 |
| 2  | 156 | 08 | 003 |
| 3  | 111 | 04 | 001 |
| 4  | 027 | 15 | 002 |
| 5  | 111 | 04 | 002 |
| 6  | 045 | 03 | 004 |
| 7  | 061 | 09 | 009 |
| 8  | 061 | 09 | 005 |
| 9  | 061 | 09 | 001 |
| 10 | 163 | 11 | 008 |
| 70 | 186 | 01 | 115 |
| 71 | 186 | 01 | 100 |
| 72 | 174 | 07 | 004 |
| 73 | 174 | 04 | 008 |


## Description

|                                |   |
|--------------------------------|---|
| Spring                         | 2 |
| Protector                      | 2 |
| Buffer.-79 mm                  | 2 |
| Bearing.-thrust                | 2 |
| Buffer                         | 2 |
| Hub                            | 2 |
| Protectors.-upper-front spring | 2 |
| Protectors.-lower-front spring | 2 |
| Protectors                     | 2 |
| Kit.-fixing kit                | 2 |
| Washer.-14 x 38                | 2 |
| Washer.-plain                  | 2 |
| Nut.-self locking-M14          | 2 |
| Nut.-8 X 125                   | 4 |

## Quantity

## Change Point

## Remarks



ZE0016

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                               |         |
|-------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL | 1. F 06 |
| DRIVE SHAFTS                  | 1. F 07 |
| FRONT DIFFERENTIAL            | 1. F 06 |
| FRONT SUSPENSION              | 1. F 02 |
| FRONT ANTI ROLL BAR           | 1. F 04 |
| FRONT SHOCK ABSORBERS         | 1. F 05 |
| FRONT SPRING                  | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB  | 1. F 03 |
| REAR SUSPENSION               | 1. F 08 |
| REAR SHOCK ABSORBERS          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER   | 1. F 08 |
| ROAD WHEELS                   | 1. F 11 |
| ROAD WHEELS                   | 1. F 11 |

# SAMAND

F03

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

FRONT SUSPENSION

FRONT SUSPENSION ARM AND HUB

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 020 | 04 | 011 |
| 1  | 020 | 04 | 006 |
| 2  | 020 | 04 | 024 |
| 2  | 020 | 04 | 025 |
| 3  | 045 | 01 | 002 |
| 4  | 027 | 02 | 002 |
| 5  | 058 | 01 | 027 |
| 6  | 030 | 14 | 004 |
| 7  | 030 | 14 | 005 |
| 8  | 098 | 04 | 005 |
| 9  | 237 | 03 | 010 |
| 10 | 040 | 01 | 129 |
| 11 | 040 | 01 | 271 |
| 12 | 040 | 01 | 095 |
| 13 | 174 | 07 | 005 |
| 14 | 163 | 25 | 001 |
| 70 | 186 | 01 | 120 |
| 71 | 186 | 01 | 096 |
| 72 | 174 | 04 | 009 |
| 73 | 174 | 07 | 031 |


Description

Quantity

Change Point

Remarks

|                                  |   |  |  |
|----------------------------------|---|--|--|
| Arm.-front swivel-LH .....       | 1 |  |  |
| Arm.-front swivel-RH .....       | 1 |  |  |
| Arm.-front-LH .....              | 1 |  |  |
| Arm.-front-RH .....              | 1 |  |  |
| Wheel Hub.-disc .....            | 1 |  |  |
| Bearing.-bearing .....           | 2 |  |  |
| Fixing Clip.-hub bearing .....   | 2 |  |  |
| Bush.-front .....                | 2 |  |  |
| Bush.-rear .....                 | 1 |  |  |
| Suspension Link.-pin ball .....  | 2 |  |  |
| Protecting Plate .....           | 2 |  |  |
| Screw.-M10 x 1.50 .....          | 2 |  |  |
| Screw.-M12 x 175-58 .....        | 2 |  |  |
| Screw.-M12 x 175-58 .....        | 2 |  |  |
| Nut.-10 x 150-self locking ..... | 2 |  |  |
| Kit.-kit .....                   | 1 |  |  |
| Washer.-13 x 24 .....            | 4 |  |  |
| Washer.-12 x 24 .....            | 4 |  |  |
| Nut.-self locking-12 X 175 ..... | 4 |  |  |
| Nut.-14 x 150-self locking ..... | 2 |  |  |



ZE0012

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                     |         |
|----|-------------------------------------|---------|
| 1C | DRIVE SHAFTS AND DIFFERENTIAL ..... | 1. F 06 |
| 1D | DRIVE SHAFTS .....                  | 1. F 07 |
| 1E | FRONT DIFFERENTIAL .....            | 1. F 06 |
| 1F | FRONT SUSPENSION .....              | 1. F 02 |
| 1G | FRONT ANTI ROLL BAR .....           | 1. F 04 |
| 1H | FRONT SHOCK ABSORBERS .....         | 1. F 05 |
| 1I | FRONT SPRING .....                  | 1. F 02 |
| 1J | FRONT SUSPENSION ARM AND HUB .....  | 1. F 03 |
| 1K | REAR SUSPENSION .....               | 1. F 08 |
| 2C | REAR SHOCK ABSORBERS .....          | 1. F 10 |
| 2F | REAR SUSPENSION ARM AND HUBS .....  | 1. F 09 |
| 2H | REAR SUSPENSION CROSSMEMBER .....   | 1. F 08 |
| 2I | ROAD WHEELS .....                   | 1. F 11 |
|    | ROAD WHEELS .....                   | 1. F 11 |

# SAMAND


F04

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

FRONT SUSPENSION

FRONT ANTI ROLL BAR



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 197 | 01 | 010 |
| 2  | 181 | 06 | 012 |
| 3  | 181 | 06 | 011 |
| 4  | 025 | 24 | 002 |
| 5  | 030 | 22 | 016 |
| 6  | 197 | 01 | 011 |
| 6  | 197 | 01 | 012 |
| 7  | 030 | 22 | 040 |
| 8  | 040 | 01 | 145 |
| 70 | 040 | 22 | 048 |
| 71 | 040 | 22 | 053 |
| 72 | 040 | 22 | 043 |
| 73 | 040 | 22 | 062 |
| 74 | 186 | 02 | 022 |
| 75 | 174 | 03 | 074 |
| 77 | 040 | 02 | 017 |

Description

|                                    |   |
|------------------------------------|---|
| Anti Roll Bar.-diameter 22.....    | 1 |
| Bracket.-diameter 22 .....         | 1 |
| Bracket.-clamp-diameter 22.....    | 2 |
| Clip.-clamp .....                  | 2 |
| Bush.....                          | 4 |
| Anti Roll Bar.-LH .....            | 1 |
| Anti Roll Bar.-RH .....            | 1 |
| Bush.-8 x 16.....                  | 2 |
| Screw.-link .....                  | 2 |
| Screw.-M8 x 125 - 40 .....         | 2 |
| Screw.-M8 X 125-65 .....           | 2 |
| Screw.-M8 X 125-100 .....          | 2 |
| Screw.-cap head-M12 X 175-45 ..... | 2 |
| Washer.-flexible.-8 x 17 .....     | 2 |
| Nut.-8 X 125.....                  | 2 |
| Screw.-flange-M8.....              | 4 |

Quantity

Change Point

Remarks

ZE0013

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL..... | 1. F 06 |
| DRIVE SHAFTS.....                  | 1. F 07 |
| FRONT DIFFERENTIAL .....           | 1. F 06 |
| FRONT SUSPENSION .....             | 1. F 02 |
| FRONT ANTI ROLL BAR.....           | 1. F 04 |
| FRONT SHOCK ABSORBERS .....        | 1. F 05 |
| FRONT SPRING .....                 | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB ..... | 1. F 03 |
| REAR SUSPENSION .....              | 1. F 08 |
| REAR SHOCK ABSORBERS.....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS.....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER.....   | 1. F 08 |
| ROAD WHEELS.....                   | 1. F 11 |
| ROAD WHEELS.....                   | 1. F 11 |

# SAMAND

F05

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

FRONT SUSPENSION

FRONT SHOCK ABSORBERS

Illus Part Number

1 150 01 007  
2 156 08 003  
70 186 01 100  
71 174 07 004



Description

Absorber.....2  
Protector.....2  
Washer.-plain.....2  
Nut.-self locking-M14.....2

Quantity

Change Point

Remarks



ZE0011

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

DRIVE SHAFTS AND DIFFERENTIAL.....1. F 06  
DRIVE SHAFTS.....1. F 07  
FRONT DIFFERENTIAL.....1. F 06  
FRONT SUSPENSION.....1. F 02  
FRONT ANTI ROLL BAR.....1. F 04  
FRONT SHOCK ABSORBERS.....1. F 05  
FRONT SPRING.....1. F 02  
FRONT SUSPENSION ARM AND HUB.....1. F 03  
REAR SUSPENSION.....1. F 08  
REAR SHOCK ABSORBERS.....1. F 10  
REAR SUSPENSION ARM AND HUBS.....1. F 09  
REAR SUSPENSION CROSSMEMBER.....1. F 08  
ROAD WHEELS.....1. F 11  
ROAD WHEELS.....1. F 11



# SAMAND

F06

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

DRIVE SHAFTS AND DIFFERENTIAL

FRONT DIFFERENTIAL

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 143 | 01 | 001 |
|    | 102 | 01 | 069 |
| 2  | 065 | 13 | 006 |
| 3  | 102 | 05 | 002 |
| 4  | 186 | 05 | 018 |
| 5  | 030 | 31 | 001 |
| 6  | 186 | 05 | 019 |
| 7  | 185 | 01 | 002 |
| 8  | 027 | 08 | 001 |
| 9  | 040 | 01 | 118 |
| 10 | 017 | 13 | 003 |
| 11 | 017 | 13 | 005 |
| 12 | 186 | 10 | 260 |
| 70 | 042 | 03 | 012 |


Description

Quantity

Change Point

Remarks

|                                            |   |  |  |
|--------------------------------------------|---|--|--|
| Crown Wheel & Pinion.-assembly .....       | 1 |  |  |
| Shaft.-hypoid set-75 teeth-reinforced..... | 1 |  |  |
| Gear.-set-16/10 teeth-77mm diameter.....   | 1 |  |  |
| Shaft.-gears-15.99 x 93.5 .....            | 1 |  |  |
| Washer.-planet-16.15 x 36-0.45 .....       | 2 |  |  |
| Bush.-centring .....                       | 1 |  |  |
| Washer.-friction.....                      | 2 |  |  |
| Differential.-housing-77mm diameter.....   | 1 |  |  |
| Bearing.-differential.....                 | 2 |  |  |
| Screw.-cap head-M10 x 100-21.5 .....       | 8 |  |  |
| Seal.-LH-40 x 58 - 11.3.....               | 1 |  |  |
| Seal.-RH-29.8 x 47 - 11.3 .....            | 1 |  |  |
| Washer.-set-55 x 62.....                   | 1 |  |  |
| Dowel.-3.5 x 25.....                       | 2 |  |  |



ZE0014

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL..... | 1. F 06 |
| DRIVE SHAFTS .....                 | 1. F 07 |
| FRONT DIFFERENTIAL .....           | 1. F 06 |
| FRONT SUSPENSION .....             | 1. F 02 |
| FRONT ANTI ROLL BAR .....          | 1. F 04 |
| FRONT SHOCK ABSORBERS .....        | 1. F 05 |
| FRONT SPRING .....                 | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB ..... | 1. F 03 |
| REAR SUSPENSION .....              | 1. F 08 |
| REAR SHOCK ABSORBERS.....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS.....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER.....   | 1. F 08 |
| ROAD WHEELS.....                   | 1. F 11 |
| ROAD WHEELS.....                   | 1. F 11 |

# SAMAND

F07

Fiche 1

## AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS DRIVE SHAFTS AND DIFFERENTIAL DRIVE SHAFTS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 035 | 01 | 003 |
| 2  | 035 | 01 | 004 |
| 4  | 156 | 02 | 004 |
| 5  | 156 | 02 | 006 |
| 6  | 027 | 09 | 001 |
| 7  | 030 | 19 | 001 |
| 8  | 040 | 21 | 001 |
| 9  | 058 | 03 | 004 |
| 10 | 017 | 22 | 001 |
| 12 | 174 | 03 | 006 |
| 13 | 174 | 03 | 007 |
| 14 | 239 | 02 | 001 |
| 15 | 042 | 08 | 003 |


Description

|                                       |   |
|---------------------------------------|---|
| Drive Shaft.-LH.....                  | 1 |
| Drive Shaft.-RH.....                  | 1 |
| Protector.-assembly-fixing kit.....   | 2 |
| Protector.-assembly-fixing kit.....   | 2 |
| Bearing.....                          | 1 |
| Bush.....                             | 1 |
| Screw.-M7 x 100-44.....               | 2 |
| Fixing Clip.-drive shaft-bearing..... | 2 |
| Seal.-RH.....                         | 1 |
| Nut.-bearing-M7-7 X 100.....          | 2 |
| Nut.-24 x 150-hub fixing.....         | 2 |
| Socket.-locking.....                  | 2 |
| Dowel.....                            | 2 |

Quantity

Change Point

Remarks



ZE0016

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL..... | 1. F 06 |
| DRIVE SHAFTS.....                  | 1. F 07 |
| FRONT DIFFERENTIAL.....            | 1. F 06 |
| FRONT SUSPENSION.....              | 1. F 02 |
| FRONT ANTI ROLL BAR.....           | 1. F 04 |
| FRONT SHOCK ABSORBERS.....         | 1. F 05 |
| FRONT SPRING.....                  | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB.....  | 1. F 03 |
| REAR SUSPENSION.....               | 1. F 08 |
| REAR SHOCK ABSORBERS.....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS.....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER.....   | 1. F 08 |
| ROAD WHEELS.....                   | 1. F 11 |
| ROAD WHEELS.....                   | 1. F 11 |

# SAMAND

F08

Fiche 1

## AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS REAR SUSPENSION REAR SUSPENSION CROSSMEMBER TORSION BAR

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 233 | 01 | 003 |
| 2  | 176 | 02 | 009 |
| 2  | 176 | 02 | 010 |
| 3  | 197 | 02 | 003 |
| 4  | 181 | 06 | 009 |
| 5  | 030 | 09 | 004 |
| 6  | 111 | 01 | 001 |
| 7  | 040 | 20 | 002 |
| 8  | 040 | 02 | 037 |
| 9  | 186 | 01 | 093 |
| 10 | 186 | 02 | 018 |
| 11 | 030 | 09 | 005 |
| 12 | 040 | 01 | 126 |
| 13 | 040 | 02 | 038 |
| 14 | 186 | 01 | 094 |
| 70 | 040 | 01 | 030 |
| 71 | 174 | 04 | 009 |

Description



|                                               |   |
|-----------------------------------------------|---|
| Crossmember.-suspension.....                  | 1 |
| Torsion Bar.-diameter 20-LH.....              | 1 |
| Torsion Bar.-diameter 20-RH.....              | 1 |
| Anti Roll Bar.-Anti-roll Bar-diameter 17..... | 2 |
| Bracket.-crossmemeber.....                    | 2 |
| Bush.-front.....                              | 2 |
| Buffer.....                                   | 2 |
| Screw.-column.....                            | 2 |
| Screw.-M10 x 150-43.....                      | 6 |
| Washer.....                                   | 2 |
| Washer.-spring.....                           | 2 |
| Bush.-centering tool.....                     | 2 |
| Screw.-M10 x 1,50-60.....                     | 2 |
| Screw.-M8 x 125-20.....                       | 4 |
| Washer.....                                   | 4 |
| Screw.-shouldered-M8 x 125-25.....            | 4 |
| Nut.-self locking-12 X 175.....               | 2 |

Quantity

Change Point

Remarks

|       |                       |
|-------|-----------------------|
| ..... | Heavy duty suspension |
| ..... | Heavy duty suspension |
| ..... | Heavy duty suspension |



ZE0001

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL..... | 1. F 06 |
| DRIVE SHAFTS.....                  | 1. F 07 |
| FRONT DIFFERENTIAL.....            | 1. F 06 |
| FRONT SUSPENSION.....              | 1. F 02 |
| FRONT ANTI ROLL BAR.....           | 1. F 04 |
| FRONT SHOCK ABSORBERS.....         | 1. F 05 |
| FRONT SPRING.....                  | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB.....  | 1. F 03 |
| REAR SUSPENSION.....               | 1. F 08 |
| REAR SHOCK ABSORBERS.....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS.....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER.....   | 1. F 08 |
| ROAD WHEELS.....                   | 1. F 11 |
| ROAD WHEELS.....                   | 1. F 11 |

# SAMAND

F09

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

REAR SUSPENSION

REAR SUSPENSION ARM AND HUBS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 020 | 06 | 005 |
| 1  | 020 | 06 | 007 |
| 2  | 027 | 05 | 004 |
| 3  | 027 | 05 | 005 |
| 4  | 111 | 01 | 006 |
| 5  | 061 | 01 | 001 |
| 6  | 045 | 02 | 002 |
| 6  | 045 | 01 | 009 |
| 7  | 061 | 02 | 005 |
| 8  | 186 | 10 | 276 |
| 9  | 174 | 03 | 008 |
| 10 | 061 | 02 | 002 |
| 11 | 163 | 10 | 001 |
| 12 | 030 | 14 | 008 |


Description

Quantity

Change Point

Remarks

|                                           |   |  |  |
|-------------------------------------------|---|--|--|
| Arm.-suspension-LH.....                   | 1 |  |  |
| Arm.-suspension-RH.....                   | 1 |  |  |
| Bearing.-exterior.....                    | 2 |  |  |
| Bearing.-interior.....                    | 2 |  |  |
| Buffer.-rebound.....                      | 1 |  |  |
| Protectors.-diameter 8.2 x 54 x 13.2..... | 2 |  |  |
| Wheel Hub.-Without ABS.....               | 2 |  |  |
| Wheel Hub.-ABS Additional-disc.....       | 2 |  |  |
| Protectors.-cup.....                      | 2 |  |  |
| Washer.....                               | 2 |  |  |
| Nut.-hub fixing-30 x 1.50.....            | 2 |  |  |
| Cap.-hub.....                             | 2 |  |  |
| Kit.-hub.....                             | 2 |  |  |
| Bush.....                                 | 2 |  |  |



## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL..... | 1. F 06 |
| DRIVE SHAFTS.....                  | 1. F 07 |
| FRONT DIFFERENTIAL.....            | 1. F 06 |
| FRONT SUSPENSION.....              | 1. F 02 |
| FRONT ANTI ROLL BAR.....           | 1. F 04 |
| FRONT SHOCK ABSORBERS.....         | 1. F 05 |
| FRONT SPRING.....                  | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB.....  | 1. F 03 |
| REAR SUSPENSION.....               | 1. F 08 |
| REAR SHOCK ABSORBERS.....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS.....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER.....   | 1. F 08 |
| ROAD WHEELS.....                   | 1. F 11 |
| ROAD WHEELS.....                   | 1. F 11 |

# SAMAND

F10

Fiche 1

AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS

REAR SUSPENSION

REAR SHOCK ABSORBERS

Illus Part Number

1 150 02 011  
1 150 02 004  
1 150 02 012  
2 030 10 007  
3 030 10 008  
4 040 01 155  
5 040 01 156  
70 186 01 181  
71 174 04 048



Description

Absorber.-rear.....1  
Absorber.....1  
Absorber.....1  
Bush.-lower.....2  
Bush.-upper.....2  
Screw.-upper-M16 x 113.....2  
Screw.-lower-M16 x 125.....2  
Washer.-plain.-M16.....2  
Nut.-self locking-M16.....4

Quantity

Change Point

Remarks



ZE0018

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

DRIVE SHAFTS AND DIFFERENTIAL.....1. F 06  
DRIVE SHAFTS.....1. F 07  
FRONT DIFFERENTIAL.....1. F 06  
FRONT SUSPENSION.....1. F 02  
FRONT ANTI ROLL BAR.....1. F 04  
FRONT SHOCK ABSORBERS.....1. F 05  
FRONT SPRING.....1. F 02  
FRONT SUSPENSION ARM AND HUB.....1. F 03  
REAR SUSPENSION.....1. F 08  
REAR SHOCK ABSORBERS.....1. F 10  
REAR SUSPENSION ARM AND HUBS.....1. F 09  
REAR SUSPENSION CROSSMEMBER.....1. F 08  
ROAD WHEELS.....1. F 11  
ROAD WHEELS.....1. F 11

## Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 081 | 01 | 008 |
| 1 | 081 | 01 | 015 |
| 2 | 127 | 02 | 014 |
| 3 | 040 | 08 | 001 |
| 4 | 096 | 09 | 001 |
| 5 | 061 | 18 | 001 |
| 6 | 090 | 11 | 001 |
| 6 | 090 | 03 | 002 |
| 6 | 090 | 10 | 001 |
| 6 | 090 | 09 | 001 |
| 6 | 090 | 02 | 002 |
| 6 | 090 | 08 | 001 |
| 6 | 090 | 07 | 001 |
| 6 | 090 | 06 | 001 |
| 6 | 090 | 05 | 001 |
| 6 | 090 | 01 | 001 |


## Description

## Quantity

## Change Point

## Remarks

|                                          |    |  |  |
|------------------------------------------|----|--|--|
| Road Wheel.-steel-5.50 J14-14 hole ..... | 5  |  |  |
| Road Wheel.-steel-6 J15 .....            | 5  |  |  |
| Wheel Cover.-road wheel .....            | 4  |  |  |
| Screw.-steel wheels-M12 x 1.25 .....     | 16 |  |  |
| Valve.-assembly .....                    | 5  |  |  |
| Cap. ....                                | 5  |  |  |
| Balance Weight.-steel wheel-10gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-15gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-20gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-25 gm .....  | 1  |  |  |
| Balance Weight.-steel wheel-30gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-35 gm .....  | 1  |  |  |
| Balance Weight.-steel wheel-40gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-45 gm .....  | 1  |  |  |
| Balance Weight.-steel wheel-50gm .....   | 1  |  |  |
| Balance Weight.-steel wheel-55gm .....   | 1  |  |  |



ZE0022

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |         |
|-------------------------------------|---------|
| DRIVE SHAFTS AND DIFFERENTIAL ..... | 1. F 06 |
| DRIVE SHAFTS .....                  | 1. F 07 |
| FRONT DIFFERENTIAL .....            | 1. F 06 |
| FRONT SUSPENSION .....              | 1. F 02 |
| FRONT ANTI ROLL BAR .....           | 1. F 04 |
| FRONT SHOCK ABSORBERS .....         | 1. F 05 |
| FRONT SPRING .....                  | 1. F 02 |
| FRONT SUSPENSION ARM AND HUB .....  | 1. F 03 |
| REAR SUSPENSION .....               | 1. F 08 |
| REAR SHOCK ABSORBERS .....          | 1. F 10 |
| REAR SUSPENSION ARM AND HUBS .....  | 1. F 09 |
| REAR SUSPENSION CROSSMEMBER .....   | 1. F 08 |
| ROAD WHEELS .....                   | 1. F 11 |
| ROAD WHEELS .....                   | 1. F 11 |





# SAMAND

G02

Fiche 1

## STEERING MANUAL AND POWER STEERING STEERING WHEEL AND COWL

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 115 | 01 | 018 |
| 2  | 126 | 20 | 020 |
| 3  | 126 | 20 | 018 |
| 4  | 126 | 20 | 019 |
| 6  | 094 | 21 | 001 |
| 70 | 186 | 01 | 105 |
| 71 | 174 | 07 | 004 |
| 72 | 040 | 14 | 031 |



Description

|                                           |   |
|-------------------------------------------|---|
| Steering Wheel.....                       | 1 |
| Trim.-steering wheel pad .....            | 1 |
| Trim.-steering column-top .....           | 1 |
| Trim.-steering column-bottom .....        | 1 |
| Switch.-rheostat-panel illumination ..... | 1 |
| Washer.-M14 .....                         | 1 |
| Nut.-self locking-M14 .....               | 1 |
| Screw.-4.2 x 12 .....                     | 1 |

Quantity

Change Point

Remarks



ZF0015

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| MANUAL AND POWER STEERING.....      | 1.G 02 |
| STEERING COLUMN .....               | 1.G 03 |
| STEERING COLUMN LOCKS .....         | 1.G 04 |
| STEERING WHEEL AND COWL .....       | 1.G 02 |
| STEERING RACK COMPONENTS .....      | 1.G 05 |
| STEERING RACK-MANUAL STEERING ..... | 1.G 05 |
| POWER ASSISTED STEERING .....       | 1.G 06 |
| POWER STEERING RESERVOIR .....      | 1.G 10 |
| STEERING RACK - POWER STEERING..... | 1.G 06 |
| STEERING RACK COMPONENTS .....      | 1.G 07 |

## STEERING MANUAL AND POWER STEERING STEERING COLUMN



|    |            |                            |   |
|----|------------|----------------------------|---|
| 1  | 102 03 018 | Shaft.-column              | 1 |
| 2  | 102 03 010 | Shaft.-steering-lower      | 1 |
| 4  | 156 04 015 | Protector.-steering        | 1 |
| 5  | 181 14 005 | Bracket.-column            | 1 |
| 6  | 040 02 058 | Screw.-M8 x 38             | 1 |
| 7  | 040 28 002 | Screw.-M8 x 35             | 1 |
| 20 | 181 14 006 | Bracket.-column assy.      | 1 |
| 21 | 186 03 077 | Washer.                    | 4 |
| 22 | 186 09 058 | Washer.-non standard paper | 1 |
| 70 | 040 02 017 | Screw.-flange-M8           | 2 |
| 71 | 174 02 004 | Nut.-self locking-M8       | 1 |
| 72 | 174 03 021 | Nut.-self locking-M14      | 1 |
| 73 | 186 01 180 | Washer.-plain..-M8         | 1 |
| 74 | 174 04 051 | Nut.-flange-6 x 100        | 5 |
| 75 | 040 01 287 | Screw.                     | 2 |
| 76 | 040 01 288 | Screw.                     | 2 |

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                     |        |
|----|-------------------------------------|--------|
| 1C | MANUAL AND POWER STEERING.....      | 1.G 02 |
| 1D | STEERING COLUMN.....                | 1.G 03 |
| 1E | STEERING COLUMN LOCKS.....          | 1.G 04 |
| 1F | STEERING WHEEL AND COWL.....        | 1.G 02 |
| 1G | STEERING RACK COMPONENTS.....       | 1.G 05 |
| 1H | STEERING RACK-MANUAL STEERING.....  | 1.G 05 |
| 1J | POWER ASSISTED STEERING.....        | 1.G 06 |
| 1J | POWER STEERING RESERVOIR.....       | 1.G 10 |
| 1K | STEERING RACK - POWER STEERING..... | 1.G 06 |
| 2C | STEERING RACK COMPONENTS.....       | 1.G 07 |
| 2F |                                     |        |
| 2H |                                     |        |
| 2I |                                     |        |

# SAMAND

G04

Fiche 1

## STEERING MANUAL AND POWER STEERING STEERING COLUMN LOCKS

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 095 | 03 | 002 |
| 1 | 095 | 03 | 003 |
| 2 | 095 | 02 | 016 |
| 3 | 194 | 01 | 009 |
| 4 | 194 | 01 | 008 |
| 5 | 194 | 01 | 010 |
| 8 | 171 | 04 | 002 |


Description

|                                                          |   |
|----------------------------------------------------------|---|
| Steering Column.-steering.-non-specific key number.....  | 1 |
| Steering Column.-steering.-specific key number.....      | 1 |
| Set of Barrel.-R/F remote control-jack knife KEYS.....   | 1 |
| Remote Control.-R/F remote control-jack knife.....       | 1 |
| Remote Control.-with infra-red central door locking..... | 1 |
| Remote Control.-R/F remote control.....                  | 1 |
| Key Blade.....                                           | 1 |

Quantity

Change Point

Remarks



ZF0009

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| MANUAL AND POWER STEERING.....      | 1.G 02 |
| STEERING COLUMN.....                | 1.G 03 |
| STEERING COLUMN LOCKS.....          | 1.G 04 |
| STEERING WHEEL AND COWL.....        | 1.G 02 |
| STEERING RACK COMPONENTS.....       | 1.G 05 |
| STEERING RACK-MANUAL STEERING.....  | 1.G 05 |
| POWER ASSISTED STEERING.....        | 1.G 06 |
| POWER STEERING RESERVOIR.....       | 1.G 10 |
| STEERING RACK - POWER STEERING..... | 1.G 06 |
| STEERING RACK COMPONENTS.....       | 1.G 07 |

| SAMAND            |     |    |     | G05                                  | STEERING<br>MANUAL STEERING<br>STEERING RACK COMPONENTS |              |         |
|-------------------|-----|----|-----|--------------------------------------|---------------------------------------------------------|--------------|---------|
|                   |     |    |     | Fiche 1                              |                                                         |              |         |
| Illus Part Number |     |    |     | Description                          | Quantity                                                | Change Point | Remarks |
|                   |     |    |     | HDR                                  |                                                         |              |         |
| 2                 | 186 | 04 | 014 | Washer.-star .....                   | 2                                                       |              |         |
| 3                 | 156 | 04 | 006 | Protector.-steering rack.....        | 2                                                       |              |         |
| 4                 | 041 | 11 | 001 | Piston.-steering rack .....          | 1                                                       |              |         |
| 5                 | 121 | 14 | 001 | Spring.-piston .....                 | 1                                                       |              |         |
| 6                 | 038 | 13 | 005 | Block & pipe-rest.....               | 1                                                       |              |         |
| 7                 | 186 | 01 | 091 | Washer.-piston.-8.2 x 26.5 .....     | 1                                                       |              |         |
| 8                 | 017 | 15 | 005 | Seal.-ring-29.1 x 32-1.6 .....       | 1                                                       |              |         |
| 9                 | 061 | 07 | 005 | Cap.-push-9mm diameter .....         | 1                                                       |              |         |
| 10                | 102 | 03 | 014 | Shaft.-connecting.....               | 2                                                       |              |         |
| 11                | 098 | 02 | 010 | Suspension Link.-ball joint-RH.....  | 1                                                       |              |         |
| 11                | 098 | 02 | 004 | Suspension Link.-ball joint-LH ..... | 1                                                       |              |         |
| 13                | 040 | 01 | 128 | Screw.-cap head-M7 x 100-18 .....    | 2                                                       |              |         |

| MASTER INDEX                            |    | GROUP INDEX                         |        |
|-----------------------------------------|----|-------------------------------------|--------|
| ENGINE                                  | 1C | MANUAL AND POWER STEERING.....      | 1.G 02 |
| FLYWHEEL AND CLUTCH                     | 1D | STEERING COLUMN .....               | 1.G 03 |
| GEARBOX                                 | 1E | STEERING COLUMN LOCKS.....          | 1.G 04 |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS | 1F | STEERING WHEEL AND COWL.....        | 1.G 02 |
| STEERING                                | 1G | STEERING RACK COMPONENTS .....      | 1.G 05 |
| BRAKES AND BRAKE CONTROLS               | 1H | STEERING RACK-MANUAL STEERING ..... | 1.G 05 |
| FUEL, EXHAUST AND EMISSION SYSTEM       | 1I | POWER ASSISTED STEERING .....       | 1.G 06 |
| COOLING, HEATING AND AIR CONDITIONING   | 1J | POWER STEERING RESERVOIR .....      | 1.G 10 |
| ELECTRICAL AND INSTRUMENTS              | 1K | STEERING RACK - POWER STEERING..... | 1.G 06 |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-  | 2C | STEERING RACK COMPONENTS .....      | 1.G 07 |
| FACIA, TRIM, SEATS AND FIXINGS          | 2F |                                     |        |
| ACCESSORIES AND PAINT                   | 2H |                                     |        |
| Numeric Index                           | 2I |                                     |        |

[www.me-en.com](http://www.me-en.com)




پایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک)

# SAMAND

G06

Fiche 1

## STEERING POWER ASSISTED STEERING STEERING RACK - POWER STEERING



ZF0012

Illus Part Number

Description

Quantity Change  
Point Remarks

|    |            |                                          |   |  |  |
|----|------------|------------------------------------------|---|--|--|
| 1  | 117 02 003 | Steering Gear.-steering LHD              | 1 |  |  |
| 3  | 040 01 100 | Screw.-steering LHD-12 x 150-95-cap head | 2 |  |  |
| 4  | 065 05 002 | Gear.-pinion                             | 1 |  |  |
| 5  | 099 03 001 | Cylinder.-steering rack                  | 1 |  |  |
| 6  | 040 01 130 | Screw.-M12 x 55                          | 1 |  |  |
| 7  | 030 05 004 | Bush.-20mm diameter                      | 2 |  |  |
| 7  | 030 05 005 | Bush.-22mm diameter                      | 2 |  |  |
| 7  | 030 05 009 | Bush.-24mm diameter                      | 2 |  |  |
| 8  | 166 07 008 | Pipe.-set-LHD                            | 1 |  |  |
| 10 | 025 02 075 | Clip.-double                             | 1 |  |  |
| 11 | 237 03 009 | Protecting Plate.-steering LHD           | 1 |  |  |
| 12 | 186 10 322 | Washer.-adjustment                       | 2 |  |  |
| 13 | 174 15 001 | Nut.-steering LHD-square-12 x 150-18-16  | 2 |  |  |
| 70 | 040 01 278 | Screw.-socket head-7 x 100-20            | 2 |  |  |
| 73 | 186 01 114 | Washer.-plain-12 x 32                    | 2 |  |  |
| 74 | 186 01 096 | Washer.-12 x 24                          | 1 |  |  |
| 75 | 186 02 003 | Washer.-7x13.7-0.8-flexible-7 x 13.7     | 2 |  |  |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| MANUAL AND POWER STEERING.....      | 1.G 02 |
| STEERING COLUMN.....                | 1.G 03 |
| STEERING COLUMN LOCKS.....          | 1.G 04 |
| STEERING WHEEL AND COWL.....        | 1.G 02 |
| STEERING RACK COMPONENTS.....       | 1.G 05 |
| STEERING RACK-MANUAL STEERING.....  | 1.G 05 |
| POWER ASSISTED STEERING.....        | 1.G 06 |
| POWER STEERING RESERVOIR.....       | 1.G 10 |
| STEERING RACK - POWER STEERING..... | 1.G 06 |
| STEERING RACK COMPONENTS.....       | 1.G 07 |




# SAMAND

G07

Fiche 1

## STEERING POWER ASSISTED STEERING STEERING RACK COMPONENTS



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 102 | 03 | 014 |
| 2  | 098 | 02 | 004 |
| 2  | 098 | 02 | 010 |
| 3  | 237 | 03 | 003 |
| 4  | 186 | 04 | 014 |
| 5  | 186 | 05 | 020 |
| 6  | 041 | 11 | 001 |
| 7  | 121 | 14 | 001 |
| 8  | 038 | 13 | 005 |
| 9  | 186 | 05 | 021 |
| 10 | 186 | 05 | 022 |
| 11 | 186 | 01 | 091 |
| 12 | 061 | 07 | 005 |
| 13 | 017 | 15 | 005 |
| 14 | 156 | 04 | 006 |
| 15 | 156 | 04 | 007 |
| 16 | 061 | 07 | 001 |
| 18 | 040 | 01 | 128 |
| 71 | 174 | 07 | 002 |

### Description

|                                         |   |
|-----------------------------------------|---|
| Shaft.-connecting.....                  | 2 |
| Suspension Link.-ball joint-LH.....     | 1 |
| Suspension Link.-ball joint-RH.....     | 1 |
| Protecting Plate.-ring.....             | 2 |
| Washer.-star.....                       | 1 |
| Washer.....                             | 1 |
| Piston.-steering rack.....              | 1 |
| Spring.-piston.....                     | 1 |
| Block & pipe-rest.....                  | 1 |
| Washer.-piston-piston.-21.5 x 27.6..... | 1 |
| Washer.-piston.-8.2 x 26.5.....         | 1 |
| Washer.-piston.-8.2 x 26.5.....         | 1 |
| Cap.-push-9mm diameter.....             | 1 |
| Seal.-ring-29.1 x 32-1.6.....           | 1 |
| Protector.-steering rack.....           | 1 |
| Protector.-steering rack.....           | 1 |
| Protectors.-steering rack.....          | 1 |
| Screw.-cap head-M7 x 100-18.....        | 2 |
| Nut.-M10.....                           | 2 |

### Quantity

### Change Point

### Remarks

ZF0018

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX


MANUAL AND POWER STEERING.....1.G 02  
STEERING COLUMN.....1.G 03  
STEERING COLUMN LOCKS.....1.G 04  
STEERING WHEEL AND COWL.....1.G 02  
STEERING RACK COMPONENTS.....1.G 05  
STEERING RACK-MANUAL STEERING.....1.G 05  
POWER ASSISTED STEERING.....1.G 06  
POWER STEERING RESERVOIR.....1.G 10  
STEERING RACK - POWER STEERING.....1.G 06  
STEERING RACK COMPONENTS.....1.G 07

# SAMAND

G08

Fiche 1

## STEERING POWER ASSISTED STEERING POWER ASSISTED STEERING- PIPING



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 166 | 07 | 010 |
| 2  | 166 | 07 | 011 |
| 3  | 166 | 07 | 005 |
| 4  | 166 | 07 | 004 |
| 6  | 181 | 26 | 011 |
| 7  | 025 | 01 | 115 |
| 9  | 030 | 05 | 002 |
| 10 | 025 | 10 | 014 |
| 14 | 078 | 01 | 001 |
| 70 | 025 | 03 | 019 |
| 71 | 025 | 03 | 018 |
| 72 | 025 | 01 | 100 |
| 73 | 174 | 04 | 020 |
| 74 | 174 | 04 | 031 |
| 75 | 025 | 01 | 111 |


### Description

|                           |   |
|---------------------------|---|
| Pipe.-high pressure.....  | 1 |
| Pipe.-low pressure.....   | 1 |
| Pipe.-low pressure.....   | 1 |
| Pipe.-PAS pipe.....       | 1 |
| Bracket.....              | 1 |
| Clip.....                 | 1 |
| Bush.....                 | 1 |
| Clip.-line.....           | 1 |
| Cover.-sleeve.....        | 1 |
| Clip.....                 | 4 |
| Clip.-metal.....          | 4 |
| Clip.....                 | 3 |
| Nut.-flange-M6.....       | 1 |
| Nut.-flange-M8.....       | 1 |
| Clip.-swivel-10 x 20..... | 3 |

### Quantity

### Change Point

### Remarks



ZF0019

### MASTER INDEX

|                                                                      |    |
|----------------------------------------------------------------------|----|
| ENGINE                                                               | 1C |
| FLYWHEEL AND CLUTCH                                                  | 1D |
| GEARBOX                                                              | 1E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS                              | 1F |
| STEERING                                                             | 1G |
| BRAKES AND BRAKE CONTROLS                                            | 1H |
| FUEL, EXHAUST AND EMISSION SYSTEM                                    | 1I |
| COOLING, HEATING AND AIR CONDITIONING                                | 1J |
| ELECTRICAL AND INSTRUMENTS                                           | 1K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-FACIA, TRIM, SEATS AND FIXINGS | 2C |
| ACCESSORIES AND PAINT                                                | 2F |
| Numeric Index                                                        | 2H |
|                                                                      | 2I |

### GROUP INDEX


|                                     |        |
|-------------------------------------|--------|
| MANUAL AND POWER STEERING.....      | 1.G 02 |
| STEERING COLUMN.....                | 1.G 03 |
| STEERING COLUMN LOCKS.....          | 1.G 04 |
| STEERING WHEEL AND COWL.....        | 1.G 02 |
| STEERING RACK COMPONENTS.....       | 1.G 05 |
| STEERING RACK-MANUAL STEERING.....  | 1.G 05 |
| POWER ASSISTED STEERING.....        | 1.G 06 |
| POWER STEERING RESERVOIR.....       | 1.G 10 |
| STEERING RACK - POWER STEERING..... | 1.G 06 |
| STEERING RACK COMPONENTS.....       | 1.G 07 |

# SAMAND

G09

Fiche 1

## STEERING POWER ASSISTED STEERING POWER STEERING PUMP



Illus Part Number

3 036 07 004  
3 036 07 002  
6 207 02 003  
7 040 01 085  
72 042 07 029  
73 186 01 174  
74 040 20 007

Description


Pump.-steering.  
Pump.-steering.  
Drive Belt.-Alternator-L = 1660  
Screw.-cap head-M8 x 125-25  
Dowel.-centralising-13 x 33  
Washer.-plain-8 x 16  
Screw.-column

Quantity

Change  
Point

Remarks

1  
1  
1  
4  
1  
1  
1



ZF0004

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

MANUAL AND POWER STEERING.....1.G 02  
STEERING COLUMN .....1.G 03  
STEERING COLUMN LOCKS .....1.G 04  
STEERING WHEEL AND COWL.....1.G 02  
STEERING RACK COMPONENTS .....1.G 05  
STEERING RACK-MANUAL STEERING .....1.G 05  
POWER ASSISTED STEERING .....1.G 06  
POWER STEERING RESERVOIR .....1.G 10  
STEERING RACK - POWER STEERING.....1.G 06  
STEERING RACK COMPONENTS .....1.G 07

# SAMAND

G10

Fiche 1

## STEERING POWER ASSISTED STEERING POWER STEERING RESERVOIR

Illus Part Number

1 172 05 002  
2 170 15 001  
70 040 22 004  
71 174 04 051  
72 174 08 006



Description

Reservoir.-reservoir ..... 1  
Plug/Cover ..... 1  
Screw.-shouldered-M6 x 100-20 ..... 2  
Nut.-flange-6 x 100 ..... 1  
Nut.-caged-M6 ..... 1

Quantity

Change Point

Remarks



ZF0001

### MASTER INDEX







ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

MANUAL AND POWER STEERING ..... 1.G 02  
STEERING COLUMN ..... 1.G 03  
STEERING COLUMN LOCKS ..... 1.G 04  
STEERING WHEEL AND COWL ..... 1.G 02  
STEERING RACK COMPONENTS ..... 1.G 05  
STEERING RACK-MANUAL STEERING ..... 1.G 05  
POWER ASSISTED STEERING ..... 1.G 06  
POWER STEERING RESERVOIR ..... 1.G 10  
STEERING RACK - POWER STEERING ..... 1.G 06  
STEERING RACK COMPONENTS ..... 1.G 07

| SAMAND                                           |                                               | H01<br>Fiche 1 | BRAKES AND BRAKE CONTROLS |                                                |
|--------------------------------------------------|-----------------------------------------------|----------------|---------------------------|------------------------------------------------|
| MASTER INDEX                                     | GROUP INDEX                                   |                |                           |                                                |
| ENGINE ..... 1 C                                 |                                               |                |                           |                                                |
| FLYWHEEL AND CLUTCH ..... 1 D                    | BRAKES NON ABS ..... 1. H 02                  |                |                           |                                                |
| GEARBOX ..... 1 E                                | BRAKE CLIPS ..... 1. H 09                     |                |                           |                                                |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS.. 1 F    | BRAKE PEDAL AND BRACKET - MANUAL .... 1. H 04 |                |                           |                                                |
| STEERING..... 1 G                                | BRAKE PIPING ..... 1. H 08                    |                |                           |                                                |
| BRAKES AND BRAKE CONTROLS..... 1 H               | BRAKE PRESSURE REGULATOR..... 1. H 10         |                |                           |                                                |
| FUEL, EXHAUST AND EMISSION SYSTEM ..... 1 I      | BRAKE SERVO UNIT..... 1. H 05                 |                |                           |                                                |
| COOLING, HEATING AND AIR CONDITIONING..... 1 J   | FRONT DISCS AND PADS - W/O ABS..... 1. H 02   |                |                           |                                                |
| ELECTRICAL AND INSTRUMENTS ..... 1 K             | HANDBRAKE LEVER AND CABLES..... 1. H 07       |                |                           |                                                |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-.. 2 C     | MASTER CYLINDER ..... 1. H 06                 |                |                           |                                                |
| FACIA, TRIM, SEATS AND FIXINGS..... 2 F          | REAR DRUMS AND SHOES - W/O ABS..... 1. H 03   |                |                           |                                                |
| ACCESSORIES AND PAINT ..... 2 H                  |                                               |                |                           |                                                |
| Numeric Index ..... 2 I                          |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
|                                                  |                                               |                |                           |                                                |
| <a href="http://www.me-en.com">www.me-en.com</a> |                                               |                |                           | پایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک) |



ZH0010

Illus Part Number

1 067 02 019  
3 099 05 012  
3 099 05 011  
4 162 01 007  
5 181 19 001  
5 181 19 002  
6 163 13 004  
7 163 13 013  
8 040 06 009  
9 156 19 001  
10 040 01 038  
70 040 05 001

Description

BRAKE DISC.-front  
Cylinder.-RH  
Cylinder.-LH  
Brake Pads.-Bendix-front-asbestos free-Standard  
Bracket.-caliper -LH  
Bracket.-caliper -RH  
Kit.-brake cylinder  
Kit.-rubber-bush.-assembly  
Screw.-bleed  
Protector.-bleed screw-Girling  
Screw.-caliper -M12 x 1.50-35  
Screw.-M6 x 100-12

Quantity Change  
Point Remarks

1  
1  
1  
1set  
1  
1  
2  
2  
2  
2  
4  
4

MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX



BRAKES NON ABS .....1.H 02  
BRAKE CLIPS .....1.H 09  
BRAKE PEDAL AND BRACKET - MANUAL .....1.H 04  
BRAKE PIPING .....1.H 08  
BRAKE PRESSURE REGULATOR .....1.H 10  
BRAKE SERVO UNIT .....1.H 05  
FRONT DISCS AND PADS - W/O ABS .....1.H 02  
HANDBRAKE LEVER AND CABLES .....1.H 07  
MASTER CYLINDER .....1.H 06  
REAR DRUMS AND SHOES - W/O ABS .....1.H 03

# SAMAND

H03

Fiche 1

## BRAKES AND BRAKE CONTROLS BRAKES NON ABS REAR DRUMS AND SHOES - W/O ABS



ZH0011

Illus Part Number

Description

Quantity

Change  
Point

Remarks

Remarks

1 112 01 018

Plate.-brake-LH-Bendix

1

1 112 01 019

Plate.-brake-RH-Bendix

1

2 141 01 007

Brake Drum.-drum brake

2

3 146 01 014

Brake Shoe

1

4 146 01 013

Brake Shoe.-brake-asbestos free-Bendix

1

5 099 05 018

Cylinder.-brake-RH-Bendix

5 099 05 019

Cylinder.-brake-LH-Bendix

6 040 01 133

Screw.-6 X 1.00-10-brake cylinder

4

7 040 06 011

Screw.-bleed

2

8 121 06 030

Spring.-brake-Bendix-kit

10 163 03 024

KIT.-brake shoe retainer

1

Manual

9 163 20 001

Kit.-Brake Lever assy

2

70 040 02 094

Screw.-socket head-M10 x 150-25

6

71 040 05 001

Screw.-M6 x 100-12

4

### MASTER INDEX



ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BRAKES NON ABS ..... 1 H 02  
BRAKE CLIPS ..... 1 H 09  
BRAKE PEDAL AND BRACKET - MANUAL ..... 1 H 04  
BRAKE PIPING ..... 1 H 08  
BRAKE PRESSURE REGULATOR ..... 1 H 10  
BRAKE SERVO UNIT ..... 1 H 05  
FRONT DISCS AND PADS - W/O ABS ..... 1 H 02  
HANDBRAKE LEVER AND CABLES ..... 1 H 07  
MASTER CYLINDER ..... 1 H 06  
REAR DRUMS AND SHOES - W/O ABS ..... 1 H 03





Illus Part Number

|    |            |
|----|------------|
| 1  | 181 04 001 |
| 2  | 181 36 001 |
| 3  | 032 01 001 |
| 4  | 040 01 094 |
| 5  | 030 17 002 |
| 6  | 030 18 001 |
| 7  | 102 02 005 |
| 9  | 094 01 006 |
| 10 | 025 01 010 |
| 11 | 042 06 001 |
| 12 | 160 04 003 |
| 13 | 186 23 004 |
| 14 | 025 02 032 |
| 70 | 174 02 004 |
| 71 | 186 01 151 |
| 72 | 174 02 003 |
| 73 | 040 14 029 |

Description

|                               |
|-------------------------------|
| Bracket.-pedal                |
| Bracket.-pedal                |
| Pedal Assy.-brake             |
| Screw.-pedal                  |
| Bush.-pedal                   |
| Bush.-pedal                   |
| Shaft.-10 X 14                |
| Switch.-stop light            |
| Clip.                         |
| Dowel.-push-rod               |
| Rubber Cover.-pedal-assembly  |
| Washer.-support               |
| Clip.-8mm diameter            |
| Nut.-self locking-M8          |
| Washer.-8 x 22mm              |
| Nut.-self locking-10x150-9-17 |
| Screw.-pedal-assembly         |

Quantity

|   |
|---|
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 1 |
| 4 |
| 4 |
| 1 |
| 1 |

Change  
Point

Remarks

ZH0012

MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX

|                                  |        |
|----------------------------------|--------|
| BRAKES NON ABS                   | 1.H 02 |
| BRAKE CLIPS                      | 1.H 09 |
| BRAKE PEDAL AND BRACKET - MANUAL | 1.H 04 |
| BRAKE PIPING                     | 1.H 08 |
| BRAKE PRESSURE REGULATOR         | 1.H 10 |
| BRAKE SERVO UNIT                 | 1.H 05 |
| FRONT DISCS AND PADS - W/O ABS   | 1.H 02 |
| HANDBRAKE LEVER AND CABLES       | 1.H 07 |
| MASTER CYLINDER                  | 1.H 06 |
| REAR DRUMS AND SHOES - W/O ABS   | 1.H 03 |

# SAMAND


H05

Fiche 1

## BRAKES AND BRAKE CONTROLS

### BRAKES NON ABS

### BRAKE SERVO UNIT



#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 002 | 02 | 009 |
| 2  | 186 | 23 | 006 |
| 4  | 163 | 03 | 022 |
| 4  | 163 | 03 | 023 |
| 5  | 096 | 02 | 010 |
| 5  | 096 | 02 | 011 |
| 6  | 108 | 10 | 005 |
| 8  | 205 | 02 | 039 |
| 9  | 025 | 02 | 091 |
| 11 | 078 | 03 | 013 |
| 70 | 174 | 04 | 031 |
| 71 | 025 | 03 | 018 |
| 72 | 058 | 07 | 004 |
| 73 | 025 | 01 | 081 |


#### Description

|                                               |   |
|-----------------------------------------------|---|
| Servo Unit .....                              | 1 |
| Washer-servo.....                             | 1 |
| Kit.-brake servo-TEVES.....                   | 1 |
| Kit.-brake servo-D.B.A .....                  | 1 |
| Valve.-brake servo-Bendix-Bosch.....          | 1 |
| Valve.-brake servo-TEVES .....                | 1 |
| Hose.-brake vacuum .....                      | 1 |
| Grommet.....                                  | 1 |
| Clip.-brake vacuum-swivel .....               | 1 |
| Cover.-brake vacuum-protection.....           | 1 |
| Nut.-flange-M8 .....                          | 1 |
| Clip.-metal.....                              | 2 |
| Fixing Clip.-brake servo-harness-1.50mm ..... | 1 |
| Clip.-11-18 RAYMOND .....                     | 2 |

#### Quantity

#### Change Point

#### Remarks



ZH0013


#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

|                                        |        |
|----------------------------------------|--------|
| BRAKES NON ABS .....                   | 1 H 02 |
| BRAKE CLIPS .....                      | 1 H 09 |
| BRAKE PEDAL AND BRACKET - MANUAL ..... | 1 H 04 |
| BRAKE PIPING .....                     | 1 H 08 |
| BRAKE PRESSURE REGULATOR .....         | 1 H 10 |
| BRAKE SERVO UNIT .....                 | 1 H 05 |
| FRONT DISCS AND PADS - W/O ABS .....   | 1 H 02 |
| HANDBRAKE LEVER AND CABLES .....       | 1 H 07 |
| MASTER CYLINDER .....                  | 1 H 06 |
| REAR DRUMS AND SHOES - W/O ABS .....   | 1 H 03 |



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 036 | 05 | 001 |
| 2  | 172 | 06 | 003 |
| 3  | 170 | 11 | 004 |
| 4  | 017 | 26 | 001 |
| 6  | 077 | 02 | 004 |
| 70 | 040 | 01 | 228 |
| 71 | 174 | 03 | 073 |

Description


|                                    |      |
|------------------------------------|------|
| Pump.-NON ABS-diameter 20.60 ..... | 1    |
| Reservoir.-brake hydraulic .....   | 1    |
| Plug/Cover.-reservoir .....        | 1    |
| Seal.-reservoir .....              | 2    |
| Fluid.-GAMME PRO .....             | 1LTR |
| Screw.-cap head-M5 x 80-25 .....   | 1    |
| Nut.-hexagonal head-5 x 80 .....   | 1    |

Quantity

Change Point

Remarks

Antilock brakes not fitted



ZH0014

MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX


|                                        |        |
|----------------------------------------|--------|
| BRAKES NON ABS .....                   | 1.H 02 |
| BRAKE CLIPS .....                      | 1.H 09 |
| BRAKE PEDAL AND BRACKET - MANUAL ..... | 1.H 04 |
| BRAKE PIPING .....                     | 1.H 08 |
| BRAKE PRESSURE REGULATOR .....         | 1.H 10 |
| BRAKE SERVO UNIT .....                 | 1.H 05 |
| FRONT DISCS AND PADS - W/O ABS .....   | 1.H 02 |
| HANDBRAKE LEVER AND CABLES .....       | 1.H 07 |
| MASTER CYLINDER .....                  | 1.H 06 |
| REAR DRUMS AND SHOES - W/O ABS .....   | 1.H 03 |

# SAMAND

H07

Fiche 1

## BRAKES AND BRAKE CONTROLS BRAKES NON ABS HANDBRAKE LEVER AND CABLES



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 015 | 01 | 009 |
| 2  | 126 | 25 | 002 |
| 3  | 037 | 11 | 001 |
| 5  | 138 | 06 | 001 |
| 6  | 138 | 06 | 003 |
| 7  | 138 | 06 | 004 |
| 8  | 181 | 32 | 002 |
| 9  | 025 | 10 | 008 |
| 10 | 025 | 02 | 008 |
| 11 | 094 | 10 | 002 |
| 12 | 181 | 35 | 006 |
| 71 | 174 | 03 | 074 |
| 72 | 174 | 02 | 004 |
| 73 | 186 | 01 | 016 |
| 74 | 186 | 02 | 046 |
| 75 | 186 | 02 | 044 |
| 77 | 025 | 01 | 109 |


### Description

|                                      |   |
|--------------------------------------|---|
| Lever.-handbrake.....                | 1 |
| Trim.-thickness 12.....              | 1 |
| Housing Body.....                    | 1 |
| Control Cable.-handbrake-centre..... | 1 |
| Control Cable.-handbrake-LH.....     | 1 |
| Control Cable.-handbrake-RH.....     | 1 |
| Bracket.-sleeve.....                 | 1 |
| Clip.....                            | 2 |
| Clip.-handbrake cable.....           | 2 |
| Switch.....                          | 1 |
| Bracket.....                         | 1 |
| Nut.-8 X 125.....                    | 4 |
| Nut.-self locking-M8.....            | 2 |
| Washer.-8 x 22mm-plain.....          | 2 |
| Washer.....                          | 1 |
| Washer.-8.3 X 14.3-spring.....       | 4 |
| Clip.-cable-24mm diameter.....       | 2 |

### Quantity

### Change Point

### Remarks



ZH0015

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                       |        |
|---------------------------------------|--------|
| BRAKES NON ABS.....                   | 1.H 02 |
| BRAKE CLIPS.....                      | 1.H 09 |
| BRAKE PEDAL AND BRACKET - MANUAL..... | 1.H 04 |
| BRAKE PIPING.....                     | 1.H 08 |
| BRAKE PRESSURE REGULATOR.....         | 1.H 10 |
| BRAKE SERVO UNIT.....                 | 1.H 05 |
| FRONT DISCS AND PADS - W/O ABS.....   | 1.H 02 |
| HANDBRAKE LEVER AND CABLES.....       | 1.H 07 |
| MASTER CYLINDER.....                  | 1.H 06 |
| REAR DRUMS AND SHOES - W/O ABS.....   | 1.H 03 |

# SAMAND

H08

Fiche 1

## BRAKES AND BRAKE CONTROLS

### BRAKES NON ABS

#### BRAKE PIPING



Illus Part Number

Description

Quantity

Change Point

Remarks



ZH0016

|    |            |                                     |   |  |  |
|----|------------|-------------------------------------|---|--|--|
| 1  | 166 05 089 | Pipe.-L = 425 .....                 | 1 |  |  |
| 2  | 166 05 011 | Pipe.-L = 600 .....                 | 4 |  |  |
| 3  | 166 05 055 | Pipe.-L = 950 .....                 | 1 |  |  |
| 4  | 166 05 056 | Pipe.-L = 1050 .....                | 1 |  |  |
| 5  | 166 05 061 | Pipe.-L = 3450 .....                | 1 |  |  |
| 6  | 166 05 009 | Pipe.-L = 900 .....                 | 1 |  |  |
| 7  | 166 05 012 | Pipe.-L = 2650 .....                | 2 |  |  |
| 8  | 166 05 059 | Pipe.-L = 400 .....                 | 2 |  |  |
| 9  | 108 11 007 | Hose.-L = 445-flexible .....        | 2 |  |  |
| 10 | 108 11 011 | Hose.-L = 180-flexible .....        | 2 |  |  |
| 11 | 093 02 006 | Union-union .....                   | 2 |  |  |
| 12 | 181 26 034 | Bracket.-pipe-LH .....              | 1 |  |  |
| 12 | 181 26 035 | Bracket.-pipe-RH .....              | 1 |  |  |
| 13 | 181 26 002 | Bracket.-pipe-LH .....              | 1 |  |  |
| 13 | 181 26 003 | Bracket.-pipe-RH .....              | 1 |  |  |
| 14 | 181 26 036 | Bracket.-pipe-LH .....              | 1 |  |  |
| 14 | 181 26 037 | Bracket.-pipe-RH .....              | 1 |  |  |
| 15 | 181 26 004 | Bracket.-pipe-LH .....              | 1 |  |  |
| 15 | 181 26 005 | Bracket.-pipe-RH .....              | 1 |  |  |
| 16 | 025 02 009 | Clip .....                          | 6 |  |  |
| 70 | 040 22 009 | Screw.-shouldered-M8 x 125-20 ..... | 4 |  |  |
| 71 | 040 01 030 | Screw.-shouldered-M8 x 125-25 ..... | 4 |  |  |
| 72 | 174 04 031 | Nut.-flange-M8 .....                | 2 |  |  |

## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C BRAKES NON ABS .....1.H 02  
1D BRAKE CLIPS .....1.H 09  
1E BRAKE PEDAL AND BRACKET - MANUAL.....1.H 04  
1F BRAKE PIPING .....1.H 08  
1G BRAKE PRESSURE REGULATOR .....1.H 10  
1H BRAKE SERVO UNIT .....1.H 05  
1I FRONT DISCS AND PADS - W/O ABS .....1.H 02  
1J HANDBRAKE LEVER AND CABLES .....1.H 07  
1K MASTER CYLINDER.....1.H 06  
2C REAR DRUMS AND SHOES - W/O ABS .....1.H 03  
2F  
2H  
2I

# SAMAND

H09

Fiche 1

## BRAKES AND BRAKE CONTROLS

### BRAKES NON ABS

#### BRAKE CLIPS

| Illus Part Number |    |    |    |   |   | Description                 | Quantity | Change Point | Remarks |
|-------------------|----|----|----|---|---|-----------------------------|----------|--------------|---------|
| 1                 | 2  | 3  | 4  | 5 | 6 | Clip.....                   | 3        |              |         |
| 7                 | 13 | 14 | 15 |   |   | Clip.....                   | 3        |              |         |
|                   |    |    |    |   |   | Clip.-4.80mm .....          | 7        |              |         |
|                   |    |    |    |   |   | Clip.-diameter 4.75 .....   | 2        |              |         |
|                   |    |    |    |   |   | Clip.-4.80mm .....          | 1        |              |         |
|                   |    |    |    |   |   | Clip.....                   | 2        |              |         |
|                   |    |    |    |   |   | Clip.-16-18 X 4,7 .....     | 3        |              |         |
|                   |    |    |    |   |   | Fixing Clip.-mounting ..... | 5        |              |         |
|                   |    |    |    |   |   | Clip.-L=275, w=5 .....      | 4        |              |         |
|                   |    |    |    |   |   | Clip.-swivel .....          | 2        |              |         |

ZH0008

## MASTER INDEX

|                                                                      |    |
|----------------------------------------------------------------------|----|
| ENGINE                                                               | 1C |
| FLYWHEEL AND CLUTCH                                                  | 1D |
| GEARBOX                                                              | 1E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS                              | 1F |
| STEERING                                                             | 1G |
| BRAKES AND BRAKE CONTROLS                                            | 1H |
| FUEL, EXHAUST AND EMISSION SYSTEM                                    | 1I |
| COOLING, HEATING AND AIR CONDITIONING                                | 1J |
| ELECTRICAL AND INSTRUMENTS                                           | 1K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-FACIA, TRIM, SEATS AND FIXINGS | 2C |
| ACCESSORIES AND PAINT                                                | 2F |
| Numeric Index                                                        | 2H |
|                                                                      | 2I |

## GROUP INDEX

|                                        |        |
|----------------------------------------|--------|
| BRAKES NON ABS .....                   | 1.H 02 |
| BRAKE CLIPS .....                      | 1.H 09 |
| BRAKE PEDAL AND BRACKET - MANUAL ..... | 1.H 04 |
| BRAKE PIPING .....                     | 1.H 08 |
| BRAKE PRESSURE REGULATOR .....         | 1.H 10 |
| BRAKE SERVO UNIT .....                 | 1.H 05 |
| FRONT DISCS AND PADS - W/O ABS .....   | 1.H 02 |
| HANDBRAKE LEVER AND CABLES .....       | 1.H 07 |
| MASTER CYLINDER .....                  | 1.H 06 |
| REAR DRUMS AND SHOES - W/O ABS .....   | 1.H 03 |

[illegible]

## GROUP INDEX

|                                               |    |     |
|-----------------------------------------------|----|-----|
| ENGINE CONTROLS .....                         | 1. | 112 |
| ACCELERATOR CABLE AND PEDAL .....             | 1. | 112 |
| EXHAUST .....                                 | 1. | 109 |
| EXHAUST HEAT SHIELDS .....                    | 1. | 111 |
| MANIFOLD/DOWN PIPE/INTERMEDIATE .....         | 1. | 109 |
| REAR EXHAUST .....                            | 1. | 110 |
| FUEL .....                                    | 1. | 102 |
| AIR FILTER, AIR HOSE AIR RESONATOR, NO1. .... | 1. | 102 |
| AIR FILTER, AIR HOSE, AIR RESONATOR ....      | 1. | 102 |
| FUEL FILLER NO FUME RECOVERY .....            | 1. | 107 |
| FUEL FILLER WITH PETRO FUME .....             | 1. | 108 |
| FUEL PIPES AND CLIPS .....                    | 1. | 108 |
| FUEL TANK .....                               | 1. | 106 |
| INJECTOR CALCULATOR - SAGEM .....             | 1. | 105 |
| INJECTORS - SAGEM .....                       | 1. | 104 |
| INTAKE MANIFOLD - SAGEM .....                 | 1. | 103 |

|        |    |
|--------|----|
| ENGINE | 16 |
|--------|----|

|                     |     |
|---------------------|-----|
| FLYWHEEL AND CLUTCH | 1 D |
|---------------------|-----|

|         |    |
|---------|----|
| GEARBOX | 15 |
|---------|----|

AXLE/CHASSIS DRIVE SHAFTS/WHEELS 15

|          |    |
|----------|----|
| STEERING | 10 |
|----------|----|

|                           |     |
|---------------------------|-----|
| BRAKES AND BRAKE CONTROLS | 111 |
|---------------------------|-----|

FUEL, EXHAUST AND EMISSION SYSTEM 11

COOLING, HEATING AND AIR CONDITIONING 41

ELECTRICAL AND INSTRUMENTS 116

ENGINE MOUNTINGS, BODY SHELL AND WASHL 36

TABLE III  
EFFECT OF TEMPERATURE ON THE GROWTH OF *E. coli* O157:H7 IN STEAK TISSUE AT DIFFERENT INITIAL CONCENTRATIONS AND STORAGE TIMES

ACCESSORIES AND PAINT 24

|               |    |
|---------------|----|
| Memoria Index | 21 |
|---------------|----|

[illegible]

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

[www.me-en.com](http://www.me-en.com)

ENGINE CONTROLS 1-113

|                             |   |     |
|-----------------------------|---|-----|
| ACCELERATOR CABLE AND PEDAL | 1 | 113 |
|-----------------------------|---|-----|

|         |   |     |
|---------|---|-----|
| EXHAUST | 1 | 108 |
|---------|---|-----|

|                      |   |     |
|----------------------|---|-----|
| EXHAUST HEAT SHIELDS | 1 | 111 |
|----------------------|---|-----|

|                                 |   |      |
|---------------------------------|---|------|
| MANIFOLD/DOWN PIPE/INTERMEDIATE | 1 | 1.09 |
|---------------------------------|---|------|

|              |   |     |
|--------------|---|-----|
| REAR EXHAUST | 1 | 110 |
|--------------|---|-----|

|     |   |     |
|-----|---|-----|
| ELI | 1 | 102 |
|-----|---|-----|

AIR FILTER AIR HOSE AIR RESONATOR NO1 102

AIR FILTER, AIR HOSE, AIR RESONATOR .... 1. 102

FUEL FILLER NO FUME RECOVERY..... 1. 107

FUEL FILLER WITH PETRO FUME..... 1. 108

FUEL PIPES AND CLIPS..... 1. 108

FUEL TANK ..... 1. 106

INJECTOR CALCULATOR - SAGEM ..... 1. 105

INJECTORS - SAGEM ..... 1. 104

INTAKE MANIFOLD - SAGEM ..... 1. 103



# SAMAND


102

Fiche 1

## FUEL, EXHAUST AND EMISSION SYSTEM

### FUEL

#### AIR FILTER, AIR HOSE, AIR RESONATOR WITH PRE FILTER



#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 124 | 03 | 016 |
| 2  | 108 | 07 | 009 |
| 3  | 186 | 03 | 071 |
| 4  | 108 | 07 | 010 |
| 5  | 108 | 07 | 013 |
| 6  | 108 | 07 | 031 |
| 7  | 124 | 02 | 005 |
| 8  | 108 | 07 | 030 |
| 9  | 061 | 37 | 001 |
| 10 | 040 | 03 | 058 |
| 71 | 025 | 02 | 077 |
| 72 | 025 | 02 | 076 |
| 73 | 025 | 03 | 029 |
| 74 | 174 | 04 | 023 |


#### Description

|                                  |   |
|----------------------------------|---|
| Filter.-element.....             | 1 |
| Hose.-air hose.....              | 1 |
| Washer.-seal.....                | 1 |
| Hose.-air hose.....              | 1 |
| Hose.-filter air.....            | 1 |
| Hose.-air intake.....            | 1 |
| Filter.-mann.....                | 1 |
| Hose.-air fitting.....           | 1 |
| Protectors.-20 X 28.....         | 1 |
| Screw.-6 x 100.....              | 1 |
| Clip.-metal-diameter 60-100..... | 1 |
| Clip.-metal.....                 | 1 |
| Clip.-metal.....                 | 1 |
| Nut.-6 x 100.....                | 1 |

#### Quantity

#### Change Point

#### Remarks



ZJ0005

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ENGINE CONTROLS.....1. | 12  
ACCELERATOR CABLE AND PEDAL.....1. | 12  
EXHAUST.....1. | 09  
EXHAUST HEAT SHIELDS.....1. | 11  
MANIFOLD/DOWN PIPE/INTERMEDIATE.....1. | 09  
REAR EXHAUST.....1. | 10  
FUEL.....1. | 02  
AIR FILTER, AIR HOSE AIR RESONATOR, NO.....1. | 02  
AIR FILTER, AIR HOSE, AIR RESONATOR.....1. | 02  
FUEL FILLER NO FUME RECOVERY.....1. | 07  
FUEL FILLER WITH PETRO FUME.....1. | 08  
FUEL PIPES AND CLIPS.....1. | 08  
FUEL TANK.....1. | 06  
INJECTOR CALCULATOR - SAGEM.....1. | 05  
INJECTORS - SAGEM.....1. | 04  
INTAKE MANIFOLD - SAGEM.....1. | 03

# SAMAND

103

Fiche 1

## FUEL, EXHAUST AND EMISSION SYSTEM

### FUEL INTAKE MANIFOLD - SAGEM


Illus Part Number

Description

Quantity

Change  
Point

Remarks





|    |            |                                          |   |  |  |
|----|------------|------------------------------------------|---|--|--|
| 1  | 167 01 006 | Manifold.-MGI with gasket                | 1 |  |  |
| 2  | 040 03 036 | Screw.-M8 x 125                          | 4 |  |  |
| 3  | 181 17 040 | Bracket.-retaining lug                   | 2 |  |  |
| 4  | 181 17 041 | Bracket.-assembly-injection harness      | 1 |  |  |
| 5  | 186 01 167 | Washer.-manifold-Green                   | 2 |  |  |
| 6  | 186 03 087 | Washer.-throttle body to manifold-maroon | 1 |  |  |
| 6  | 186 03 086 | Seal.-throttle body to manifold-Green    | 1 |  |  |
| 10 | 061 38 001 | Protectors.-water pump                   | 1 |  |  |
| 12 | 092 02 004 | Sensor.-unit-MMDCM                       | 1 |  |  |
| 12 | 092 02 005 | Sensor.-unit-AMC                         | 1 |  |  |
| 13 | 074 01 002 | Regulator.-regulator-fuel feed-MMDCM     | 1 |  |  |
| 13 | 074 01 004 | Regulator.-regulator-fuel feed-AMC       | 1 |  |  |
| 15 | 074 04 001 | Regulator.-throttle-air-intake           | 1 |  |  |
| 16 | 181 83 001 | Bracket.-bracket                         | 1 |  |  |
| 17 | 178 12 001 | Link.                                    | 1 |  |  |
| 70 | 040 22 047 | Screw.-shouldered-M8 x 125               | 2 |  |  |
| 71 | 174 04 041 | Nut.-self locking-M8 x 125               | 4 |  |  |
| 72 | 025 03 019 | Clip.                                    | 1 |  |  |
| 73 | 040 02 086 | Screw.-socket head-6 x 100               | 3 |  |  |

#### MASTER INDEX

#### GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                        |   |    |
|----|----------------------------------------|---|----|
| 1C | ENGINE CONTROLS                        | 1 | 12 |
| 1D | ACCELERATOR CABLE AND PEDAL            | 1 | 12 |
| 1E | EXHAUST                                | 1 | 09 |
| 1F | EXHAUST HEAT SHIELDS                   | 1 | 11 |
| 1G | MANIFOLD/DOWN PIPE/INTERMEDIATE        | 1 | 09 |
| 1H | REAR EXHAUST                           | 1 | 10 |
| 1I | FUEL                                   | 1 | 02 |
| 1J | AIR FILTER, AIR HOSE AIR RESONATOR, NO | 1 | 02 |
| 1K | AIR FILTER, AIR HOSE, AIR RESONATOR    | 1 | 02 |
| 2C | FUEL FILLER NO FUME RECOVERY           | 1 | 07 |
| 2F | FUEL FILLER WITH PETRO FUME            | 1 | 08 |
| 2H | FUEL PIPES AND CLIPS                   | 1 | 08 |
| 2I | FUEL TANK                              | 1 | 06 |
|    | INJECTOR CALCULATOR - SAGEM            | 1 | 05 |
|    | INJECTORS - SAGEM                      | 1 | 04 |
|    | INTAKE MANIFOLD - SAGEM                | 1 | 03 |



Illus Part Number

Description

Quantity

Change  
Point

Remarks

|    |            |                                              |   |  |  |
|----|------------|----------------------------------------------|---|--|--|
| 1  | 074 04 006 | Regulator-injector-injector-Magneti Marelli- | 1 |  |  |
| 2  | 058 05 012 | Fixing Clip.-swivel                          | 1 |  |  |
| 3  | 108 16 001 | Hose.-vacuum union                           | 1 |  |  |
| 4  | 013 01 005 | Injector-Magneti Marelli                     | 4 |  |  |
| 5  | 025 18 001 | Clip.-injector                               | 2 |  |  |
| 6  | 017 27 001 | Seal.-Magneti Marelli                        | 1 |  |  |
| 70 | 040 02 042 | Screw.-M6 x 100-12                           | 2 |  |  |

ZJ0008

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ENGINE CONTROLS ..... 1. | 12  
ACCELERATOR CABLE AND PEDAL ..... 1. | 12  
EXHAUST ..... 1. | 09  
EXHAUST HEAT SHIELDS ..... 1. | 11  
MANIFOLD/DOWN PIPE/INTERMEDIATE ..... 1. | 09  
REAR EXHAUST ..... 1. | 10  
FUEL ..... 1. | 02  
AIR FILTER, AIR HOSE AIR RESONATOR, NO ..... 1. | 02  
AIR FILTER, AIR HOSE, AIR RESONATOR ..... 1. | 02  
FUEL FILLER NO FUME RECOVERY ..... 1. | 07  
FUEL FILLER WITH PETRO FUME ..... 1. | 08  
FUEL PIPES AND CLIPS ..... 1. | 08  
FUEL TANK ..... 1. | 06  
INJECTOR CALCULATOR - SAGEM ..... 1. | 05  
INJECTORS - SAGEM ..... 1. | 04  
INTAKE MANIFOLD - SAGEM ..... 1. | 03


illus Part Number

|    |            |
|----|------------|
| 6  | 075 09 002 |
| 8  | 092 05 001 |
| 9  | 181 59 003 |
| 10 | 092 06 001 |
| 11 | 092 01 019 |
| 12 | 108 13 001 |
| 13 | 231 01 003 |
| 14 | 092 02 002 |
| 72 | 040 25 004 |
| 73 | 186 01 001 |
| 74 | 174 03 060 |
| 75 | 040 22 004 |
| 76 | 174 04 051 |
| 77 | 040 02 042 |
| 78 | 025 02 081 |

Description

Quantity Change  
Point Remarks

|                                     |   |
|-------------------------------------|---|
| Relay.-injection feed + fuel pump   | 1 |
| Sensor.-pressure-SAGEMh             | 1 |
| Bracket.-sensor                     | 1 |
| Sensor.-engine speed                | 1 |
| Sensor.-temperature-probe           | 1 |
| Hose.-vacuum union                  | 1 |
| Potentiometer.-SAGEM                | 1 |
| Sensor.-temperature                 | 1 |
| Screw.-caged-M6 x 100-12            | 1 |
| Washer.-plain.-6 x 12               | 1 |
| Nut.-hexagonal-6 x 100              | 1 |
| Screw.-shouldered-M6 x 100-20-Bosch | 1 |
| Nut.-flange-6 x 100                 | 3 |
| Screw.-M6 x 100-12                  | 1 |
| Clip.-swivel                        | 2 |



## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                        |   |    |
|----------------------------------------|---|----|
| ENGINE CONTROLS                        | 1 | 12 |
| ACCELERATOR CABLE AND PEDAL            | 1 | 12 |
| EXHAUST                                | 1 | 09 |
| EXHAUST HEAT SHIELDS                   | 1 | 11 |
| MANIFOLD/DOWN PIPE/INTERMEDIATE        | 1 | 09 |
| REAR EXHAUST                           | 1 | 10 |
| FUEL                                   | 1 | 02 |
| AIR FILTER, AIR HOSE AIR RESONATOR, NO | 1 | 02 |
| AIR FILTER, AIR HOSE, AIR RESONATOR    | 1 | 02 |
| FUEL FILLER NO FUME RECOVERY           | 1 | 07 |
| FUEL FILLER WITH PETRO FUME            | 1 | 08 |
| FUEL PIPES AND CLIPS                   | 1 | 08 |
| FUEL TANK                              | 1 | 06 |
| INJECTOR CALCULATOR - SAGEM            | 1 | 05 |
| INJECTORS - SAGEM                      | 1 | 04 |
| INTAKE MANIFOLD - SAGEM                | 1 | 03 |


## Illus Part Number

## Description

## Quantity


## Change Point

## Remarks



|    |     |    |     |
|----|-----|----|-----|
| 2  | 021 | 01 | 006 |
| 3  | 181 | 38 | 002 |
| 4  | 181 | 38 | 003 |
| 6  | 158 | 02 | 006 |
| 7  | 080 | 05 | 002 |
| 8  | 186 | 03 | 038 |
| 10 | 094 | 17 | 001 |
| 11 | 181 | 59 | 006 |
| 71 | 025 | 02 | 008 |
| 72 | 025 | 01 | 109 |
| 73 | 174 | 04 | 022 |

|                                |   |
|--------------------------------|---|
| Fuel Tank.-fuel                | 1 |
| Bracket.-fuel-tank-assembly-LH | 1 |
| Bracket.-fuel-tank-assembly-RH | 1 |
| Fluid Gauge                    | 1 |
| Ring.-tank                     | 1 |
| Washer.-tank                   | 1 |
| Switch.-contact-inertia        | 1 |
| Bracket.-switch-inertia-switch | 1 |
| Clip                           | 2 |
| Clip.-cable-24mm diameter      | 2 |
| Nut.-M5 x 80-6-15              | 2 |



ZJ0015

## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                        |   |    |
|----|----------------------------------------|---|----|
| 1C | ENGINE CONTROLS                        | 1 | 12 |
| 1D | ACCELERATOR CABLE AND PEDAL            | 1 | 12 |
| 1E | EXHAUST                                | 1 | 09 |
| 1F | EXHAUST HEAT SHIELDS                   | 1 | 11 |
| 1G | MANIFOLD/DOWN PIPE/INTERMEDIATE        | 1 | 09 |
| 1H | REAR EXHAUST                           | 1 | 10 |
| 1I | FUEL                                   | 1 | 02 |
| 1J | AIR FILTER, AIR HOSE AIR RESONATOR, NO | 1 | 02 |
| 1K | AIR FILTER, AIR HOSE, AIR RESONATOR    | 1 | 02 |
| 2C | FUEL FILLER NO FUME RECOVERY           | 1 | 07 |
| 2F | FUEL FILLER WITH PETRO FUME            | 1 | 08 |
| 2H | FUEL PIPES AND CLIPS                   | 1 | 08 |
| 2I | FUEL TANK                              | 1 | 06 |
|    | INJECTOR CALCULATOR - SAGEM            | 1 | 05 |
|    | INJECTORS - SAGEM                      | 1 | 04 |
|    | INTAKE MANIFOLD - SAGEM                | 1 | 03 |

# SAMAND

107

Fiche 1

## FUEL, EXHAUST AND EMISSION SYSTEM

### FUEL

#### FUEL FILLER NO FUME RECOVERY


Illus Part Number

Description

Quantity


Change Point

Remarks



|    |     |    |     |
|----|-----|----|-----|
| 1  | 166 | 06 | 011 |
| 3  | 108 | 04 | 023 |
| 5  | 186 | 20 | 001 |
| 6  | 108 | 04 | 001 |
| 8  | 166 | 06 | 013 |
| 9  | 166 | 06 | 014 |
| 10 | 108 | 04 | 026 |
| 11 | 166 | 06 | 009 |
| 12 | 108 | 04 | 044 |
| 13 | 108 | 04 | 027 |
| 70 | 025 | 03 | 018 |
| 71 | 025 | 08 | 008 |
| 72 | 025 | 03 | 032 |
| 73 | 025 | 08 | 009 |
| 74 | 058 | 27 | 008 |
| 75 | 025 | 02 | 017 |
| 76 | 025 | 07 | 018 |
| 77 | 025 | 07 | 011 |
| 78 | 174 | 04 | 005 |
| 79 | 025 | 03 | 021 |
| 80 | 186 | 01 | 168 |
| 81 | 040 | 02 | 039 |

|                                          |   |
|------------------------------------------|---|
| Pipe.-filler without reducer .....       | 1 |
| Hose.-filler.....                        | 1 |
| Washer.-fuel pipe .....                  | 1 |
| Hose.-degassing -L=1000 .....            | 1 |
| Pipe.-venting-5.4 X 7.14 .....           | 1 |
| Pipe.-6 X 8 .....                        | 1 |
| Hose.-recycling-8 X 8 .....              | 2 |
| Pipe.-venting-diameter 6 x 8 .....       | 3 |
| Hose.-6 X 8 .....                        | 2 |
| Hose.-fuel return .....                  | 1 |
| Clip.-metal .....                        | 1 |
| Clip.-metal-6-13,5 L = 6 .....           | 1 |
| Clip.-metal-diameter 8-16 larg 9,5 ..... | 4 |
| Clip.-metal-diameter 5-13 L = 6 .....    | 2 |
| Fixing Clip.-8 x 6-2,8 .....             | 1 |
| Clip.-diameter 7-8 .....                 | 1 |
| Clip.-L=427 LARG=8 .....                 | 4 |
| Clip.-L=275, w=5 .....                   | 2 |
| Nut.-M6 x 100 .....                      | 1 |
| Clip.-metal-diameter 50-70 .....         | 2 |
| Washer.-seal-4 X 10-08 .....             | 2 |
| Screw.-4.8-19 .....                      | 2 |



## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                              |   |    |
|----|----------------------------------------------|---|----|
| 1C | ENGINE CONTROLS .....                        | 1 | 12 |
| 1D | ACCELERATOR CABLE AND PEDAL .....            | 1 | 12 |
| 1E | EXHAUST .....                                | 1 | 09 |
| 1F | EXHAUST HEAT SHIELDS .....                   | 1 | 11 |
| 1G | MANIFOLD/DOWN PIPE/INTERMEDIATE .....        | 1 | 09 |
| 1H | REAR EXHAUST .....                           | 1 | 10 |
| 1I | FUEL .....                                   | 1 | 02 |
| 1J | AIR FILTER, AIR HOSE AIR RESONATOR, NO ..... | 1 | 02 |
| 1K | AIR FILTER, AIR HOSE, AIR RESONATOR .....    | 1 | 02 |
| 2C | FUEL FILLER NO FUME RECOVERY .....           | 1 | 07 |
| 2F | FUEL FILLER WITH PETRO FUME .....            | 1 | 08 |
| 2H | FUEL PIPES AND CLIPS .....                   | 1 | 08 |
| 2I | FUEL TANK .....                              | 1 | 06 |
|    | INJECTOR CALCULATOR - SAGEM .....            | 1 | 05 |
|    | INJECTORS - SAGEM .....                      | 1 | 04 |
|    | INTAKE MANIFOLD - SAGEM .....                | 1 | 03 |



# SAMAND

108

## FUEL, EXHAUST AND EMISSION SYSTEM

Fiche 1

### FUEL FUEL PIPES AND CLIPS



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 166 | 06 | 016 |
| 2  | 166 | 06 | 017 |
| 3  | 166 | 06 | 015 |
| 4  | 108 | 04 | 027 |
| 5  | 166 | 02 | 013 |
| 6  | 108 | 04 | 004 |
| 7  | 108 | 04 | 005 |
| 9  | 108 | 04 | 010 |
| 10 | 108 | 04 | 017 |
| 11 | 108 | 04 | 018 |
| 12 | 108 | 04 | 019 |
| 15 | 036 | 03 | 012 |
| 16 | 124 | 01 | 004 |
| 17 | 181 | 26 | 039 |
| 18 | 025 | 02 | 078 |
| 19 | 025 | 01 | 103 |
| 20 | 025 | 01 | 102 |
| 21 | 025 | 01 | 060 |
| 22 | 025 | 02 | 087 |
| 23 | 025 | 02 | 085 |
| 24 | 025 | 02 | 086 |
| 27 | 221 | 05 | 001 |
| 71 | 174 | 04 | 051 |
| 72 | 025 | 03 | 031 |
| 73 | 025 | 03 | 018 |
| 74 | 025 | 02 | 088 |
| 75 | 025 | 01 | 110 |
| 80 | 025 | 02 | 092 |

Description

|                                       |    |
|---------------------------------------|----|
| Pipe.-fuel feed.....                  | 1  |
| Pipe.-fuel feed.....                  | 1  |
| Pipe.-fuel feed.....                  | 1  |
| Hose.-fuel return.....                | 1  |
| Pipe.-L = 55-very cold countries..... | 1  |
| Hose.-Dia. 11.....                    | 1  |
| Hose.....                             | 1  |
| Hose.-7 x 13.....                     | 1  |
| Hose.....                             | 1  |
| Hose.....                             | 1  |
| Hose.....                             | 1  |
| Pump.-petrol.....                     | 1  |
| Filter.-element-petrol.....           | 1  |
| Bracket.....                          | 1  |
| Clip.-16-18 X 4,7.....                | 1  |
| Clip.....                             | 1  |
| Clip.....                             | 1  |
| Clip.....                             | 5  |
| Clip.-swivel.....                     | 2  |
| Clip.....                             | 3  |
| Clip.....                             | 1  |
| Socket Tool.-socket.....              | 1  |
| Nut.-flange-6 x 100.....              | 1  |
| Clip.-metal.....                      | 11 |
| Clip.-metal.....                      | 5  |
| Clip.-16-18 X 4,8.....                | 1  |
| Clip.-16-18 X 4,7.....                | 1  |
| Clip.....                             | 1  |

Quantity

Change Point

Remarks

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                             |   |    |
|---------------------------------------------|---|----|
| ENGINE CONTROLS.....                        | 1 | 12 |
| ACCELERATOR CABLE AND PEDAL.....            | 1 | 12 |
| EXHAUST.....                                | 1 | 09 |
| EXHAUST HEAT SHIELDS.....                   | 1 | 11 |
| MANIFOLD/DOWN PIPE/INTERMEDIATE.....        | 1 | 09 |
| REAR EXHAUST.....                           | 1 | 10 |
| FUEL.....                                   | 1 | 02 |
| AIR FILTER, AIR HOSE AIR RESONATOR, NO..... | 1 | 02 |
| AIR FILTER, AIR HOSE, AIR RESONATOR.....    | 1 | 02 |
| FUEL FILLER NO FUME RECOVERY.....           | 1 | 07 |
| FUEL FILLER WITH PETRO FUME.....            | 1 | 08 |
| FUEL PIPES AND CLIPS.....                   | 1 | 08 |
| FUEL TANK.....                              | 1 | 06 |
| INJECTOR CALCULATOR - SAGEM.....            | 1 | 05 |
| INJECTORS - SAGEM.....                      | 1 | 04 |
| INTAKE MANIFOLD - SAGEM.....                | 1 | 03 |



# SAMAND

109

Fiche 1

## FUEL, EXHAUST AND EMISSION SYSTEM

### EXHAUST

#### MANIFOLD/DOWN PIPE/INTERMEDIATE



Illus Part Number

Description

Quantity

Change Point

Remarks



|    |     |    |     |
|----|-----|----|-----|
| 1  | 166 | 04 | 007 |
| 2  | 163 | 18 | 003 |
| 3  | 186 | 08 | 017 |
| 4  | 172 | 02 | 026 |
| 5  | 025 | 04 | 011 |
| 6  | 025 | 06 | 001 |
| 7  | 181 | 39 | 006 |
| 15 | 167 | 02 | 001 |
| 16 | 040 | 03 | 020 |
| 17 | 174 | 03 | 001 |
| 18 | 114 | 01 | 003 |
| 19 | 030 | 22 | 011 |
| 20 | 030 | 22 | 028 |
| 70 | 174 | 02 | 001 |
| 71 | 040 | 01 | 277 |
| 72 | 174 | 04 | 036 |
| 73 | 040 | 01 | 178 |
| 74 | 040 | 01 | 276 |
| 75 | 186 | 01 | 001 |


|                                                |   |
|------------------------------------------------|---|
| Pipe.-non catalyst-down pipe.....              | 1 |
| Kit.-exhaust olive-assembly-front.....         | 1 |
| Washer.-manifold to downpipe.....              | 2 |
| Reservoir.-intermediate .....                  | 1 |
| Clip.-exhaust-rubber .....                     | 2 |
| Clip.-half.....                                | 1 |
| Bracket.-exhaust support.....                  | 1 |
| Manifold.-exhaust.....                         | 1 |
| Screw.-manifold heatshield-8 X 125 .....       | 8 |
| Nut.-flange-M8 x 125 .....                     | 8 |
| Shield.-manifold.....                          | 1 |
| Bush.-manifold-6 x 13-48.....                  | 1 |
| Bush.-manifold-6 x 13-20.....                  | 1 |
| Nut.-self locking-M6 x 100 .....               | 2 |
| Screw.-exhaust clamp-M8 x 125-35.....          | 2 |
| Nut.-exhaust clamp-flange-M8.....              | 2 |
| Screw.-heatshield to manifold-M6 x 100-60..... | 1 |
| Screw.-heatshield to manifold-M6 x 100-35..... | 1 |
| Washer.-plain...-6 x 12.....                   | 2 |

## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                              |   |    |
|----|----------------------------------------------|---|----|
| 1C | ENGINE CONTROLS .....                        | 1 | 12 |
| 1D | ACCELERATOR CABLE AND PEDAL.....             | 1 | 12 |
| 1E | EXHAUST .....                                | 1 | 09 |
| 1F | EXHAUST HEAT SHIELDS.....                    | 1 | 11 |
| 1G | MANIFOLD/DOWN PIPE/INTERMEDIATE.....         | 1 | 09 |
| 1H | REAR EXHAUST .....                           | 1 | 10 |
| 1I | FUEL.....                                    | 1 | 02 |
| 1J | AIR FILTER, AIR HOSE AIR RESONATOR, NO ..... | 1 | 02 |
| 1K | AIR FILTER, AIR HOSE, AIR RESONATOR.....     | 1 | 02 |
| 2C | FUEL FILLER NO FUME RECOVERY .....           | 1 | 07 |
| 2F | FUEL FILLER WITH PETRO FUME .....            | 1 | 08 |
| 2H | FUEL PIPES AND CLIPS .....                   | 1 | 08 |
| 2I | FUEL TANK.....                               | 1 | 06 |
|    | INJECTOR CALCULATOR - SAGEM.....             | 1 | 05 |
|    | INJECTORS - SAGEM .....                      | 1 | 04 |
|    | INTAKE MANIFOLD - SAGEM.....                 | 1 | 03 |



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 172 | 02 | 006 |
| 4  | 163 | 18 | 004 |
| 2  | 025 | 06 | 001 |
| 3  | 025 | 04 | 010 |
| 70 | 040 | 01 | 277 |
| 71 | 174 | 04 | 036 |


## Description

|                                  |   |
|----------------------------------|---|
| Reservoir.-rear.....             | 1 |
| KIT.-ASSEMBLY-REAR SILENCER..... | 1 |
| • Clip.....                      | 2 |
| • Clip.-rubber.....              | 2 |
| • Screw.-M8 x 125-35.....        | 2 |
| • Nut.-flange-M8.....            | 2 |

## Quantity

## Change Point

## Remarks



ZK0005

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                             |   |    |
|---------------------------------------------|---|----|
| ENGINE CONTROLS.....                        | 1 | 12 |
| ACCELERATOR CABLE AND PEDAL.....            | 1 | 12 |
| EXHAUST.....                                | 1 | 09 |
| EXHAUST HEAT SHIELDS.....                   | 1 | 11 |
| MANIFOLD/DOWN PIPE/INTERMEDIATE.....        | 1 | 09 |
| REAR EXHAUST.....                           | 1 | 10 |
| FUEL.....                                   | 1 | 02 |
| AIR FILTER, AIR HOSE AIR RESONATOR, NO..... | 1 | 02 |
| AIR FILTER, AIR HOSE, AIR RESONATOR.....    | 1 | 02 |
| FUEL FILLER NO FUME RECOVERY.....           | 1 | 07 |
| FUEL FILLER WITH PETRO FUME.....            | 1 | 08 |
| FUEL PIPES AND CLIPS.....                   | 1 | 08 |
| FUEL TANK.....                              | 1 | 06 |
| INJECTOR CALCULATOR - SAGEM.....            | 1 | 05 |
| INJECTORS - SAGEM.....                      | 1 | 04 |
| INTAKE MANIFOLD - SAGEM.....                | 1 | 03 |

# SAMAND

111

## FUEL, EXHAUST AND EMISSION SYSTEM

Fiche 1

### EXHAUST

#### EXHAUST HEAT SHIELDS

Illus Part Number

Description


Quantity

Change Point

Remarks

|    |     |    |     |
|----|-----|----|-----|
| 1  | 114 | 01 | 001 |
| 3  | 181 | 38 | 004 |
| 5  | 114 | 01 | 021 |
| 6  | 025 | 01 | 058 |
| 7  | 114 | 01 | 024 |
| 10 | 114 | 01 | 004 |
| 70 | 174 | 04 | 004 |
| 71 | 040 | 01 | 013 |
| 73 | 174 | 04 | 046 |
| 74 | 174 | 04 | 012 |

|                                                   |   |  |  |
|---------------------------------------------------|---|--|--|
| Shield.-heat.....                                 | 1 |  |  |
| Bracket.-heat-tailpipe.....                       | 1 |  |  |
| Shield.-spare wheel well.....                     | 1 |  |  |
| Clip.-fastening.....                              | 4 |  |  |
| Shield.....                                       | 1 |  |  |
| Shield.-heat-manifold.....                        | 1 |  |  |
| Nut.-with washer-M6-manifold-lower.....           | 3 |  |  |
| Screw.-M6 X 100 L20 STL DAC500A.....              | 2 |  |  |
| Nut.-with washer-M6 x 100-heatshield to body..... | 8 |  |  |
| Nut.-flanged head-M8 x 125.....                   | 1 |  |  |





### MASTER INDEX

### GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                             |   |    |
|----|---------------------------------------------|---|----|
| 1C | ENGINE CONTROLS.....                        | 1 | 12 |
| 1D | ACCELERATOR CABLE AND PEDAL.....            | 1 | 12 |
| 1E | EXHAUST.....                                | 1 | 09 |
| 1F | EXHAUST HEAT SHIELDS.....                   | 1 | 11 |
| 1G | MANIFOLD/DOWN PIPE/INTERMEDIATE.....        | 1 | 09 |
| 1H | REAR EXHAUST.....                           | 1 | 10 |
| 1I | FUEL.....                                   | 1 | 02 |
| 1J | AIR FILTER, AIR HOSE AIR RESONATOR, NO..... | 1 | 02 |
| 1K | AIR FILTER, AIR HOSE, AIR RESONATOR.....    | 1 | 02 |
| 2C | FUEL FILLER NO FUME RECOVERY.....           | 1 | 07 |
| 2F | FUEL FILLER WITH PETRO FUME.....            | 1 | 08 |
| 2H | FUEL PIPES AND CLIPS.....                   | 1 | 08 |
| 2I | FUEL TANK.....                              | 1 | 06 |
|    | INJECTOR CALCULATOR - SAGEM.....            | 1 | 05 |
|    | INJECTORS - SAGEM.....                      | 1 | 04 |
|    | INTAKE MANIFOLD - SAGEM.....                | 1 | 03 |



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 032 | 03 | 005 |
| 3  | 061 | 31 | 002 |
| 4  | 138 | 07 | 006 |
| 5  | 058 | 05 | 001 |
| 7  | 205 | 02 | 037 |
| 8  | 015 | 06 | 004 |
| 9  | 038 | 13 | 006 |
| 10 | 121 | 09 | 010 |
| 11 | 178 | 12 | 001 |
| 70 | 040 | 05 | 002 |
| 71 | 186 | 01 | 105 |
| 72 | 042 | 08 | 004 |

## Description

|                                  |   |
|----------------------------------|---|
| Pedal Assy.-accelerator .....    | 1 |
| Protectors.-half .....           | 1 |
| Control Cable .....              | 1 |
| Fixing Clip.-retaining .....     | 1 |
| Grommet.-diameter int. 12.6..... | 1 |
| Lever.-accelerator control ..... | 1 |
| Block & pipe.....                | 1 |
| Spring.-cable.....               | 1 |
| Link.-accelerator drum .....     | 1 |
| Screw.-4.5 x 20 .....            | 2 |
| Washer.-M14 .....                | 1 |
| Dowel.-accelerator cable .....   | 1 |

## Quantity

## Change Point

## Remarks

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                              |   |    |
|----------------------------------------------|---|----|
| ENGINE CONTROLS .....                        | 1 | 12 |
| ACCELERATOR CABLE AND PEDAL .....            | 1 | 12 |
| EXHAUST .....                                | 1 | 09 |
| EXHAUST HEAT SHIELDS .....                   | 1 | 11 |
| MANIFOLD/DOWN PIPE/INTERMEDIATE .....        | 1 | 09 |
| REAR EXHAUST .....                           | 1 | 10 |
| FUEL .....                                   | 1 | 02 |
| AIR FILTER, AIR HOSE AIR RESONATOR, NO ..... | 1 | 02 |
| AIR FILTER, AIR HOSE, AIR RESONATOR .....    | 1 | 02 |
| FUEL FILLER NO FUME RECOVERY .....           | 1 | 07 |
| FUEL FILLER WITH PETRO FUME .....            | 1 | 08 |
| FUEL PIPES AND CLIPS .....                   | 1 | 08 |
| FUEL TANK .....                              | 1 | 06 |
| INJECTOR CALCULATOR - SAGEM .....            | 1 | 05 |
| INJECTORS - SAGEM .....                      | 1 | 04 |
| INTAKE MANIFOLD - SAGEM .....                | 1 | 03 |



## Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 016 | 01 | 002 |
| 2 | 096 | 06 | 002 |
| 3 | 108 | 06 | 025 |
| 4 | 205 | 02 | 035 |
| 5 | 181 | 26 | 024 |
| 6 | 040 | 03 | 023 |


## Description

|                                                     |   |
|-----------------------------------------------------|---|
| EVAPORATOR.-R134-VALEO-WITH ATC.....                | 1 |
| • Valve.-pressure relief-with ATC-Valeo .....       | 1 |
| Hose.-evacuation-with ATC-Valeo .....               | 1 |
| Grommet.-Valeo-with ATC .....                       | 1 |
| Bracket.-pressure relief valve-with ATC-Valeo ..... | 1 |
| Screw.-pressure relief valve-with ATC-Valeo .....   | 1 |

## Quantity

## Change Point

## Remarks



ZL0013

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |

## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 074 | 06 | 001 |
| 2  | 043 | 04 | 003 |
| 3  | 092 | 14 | 003 |
| 4  | 092 | 14 | 002 |
| 70 | 040 | 14 | 078 |



## Description

|                                               |   |
|-----------------------------------------------|---|
| Regulator.-with ATC-Valeo.....                | 1 |
| Thermostat.-less harness-Blue.-less ATC ..... | 1 |
| Sensor.-evaporator-with ATC-Valeo .....       | 1 |
| Sensor. ....                                  | 1 |
| Screw.-RLX 4,5 - 12.....                      | 1 |

## Quantity

## Change Point

## Remarks



ZL0014

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 108 | 06 | 026 |
| 2  | 108 | 06 | 027 |
| 3  | 108 | 06 | 028 |
| 4  | 181 | 26 | 040 |
| 5  | 181 | 26 | 038 |
| 6  | 040 | 01 | 289 |
| 7  | 174 | 07 | 032 |
| 8  | 186 | 01 | 182 |
| 9  | 205 | 02 | 038 |
| 10 | 017 | 01 | 009 |
| 11 | 017 | 01 | 010 |


## Description

## Quantity

## Change Point

## Remarks

|                                                      |   |  |  |
|------------------------------------------------------|---|--|--|
| Hose.-freon air con .....                            | 1 |  |  |
| Hose.-freon air con .....                            | 1 |  |  |
| Hose.-freon air con .....                            | 1 |  |  |
| Bracket.....                                         | 1 |  |  |
| Bracket.-assembly-LHD .....                          | 2 |  |  |
| Screw.....                                           | 2 |  |  |
| Nut.....                                             | 1 |  |  |
| Washer.....                                          | 2 |  |  |
| Grommet.-diameter interior = 68,5 thickness = 12 ... | 1 |  |  |
| Seal.-interior = 13,5 .....                          | 1 |  |  |
| Seal.-interior = 16,5 .....                          | 1 |  |  |



ZL0016

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL.....       | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES.....                | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING.....       | 1. J 11 |
| HEATER.....                       | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET.....                   | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |

# SAMAND

J05

Fiche 1

COOLING, HEATING AND AIR CONDITIONING

AIR CONDITIONING  
COMPRESSOR-PETROL

Illus Part Number

1 148 02 001  
2 030 29 003  
4 163 07 002  
5 147 01 001  
70 040 01 275  
71 186 01 170  
72 186 03 081  
73 174 03 070





Description

Air Con Compressor.-Sanden..... 1  
Bush.-centralising-16 x 25.5..... 4  
Kit.-compressor-Sanden..... 1  
Compressor Clutch.-pulley-Sanden..... 1  
Screw.-cap head-M10 x 150-55..... 4  
Washer.-plain-M10 x 20-2..... 8  
Washer.-flexible-M10 x 21.3-1..... 4  
Nut.-self locking-14 x 150..... 4

Quantity

Change Point

Remarks



ZL0015


## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

AIR CONDITIONING ..... 1. J 02  
COMPRESSOR-PETROL ..... 1. J 05  
CONDENSER ..... 1. J 06  
EVAPORATOR ..... 1. J 02  
PIPES AND HOSES-PETROL ..... 1. J 04  
COOLING ..... 1. J 07  
COOLING FAN ..... 1. J 08  
COOLING HOSES ..... 1. J 10  
COOLING RADIATOR ..... 1. J 09  
RADIATOR AND FAN SUPPORT ..... 1. J 07  
THERMOSTAT AND HOUSING ..... 1. J 11  
HEATER ..... 1. J 12  
AIR INTAKE ..... 1. J 12  
AIR INTAKE AIR CONDITIONING ..... 1. J 13  
AIR OUTLET ..... 1. J 14  
HEATER AIR CONDITIONING ..... 1. J 15  
HEATER CONTROL ..... 1. J 17  
HEATER HOSES ..... 1. J 16



Il.us Part Number


1 151 01 007  
2 224 01 003  
3 181 81 002  
6 111 11 002  
71 040 22 044

Description

Condenser.  
Dryer.-with harness  
Bracket.  
Buffer.-26mm-rubber  
Screw.-M6 x 100-20

Quantity Change  
Point Remarks

1  
1  
1  
2  
2



ZL0017

MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX

AIR CONDITIONING ..... 1. J 02  
COMPRESSOR-PETROL ..... 1. J 05  
CONDENSER ..... 1. J 06  
EVAPORATOR ..... 1. J 02  
PIPES AND HOSES-PETROL ..... 1. J 04  
COOLING ..... 1. J 07  
COOLING FAN ..... 1. J 08  
COOLING HOSES ..... 1. J 10  
COOLING RADIATOR ..... 1. J 09  
RADIATOR AND FAN SUPPORT ..... 1. J 07  
THERMOSTAT AND HOUSING ..... 1. J 11  
HEATER ..... 1. J 12  
AIR INTAKE ..... 1. J 12  
AIR INTAKE AIR CONDITIONING ..... 1. J 13  
AIR OUTLET ..... 1. J 14  
HEATER AIR CONDITIONING ..... 1. J 15  
HEATER CONTROL ..... 1. J 17  
HEATER HOSES ..... 1. J 16

## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 133 | 02 | 011 |
| 2  | 040 | 01 | 009 |
| 3  | 128 | 04 | 043 |
| 70 | 040 | 22 | 055 |



## Description

|                                                   |   |
|---------------------------------------------------|---|
| Assembly.-radiator support-twin-blower assy ..... | 1 |
| Screw.-crossmember-M8 x 125-20-shouldered .....   | 2 |
| Panel.-radiator support .....                     | 1 |
| Screw.-crossmember-M8 x 125-30 .....              | 2 |

## Quantity

## Change Point

## Remarks



ZL0026

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |


# SAMAND

J08

Fiche 1

## COOLING, HEATING AND AIR CONDITIONING

### COOLING COOLING FAN



Illus Part Number

Description

Quantity

Change  
Point

Remarks

1 101 01 007

Motor.-200w

2

1 101 01 005

Motor.-200w Ecia699

2

2 033 02 010

Cooling Fan.-blade engine cooling-200w-9 blade

2

4 092 01 007

Sensor.-temperature-Blue.

1

4 092 01 013

Sensor.-temperature

1

5 017 02 005

Seal.-housing

1

6 040 09 013

Screw.-radiator and fan-22 x 150

1

9 075 04 004

Relay.-electric fan

3

11 209 02 001

Control Unit.-temperature 96/118 bitron

1

13 058 01 036

Fixing Clip.

2

20 126 02 005

Deflector-radiator

1

70 040 14 014

Screw.-flanged-M6 x 100-22-inner

6

72 040 25 002

Screw.-caged-5 x 80

2

73 174 04 037

Nut.-flange-5 x 80

2

75 040 14 036

Screw.-cap head-M4 x 70-10-LH

2

76 186 02 041

Washer.-spring.-4 x 11.2

2

80 025 02 029

Clip.-harness-17 x 14

5

81 025 11 002

Clip.-6.2mm-rear-harness

3

82 025 02 022

Clip.-8mm diameter

4

#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

AIR CONDITIONING ..... 1. J 02  
COMPRESSOR-PETROL ..... 1. J 05  
CONDENSER ..... 1. J 06  
EVAPORATOR ..... 1. J 02  
PIPES AND HOSES-PETROL ..... 1. J 04  
COOLING ..... 1. J 07  
COOLING FAN ..... 1. J 08  
COOLING HOSES ..... 1. J 10  
COOLING RADIATOR ..... 1. J 09  
RADIATOR AND FAN SUPPORT ..... 1. J 07  
THERMOSTAT AND HOUSING ..... 1. J 11  
HEATER ..... 1. J 12  
AIR INTAKE ..... 1. J 12  
AIR INTAKE AIR CONDITIONING ..... 1. J 13  
AIR OUTLET ..... 1. J 14  
HEATER AIR CONDITIONING ..... 1. J 15  
HEATER CONTROL ..... 1. J 17  
HEATER HOSES ..... 1. J 16

# SAMAND

J09

COOLING, HEATING AND AIR CONDITIONING

Fiche 1

COOLING  
COOLING RADIATOR

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 072 | 01 | 001 |
| 3  | 170 | 05 | 008 |
| 4  | 121 | 10 | 002 |
| 5  | 111 | 11 | 002 |
| 6  | 092 | 11 | 001 |
| 7  | 038 | 17 | 001 |
| 8  | 106 | 03 | 003 |
| 10 | 106 | 03 | 004 |


Description

|                                        |   |
|----------------------------------------|---|
| Radiator.-new.....                     | 1 |
| Plug/Cover.-radiator-1.4 BAR .....     | 1 |
| Spring.....                            | 2 |
| Buffer.-26mm-rubber.....               | 2 |
| Sensor.-fluid level .....              | 1 |
| Block & pipe-drain-14mm diameter ..... | 1 |
| Converter.....                         | 1 |
| Converter-16mm diameter.....           | 1 |

Quantity

Change Point

Remarks



ZL0004


## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 108 | 03 | 055 |
| 2  | 108 | 03 | 038 |
| 5  | 186 | 09 | 039 |
| 6  | 186 | 03 | 031 |
| 7  | 025 | 07 | 008 |
| 9  | 025 | 14 | 002 |
| 11 | 040 | 12 | 005 |
| 12 | 061 | 24 | 001 |
| 13 | 061 | 04 | 002 |
| 70 | 025 | 03 | 020 |
| 71 | 025 | 03 | 029 |
| 72 | 025 | 03 | 018 |
| 75 | 174 | 04 | 005 |
| 76 | 040 | 25 | 004 |
| 79 | 025 | 07 | 018 |


## Description

|                                   |   |
|-----------------------------------|---|
| Hose.-water intake.....           | 1 |
| Hose.-water outlet.....           | 1 |
| Washer.-32mm diameter.....        | 2 |
| Washer.-12 mm.....                | 2 |
| Clip.-water outlet.....           | 2 |
| Clip.....                         | 1 |
| Screw.-drain.....                 | 1 |
| Cap.....                          | 1 |
| Cap.-23mm diameter-30mm long..... | 1 |
| Clip.-water outlet-metal.....     | 2 |
| Clip.-metal.....                  | 1 |
| Clip.-metal.....                  | 1 |
| Nut.-M6 x 100.....                | 1 |
| Screw.-caged-M6 x 100-12.....     | 1 |
| Clip.-L=427 LARG=8.....           | 1 |

## Quantity

## Change Point

## Remarks



ZL0003

## MASTER INDEX



ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                  |         |
|----------------------------------|---------|
| AIR CONDITIONING.....            | 1. J 02 |
| COMPRESSOR-PETROL.....           | 1. J 05 |
| CONDENSER.....                   | 1. J 06 |
| EVAPORATOR.....                  | 1. J 02 |
| PIPES AND HOSES-PETROL.....      | 1. J 04 |
| COOLING.....                     | 1. J 07 |
| COOLING FAN.....                 | 1. J 08 |
| COOLING HOSES.....               | 1. J 10 |
| COOLING RADIATOR.....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT.....    | 1. J 07 |
| THERMOSTAT AND HOUSING.....      | 1. J 11 |
| HEATER.....                      | 1. J 12 |
| AIR INTAKE.....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING..... | 1. J 13 |
| AIR OUTLET.....                  | 1. J 14 |
| HEATER AIR CONDITIONING.....     | 1. J 15 |
| HEATER CONTROL.....              | 1. J 17 |
| HEATER HOSES.....                | 1. J 16 |





## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 037 | 06 | 014 |
| 2  | 040 | 06 | 005 |
| 3  | 186 | 03 | 070 |
| 4  | 040 | 02 | 059 |
| 5  | 186 | 01 | 079 |
| 10 | 037 | 06 | 011 |
| 11 | 186 | 09 | 044 |
| 12 | 043 | 01 | 002 |
| 13 | 061 | 18 | 001 |
| 14 | 166 | 22 | 002 |
| 20 | 092 | 01 | 019 |
| 21 | 092 | 01 | 010 |
| 22 | 092 | 01 | 008 |
| 23 | 040 | 09 | 008 |
| 70 | 040 | 22 | 009 |
| 71 | 042 | 02 | 017 |
| 72 | 040 | 14 | 079 |
| 73 | 040 | 14 | 080 |

## Description

| Description                             | Quantity | Change Point | Remarks |
|-----------------------------------------|----------|--------------|---------|
| Housing Body.-water outlet.....         | 1        |              |         |
| Screw.-drain-thermostat housing.....    | 1        |              |         |
| Washer.-drain screw.....                | 1        |              |         |
| Screw.-socket head-M7 x 100-55.....     | 1        |              |         |
| Washer.-thermostat housing.....         | 1        |              |         |
| Housing Body.-thermostat housing.....   | 1        |              |         |
| Washer.-thermostat housing.....         | 1        |              |         |
| Thermostat.-82 degrees C.....           | 1        |              |         |
| Cap.-valve.....                         | 1        |              |         |
| Pipe.-water outlet.....                 | 1        |              |         |
| Sensor.-probe-probe.....                | 1        |              |         |
| Sensor.-temperature-110 deg-Jaeger..... | 1        |              |         |
| Sensor.-electricfil-14 x 125.....       | 1        |              |         |
| Screw.-14 x 125.....                    | 1        |              |         |
| Screw.-shouldered-M8 x 125-20.....      | 2        |              |         |
| Dowel.-10mm x 13mm.....                 | 2        |              |         |
| Screw.-shouldered-M7 x 100-40.....      | 3        |              |         |
| Screw.-M7 x 100-75.....                 | 3        |              |         |

ZL0021

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                  |         |
|----|----------------------------------|---------|
| 1C | AIR CONDITIONING.....            | 1. J 02 |
| 1D | COMPRESSOR-PETROL.....           | 1. J 05 |
| 1E | CONDENSER.....                   | 1. J 06 |
| 1F | EVAPORATOR.....                  | 1. J 02 |
| 1G | PIPES AND HOSES-PETROL.....      | 1. J 04 |
| 1H | COOLING.....                     | 1. J 07 |
| 1I | COOLING FAN.....                 | 1. J 08 |
| 1J | COOLING HOSES.....               | 1. J 10 |
| 1K | COOLING RADIATOR.....            | 1. J 09 |
| 2C | RADIATOR AND FAN SUPPORT.....    | 1. J 07 |
| 2F | THERMOSTAT AND HOUSING.....      | 1. J 11 |
| 2H | HEATER.....                      | 1. J 12 |
| 2I | AIR INTAKE.....                  | 1. J 12 |
|    | AIR INTAKE AIR CONDITIONING..... | 1. J 13 |
|    | AIR OUTLET.....                  | 1. J 14 |
|    | HEATER AIR CONDITIONING.....     | 1. J 15 |
|    | HEATER CONTROL.....              | 1. J 17 |
|    | HEATER HOSES.....                | 1. J 16 |

# SAMAND

J12

Fiche 1

COOLING, HEATING AND AIR CONDITIONING

HEATER

AIR INTAKE

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 103 | 06 | 004 |
| 2 | 182 | 02 | 011 |
| 3 | 025 | 21 | 001 |
| 4 | 040 | 05 | 002 |
| 5 | 058 | 15 | 013 |
| 6 | 126 | 21 | 004 |
| 7 | 058 | 15 | 015 |
| 8 | 040 | 05 | 040 |



Description

Quantity

Change Point

Remarks

|                                   |   |  |  |
|-----------------------------------|---|--|--|
| Grill.-air intake.....            | 1 |  |  |
| Rubber Seal.-air intake .....     | 1 |  |  |
| Clip.-plastic .....               | 4 |  |  |
| Screw.-4.5 x 20 .....             | 4 |  |  |
| Fixing Clip.-fastening-steel..... | 2 |  |  |
| Trim.-water-deflector .....       | 1 |  |  |
| Fixing Clip.-fastening .....      | 2 |  |  |
| Screw.-RLX5L 13.....              | 2 |  |  |



ZL0029A

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |

Illus Part Number

|    |            |
|----|------------|
| 1  | 101 02 005 |
| 2  | 196 02 002 |
| 4  | 051 06 002 |
| 5  | 126 27 003 |
| 6  | 126 24 001 |
| 7  | 124 03 022 |
| 8  | 124 03 006 |
| 70 | 040 22 036 |
| 71 | 174 12 005 |
| 72 | 174 04 035 |




Description

Quantity

Change Point

Remarks

|                                            |   |  |  |
|--------------------------------------------|---|--|--|
| Motor.-air intake-with ATC-Valeo .....     | 1 |  |  |
| Module.-heater module-with ATC-Valeo ..... | 1 |  |  |
| Adjusting Mechanism.-with ATC-Valeo .....  | 1 |  |  |
| Trim.-air channel -upper.....              | 1 |  |  |
| Trim.-air channel -lower .....             | 1 |  |  |
| Filter.-air intake .....                   | 1 |  |  |
| Filter.-pollen .....                       | 1 |  |  |
| Screw.-flanged-M6 x 100-35.....            | 2 |  |  |
| Nut.-caged-6 x 100 .....                   | 2 |  |  |
| Nut.-flange-6 x 100 .....                  | 1 |  |  |



MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |

# SAMAND

J14

Fiche 1

COOLING, HEATING AND AIR CONDITIONING

HEATER  
AIR OUTLET

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 230 | 01 | 009 |
| 2  | 230 | 01 | 010 |
| 3  | 230 | 01 | 011 |
| 5  | 062 | 03 | 005 |
| 6  | 062 | 01 | 010 |
| 7  | 062 | 02 | 009 |
| 8  | 058 | 05 | 011 |
| 10 | 040 | 14 | 019 |
| 12 | 174 | 02 | 015 |
| 20 | 103 | 06 | 005 |
| 21 | 103 | 06 | 006 |
| 22 | 062 | 01 | 011 |
| 23 | 062 | 02 | 010 |
| 24 | 181 | 45 | 004 |
| 25 | 156 | 16 | 003 |
| 26 | 156 | 16 | 004 |
| 27 | 156 | 17 | 001 |
| 28 | 230 | 01 | 014 |
| 29 | 230 | 01 | 015 |
| 30 | 186 | 03 | 082 |


Description

Quantity

Change Point

Remarks

|                                                |   |  |  |
|------------------------------------------------|---|--|--|
| Ducting.-centre .....                          | 1 |  |  |
| Ducting.-LH.....                               | 1 |  |  |
| Ducting.-RH.....                               | 1 |  |  |
| Air Vent.-centre .....                         | 1 |  |  |
| Air Vent.-LH .....                             | 1 |  |  |
| Air Vent.-RH.....                              | 1 |  |  |
| Fixing Clip.-clamping-top .....                | 2 |  |  |
| Screw.-4.2 x 13-front panel-lower .....        | 6 |  |  |
| Nut.-clamping.....                             | 2 |  |  |
| Grill.-screen demist-LH.....                   | 1 |  |  |
| Grill.-screen demist-RH.....                   | 1 |  |  |
| Air Vent.-side window demist-LH.....           | 1 |  |  |
| Air Vent.-side window demist-RH.....           | 1 |  |  |
| Bracket.-ducting adapter-lower .....           | 1 |  |  |
| Protector.-elbow ducting-dash air vent-LH..... | 1 |  |  |
| Protector.-elbow ducting-dash air vent-RH..... | 1 |  |  |
| Protector.-ducting adapter .....               | 1 |  |  |
| Protector.-ducting adapter .....               | 1 |  |  |
| Ducting.-ducting dash air vent-LH.....         | 1 |  |  |
| Ducting.-ducting dash air vent-RH.....         | 1 |  |  |
| Washer.-heater elbow.....                      | 2 |  |  |



ZL0023

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                  |         |
|----------------------------------|---------|
| AIR CONDITIONING .....           | 1. J 02 |
| COMPRESSOR-PETROL .....          | 1. J 05 |
| CONDENSER.....                   | 1. J 06 |
| EVAPORATOR.....                  | 1. J 02 |
| PIPES AND HOSES-PETROL.....      | 1. J 04 |
| COOLING.....                     | 1. J 07 |
| COOLING FAN .....                | 1. J 08 |
| COOLING HOSES.....               | 1. J 10 |
| COOLING RADIATOR .....           | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....   | 1. J 07 |
| THERMOSTAT AND HOUSING.....      | 1. J 11 |
| HEATER.....                      | 1. J 12 |
| AIR INTAKE .....                 | 1. J 12 |
| AIR INTAKE AIR CONDITIONING..... | 1. J 13 |
| AIR OUTLET.....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....    | 1. J 15 |
| HEATER CONTROL .....             | 1. J 17 |
| HEATER HOSES .....               | 1. J 16 |

# SAMAND


J15

Fiche 1

COOLING, HEATING AND AIR CONDITIONING

HEATER

HEATER AIR CONDITIONING



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 023 | 01 | 009 |
| 2  | 037 | 04 | 013 |
| 3  | 181 | 03 | 003 |
| 4  | 181 | 03 | 004 |
| 5  | 186 | 24 | 017 |
| 70 | 040 | 22 | 036 |
| 71 | 040 | 22 | 004 |
| 72 | 040 | 30 | 002 |
| 73 | 040 | 02 | 085 |
| 74 | 040 | 14 | 021 |
| 75 | 186 | 01 | 171 |
| 76 | 174 | 04 | 035 |


Description

Quantity

Change Point

Remarks

|                                                |   |  |  |
|------------------------------------------------|---|--|--|
| Housing.-heater assy-Valeo.....                | 1 |  |  |
| Housing Body.-blower assy-with ATC-Valeo ..... | 1 |  |  |
| Bracket.....                                   | 1 |  |  |
| Bracket.-heater assy.....                      | 1 |  |  |
| Washer.-heater assy-heater assy.....           | 1 |  |  |
| Screw.-flanged-M6 x 100-35.....                | 1 |  |  |
| Screw.-shouldered-M6 x 100-20.....             | 2 |  |  |
| Screw.-caged.....                              | 1 |  |  |
| Screw.-M6 x 100-30.....                        | 1 |  |  |
| Screw.-side-M6 x 100-16.....                   | 2 |  |  |
| Washer.-plain-6 x 34.....                      | 2 |  |  |
| Nut.-flange-6 x 100.....                       | 1 |  |  |



ZL0025

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                  |         |
|----------------------------------|---------|
| AIR CONDITIONING .....           | 1. J 02 |
| COMPRESSOR-PETROL .....          | 1. J 05 |
| CONDENSER.....                   | 1. J 06 |
| EVAPORATOR.....                  | 1. J 02 |
| PIPES AND HOSES-PETROL.....      | 1. J 04 |
| COOLING .....                    | 1. J 07 |
| COOLING FAN .....                | 1. J 08 |
| COOLING HOSES.....               | 1. J 10 |
| COOLING RADIATOR.....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....   | 1. J 07 |
| THERMOSTAT AND HOUSING .....     | 1. J 11 |
| HEATER.....                      | 1. J 12 |
| AIR INTAKE .....                 | 1. J 12 |
| AIR INTAKE AIR CONDITIONING..... | 1. J 13 |
| AIR OUTLET.....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....    | 1. J 15 |
| HEATER CONTROL .....             | 1. J 17 |
| HEATER HOSES .....               | 1. J 16 |


# SAMAND

J16

Fiche 1

COOLING, HEATING AND AIR CONDITIONING

HEATER  
HEATER HOSES



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 108 | 02 | 014 |
| 2  | 166 | 08 | 006 |
| 3  | 072 | 02 | 004 |
| 4  | 108 | 02 | 002 |
| 4  | 166 | 08 | 002 |
| 5  | 017 | 09 | 005 |
| 5  | 017 | 09 | 006 |
| 70 | 025 | 01 | 104 |
| 71 | 025 | 02 | 089 |


Description

|                                        |   |
|----------------------------------------|---|
| Hose.-heater assy.....                 | 1 |
| Pipe.-heater assy.....                 | 1 |
| Heating.-matrix .....                  | 1 |
| Hose.-heater assy-less ATC-Behr .....  | 1 |
| Pipe.-heater assy-with ATC-Valeo ..... | 1 |
| Seal.-heater assy.....                 | 2 |
| Seal.....                              | 2 |
| Clip.-30mm diameter-heater assy.....   | 1 |
| Clip.-swivel.....                      | 1 |

Quantity

Change Point

Remarks



## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                   |         |
|-----------------------------------|---------|
| AIR CONDITIONING .....            | 1. J 02 |
| COMPRESSOR-PETROL .....           | 1. J 05 |
| CONDENSER .....                   | 1. J 06 |
| EVAPORATOR .....                  | 1. J 02 |
| PIPES AND HOSES-PETROL .....      | 1. J 04 |
| COOLING .....                     | 1. J 07 |
| COOLING FAN .....                 | 1. J 08 |
| COOLING HOSES .....               | 1. J 10 |
| COOLING RADIATOR .....            | 1. J 09 |
| RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| THERMOSTAT AND HOUSING .....      | 1. J 11 |
| HEATER .....                      | 1. J 12 |
| AIR INTAKE .....                  | 1. J 12 |
| AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
| AIR OUTLET .....                  | 1. J 14 |
| HEATER AIR CONDITIONING .....     | 1. J 15 |
| HEATER CONTROL .....              | 1. J 17 |
| HEATER HOSES .....                | 1. J 16 |

## Illus Part Number

|    |            |
|----|------------|
| 1  | 229 02 005 |
| 2  | 126 23 006 |
| 3  | 126 23 007 |
| 4  | 225 05 004 |
| 5  | 138 09 001 |
| 6  | 225 01 008 |
| 70 | 040 14 019 |



## Description

## Quantity

## Change Point

## Remarks

|                                            |   |  |  |
|--------------------------------------------|---|--|--|
| Heater Control.-heater control-Valeo ..... | 1 |  |  |
| Trim.-heater control-Valeo .....           | 1 |  |  |
| Trim.-heater control-Valeo .....           | 1 |  |  |
| Button.-heater control-Valeo .....         | 1 |  |  |
| Control Cable.-heater control .....        | 1 |  |  |
| Button.-set of 2 .....                     | 1 |  |  |
| Screw.-4.2 x 13-front panel-lower .....    | 1 |  |  |



ZL0007

## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

|    |                                   |         |
|----|-----------------------------------|---------|
| 1C | AIR CONDITIONING .....            | 1. J 02 |
| 1D | COMPRESSOR-PETROL .....           | 1. J 05 |
| 1E | CONDENSER .....                   | 1. J 06 |
| 1F | EVAPORATOR .....                  | 1. J 02 |
| 1G | PIPES AND HOSES-PETROL .....      | 1. J 04 |
| 1H | COOLING .....                     | 1. J 07 |
| 1I | COOLING FAN .....                 | 1. J 08 |
| 1J | COOLING HOSES .....               | 1. J 10 |
| 1K | COOLING RADIATOR .....            | 1. J 09 |
| 2C | RADIATOR AND FAN SUPPORT .....    | 1. J 07 |
| 2F | THERMOSTAT AND HOUSING .....      | 1. J 11 |
| 2H | HEATER .....                      | 1. J 12 |
| 2I | AIR INTAKE .....                  | 1. J 12 |
|    | AIR INTAKE AIR CONDITIONING ..... | 1. J 13 |
|    | AIR OUTLET .....                  | 1. J 14 |
|    | HEATER AIR CONDITIONING .....     | 1. J 15 |
|    | HEATER CONTROL .....              | 1. J 17 |
|    | HEATER HOSES .....                | 1. J 16 |






# SAMAND

K02

Fiche 1

## ELECTRICAL AND INSTRUMENTS IGNITION AND ENGINE ELECTRICS IGNITION COMPONENTS



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 104 | 01 | 023 |
| 3  | 232 | 01 | 012 |
| 4  | 025 | 02 | 082 |
| 6  | 153 | 01 | 006 |
| 7  | 181 | 17 | 042 |
| 70 | 040 | 05 | 034 |
| 71 | 040 | 22 | 009 |
| 72 | 040 | 22 | 004 |


### Description

|                                       |   |
|---------------------------------------|---|
| Spark Plug.-spark-EYQUEM .....        | 4 |
| Ignition Harness.-ignition .....      | 1 |
| Clip.-harness-injection harness ..... | 1 |
| Ignition Coil.-ignition .....         | 1 |
| Bracket .....                         | 1 |
| Screw.-5 x 80 -50 .....               | 4 |
| Screw.-shouldered-M8 x 125-20 .....   | 2 |
| Screw.-shouldered-M6 x 100-20 .....   | 1 |

### Quantity

### Change Point

### Remarks



ZM0031

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX

|    |                                    |        |
|----|------------------------------------|--------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1.K 04 |
| 1D | ALTERNATOR COMPONENTS.....         | 1.K 05 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1.K 04 |
| 1F | BATTERY AND FITTINGS.....          | 1.L 07 |
| 1G | BATTERY & CABLES.....              | 1.L 07 |
| 1H | BATTERY TRAY ASSY.....             | 1.L 08 |
| 1I | BURGLAR ALARM.....                 | 1.L 06 |
| 1J | BURGLAR ALARM.....                 | 1.L 06 |
| 1K | ECU AND SENSORS.....               | 1.K 03 |
| 2C | ECU'S AND SENSORS.....             | 1.K 03 |
| 2F | ELECTRICAL COMPONENTS.....         | 1.K 02 |
| 2H | ROTOR.....                         | 1.K 02 |
| 2I | FUSEBOX AND RELAYS.....            | 1.L 03 |
|    | FUSEBOX ASSY.....                  | 1.L 03 |
|    | RELAYS.....                        | 1.L 04 |
|    | HORN.....                          | 1.L 05 |
|    | HORN.....                          | 1.L 05 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1.K 02 |
|    | IGNITION COMPONENTS.....           | 1.K 02 |
|    | IN CAR ENTERTAINMENT.....          | 1.M 03 |
|    | AERIAL AND MOUNTING.....           | 1.M 06 |
|    | CD PLAYER AND FITTINGS.....        | 1.M 04 |
|    | RADIO CASSETTE AND FITTINGS.....   | 1.M 03 |

|                                        |        |
|----------------------------------------|--------|
| SPEAKER AND FITTINGS.....              | 1.M 05 |
| INSTRUMENTS.....                       | 1.K 14 |
| INSTRUMENTS.....                       | 1.K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1.K 14 |
| LIGHTING.....                          | 1.K 08 |
| DOOR WARNING LAMPS.....                | 1.K 13 |
| DRIVING AND FOG LAMPS.....             | 1.K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1.K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1.K 10 |
| INTERIOR LAMPS.....                    | 1.K 12 |
| REAR LAMPS.....                        | 1.K 09 |
| STARTER MOTOR COMPONENTS.....          | 1.K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1.K 06 |
| SWITCHES.....                          | 1.K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1.K 18 |
| SWITCHES - BODY.....                   | 1.K 16 |
| SWITCHES - DOOR.....                   | 1.L 02 |
| WIRING.....                            | 1.L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1.M 02 |

# SAMAND


K03

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### ECU AND SENSORS

### ECU'S AND SENSORS



Illus Part Number

9 209 03 003  
10 208 10 001  
11 181 21 017  
12 170 16 001  
13 025 10 015  
14 181 21 018  
70 040 22 065  
71 174 04 037  
72 174 04 050

Description

Control Unit.-engine management system-SAGEM  
Box.-ecu protection box  
Bracket.-ecu protection box  
Plug/Cover.-ecu protection box  
Clip.-ecu protection box  
Bracket.-fuseholder  
Screw.-ecu to support-M5 x 0.80  
Nut.-flange-5 x 80  
Nut.-ecu box to bracket-flanged head-M6 x 100

Quantity

1  
1  
1  
1  
1  
1  
4  
4  
3

Change  
Point

Remarks

ZL0001

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS.....1.K 04  
ALTERNATOR COMPONENTS.....1.K 05  
ALTERNATOR-1800CC PETROL.....1.K 04  
BATTERY AND FITTINGS.....1.L 07  
BATTERY & CABLES.....1.L 07  
BATTERY TRAY ASSY.....1.L 08  
BURGLAR ALARM.....1.L 06  
BURGLAR ALARM.....1.L 06  
ECU'S AND SENSORS.....1.K 03  
ECU'S AND SENSORS.....1.K 03  
ELECTRICAL COMPONENTS.....1.K 02  
ROTOR.....1.K 02  
FUSEBOX AND RELAYS.....1.L 03  
FUSEBOX ASSY.....1.L 03  
RELAYS.....1.L 04  
RELAYS.....1.L 04  
HORN.....1.L 05  
HORN.....1.L 05  
IGNITION AND ENGINE ELECTRICS.....1.K 02  
IGNITION COMPONENTS.....1.K 02  
IN CAR ENTERTAINMENT.....1.M 03  
AERIAL AND MOUNTING.....1.M 06  
CD PLAYER AND FITTINGS.....1.M 04  
RADIO CASSETTE AND FITTINGS.....1.M 03

SPEAKER AND FITTINGS.....1.M 05  
INSTRUMENTS.....1.K 14  
INSTRUMENTS.....1.K 15  
SPEEDO CABLE AND FIXINGS.....1.K 14  
LIGHTING.....1.K 08  
DOOR WARNING LAMPS.....1.K 13  
DRIVING AND FOG LAMPS.....1.K 11  
HEADLAMPS & SIDE LAMPS.....1.K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1.K 10  
INTERIOR LAMPS.....1.K 12  
REAR LAMPS.....1.K 09  
STARTER MOTOR COMPONENTS.....1.K 07  
STARTER MOTOR INJECTION XU7 JP.....1.K 06  
SWITCHES.....1.K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1.K 18  
SWITCHES - BODY.....1.K 16  
SWITCHES - DOOR.....1.L 02  
WIRING.....1.L 09  
SUPPLEMENTARY FRONT HARNESS.....1.M 02

# SAMAND

K04

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### ALTERNATOR AND FITTINGS

#### ALTERNATOR-1800CC PETROL

Illus Part Number

Description


Quantity

Change Point

Remarks

|    |     |    |     |
|----|-----|----|-----|
| 1  | 069 | 05 | 003 |
| 2  | 181 | 05 | 021 |
| 3  | 181 | 05 | 009 |
| 4  | 040 | 01 | 123 |
| 5  | 116 | 01 | 008 |
| 6  | 116 | 01 | 009 |
| 9  | 061 | 19 | 002 |
| 10 | 061 | 19 | 001 |
| 20 | 207 | 02 | 003 |
| 70 | 040 | 02 | 089 |
| 71 | 040 | 02 | 090 |
| 73 | 040 | 02 | 095 |
| 74 | 030 | 29 | 004 |
| 75 | 040 | 22 | 054 |
| 76 | 186 | 01 | 174 |
| 77 | 174 | 04 | 036 |
| 78 | 040 | 02 | 091 |
| 81 | 174 | 04 | 020 |
| 82 | 174 | 04 | 019 |

|                                                    |   |
|----------------------------------------------------|---|
| Alternator.-Mitsubishi, Valeo-assembly-80 amp..... | 1 |
| Bracket.-upper .....                               | 1 |
| Bracket.-lower.....                                | 1 |
| Screw.-10 x 150 .....                              | 1 |
| Tensioner. ....                                    | 1 |
| Tensioner.-roller-assembly.....                    | 1 |
| Protectors.-Alternator-diameter 8mm .....          | 1 |
| Protectors.-Alternator-diameter 5mm .....          | 1 |
| Drive Belt.-Alternator-L = 1660 .....              | 1 |
| Screw.-socket head-M10 x 150-45 .....              | 1 |
| Screw.-socket head-M8 x 125-20 .....               | 2 |
| Screw.-socket head-M8 x 125-20 .....               | 3 |
| Bush.-centralising-16 x 25.5 .....                 | 2 |
| Screw.-socket head-M8 X 125-55.....                | 1 |
| Washer.-plain-8 x 16.....                          | 4 |
| Nut.-flange-M8.....                                | 1 |
| Screw.-M8 x 125-25.....                            | 2 |
| Nut.-flange-M6.....                                | 1 |
| Nut.-flange-5 x 80 .....                           | 1 |



ZM0032

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |         |
|-------------------------------------|---------|
| ALTERNATOR AND FITTINGS.....        | 1. K 04 |
| ALTERNATOR COMPONENTS .....         | 1. K 05 |
| ALTERNATOR-1800CC PETROL .....      | 1. K 04 |
| BATTERY AND FITTINGS.....           | 1. L 07 |
| BATTERY & CABLES .....              | 1. L 07 |
| BATTERY TRAY ASSY .....             | 1. L 08 |
| BURGLAR ALARM .....                 | 1. L 06 |
| BURGLAR ALARM .....                 | 1. L 06 |
| ECU AND SENSORS .....               | 1. K 03 |
| ECU'S AND SENSORS.....              | 1. K 03 |
| ELECTRICAL COMPONENTS .....         | 1. K 02 |
| ROTOR .....                         | 1. K 02 |
| FUSEBOX AND RELAYS .....            | 1. L 03 |
| FUSEBOX ASSY .....                  | 1. L 03 |
| RELAYS .....                        | 1. L 04 |
| HORN .....                          | 1. L 05 |
| HORN .....                          | 1. L 05 |
| IGNITION AND ENGINE ELECTRICS ..... | 1. K 02 |
| IGNITION COMPONENTS .....           | 1. K 02 |
| IN CAR ENTERTAINMENT .....          | 1. M 03 |
| AERIAL AND MOUNTING.....            | 1. M 06 |
| CD PLAYER AND FITTINGS.....         | 1. M 04 |
| RADIO CASSETTE AND FITTINGS.....    | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS .....                      | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS .....         | 1. K 14 |
| LIGHTING .....                         | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS .....                   | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS .....         | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP .....   | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING .....                           | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |

# SAMAND

K05

Fiche 1

## ELECTRICAL AND INSTRUMENTS ALTERNATOR AND FITTINGS ALTERNATOR COMPONENTS

Illus Part Number

2 004 02 015  
3 022 01 013  
4 050 01 009  
5 074 03 003  
6 027 04 001  
7 200 01 001  
8 163 08 001


Description

Rotor-Alternator ..... 1  
Stator-Alternator ..... 1  
Diodes-assembly-Alternator ..... 1  
Regulator-assembly-Alternator ..... 1  
Bearing-Alternator ..... 1  
Battery Terminal-positive-Alternator ..... 1  
Kit-Alternator..... 1

Quantity

Change Point

Remarks



ZM0001

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1 K 04  
ALTERNATOR COMPONENTS ..... 1 K 05  
ALTERNATOR-1800CC PETROL ..... 1 K 04  
BATTERY AND FITTINGS ..... 1 L 07  
BATTERY & CABLES ..... 1 L 07  
BATTERY TRAY ASSY ..... 1 L 08  
BURGLAR ALARM ..... 1 L 06  
BURGLAR ALARM ..... 1 L 06  
ECU AND SENSORS ..... 1 K 03  
ECU'S AND SENSORS ..... 1 K 03  
ELECTRICAL COMPONENTS ..... 1 K 02  
ROTOR ..... 1 K 02  
FUSEBOX AND RELAYS ..... 1 L 03  
FUSEBOX ASSY ..... 1 L 03  
RELAYS ..... 1 L 04  
HORN ..... 1 L 05  
HORN ..... 1 L 05  
IGNITION AND ENGINE ELECTRICS ..... 1 K 02  
IGNITION COMPONENTS ..... 1 K 02  
IN CAR ENTERTAINMENT ..... 1 M 03  
AERIAL AND MOUNTING ..... 1 M 06  
CD PLAYER AND FITTINGS ..... 1 M 04  
RADIO CASSETTE AND FITTINGS ..... 1 M 03


SPEAKER AND FITTINGS ..... 1 M 05  
INSTRUMENTS ..... 1 K 14  
INSTRUMENTS ..... 1 K 15  
SPEEDO CABLE AND FIXINGS ..... 1 K 14  
LIGHTING ..... 1 K 08  
DOOR WARNING LAMPS ..... 1 K 13  
DRIVING AND FOG LAMPS ..... 1 K 11  
HEADLAMPS & SIDE LAMPS ..... 1 K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1 K 10  
INTERIOR LAMPS ..... 1 K 12  
REAR LAMPS ..... 1 K 09  
STARTER MOTOR COMPONENTS ..... 1 K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1 K 06  
SWITCHES ..... 1 K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1 K 18  
SWITCHES - BODY ..... 1 K 16  
SWITCHES - DOOR ..... 1 L 02  
WIRING ..... 1 L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1 M 02

# SAMAND

K06

Fiche 1

## ELECTRICAL AND INSTRUMENTS STARTER MOTOR STARTER MOTOR INJECTION XU7 JP



Illus Part Number

1 005 01 002  
2 181 10 003  
70 030 29 001  
71 040 02 020  
72 186 03 081  
73 040 01 274  
74 186 01 104  
75 186 02 003  
76 174 04 019  
77 174 04 026  
78 040 02 092

Description


Starter Motor-assembly-starter-Bosch-Valeo  
Bracket.-starter  
Bush.-14 X 15  
Screw.-socket head-M10 x 150-60  
Washer.-flexible-M10 x 21.3-1  
Screw.-cap head-M7 x 100-22  
Washer.-plain-7 x 20  
Washer.-flexible-7 x 13.7  
Nut.-flange-5 x 80  
Nut.-with base-M7 x 100-6-14  
Screw.-socket head-M10 x 150-70

Quantity

1  
1  
1  
2  
3  
2  
2  
2  
3  
1  
1

Change  
Point

Remarks



ZM0037

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU'S AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02



Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 2 | 004 | 01 | 012 |
| 3 | 075 | 01 | 012 |
| 4 | 065 | 08 | 011 |
| 5 | 015 | 04 | 003 |
| 6 | 071 | 01 | 011 |
| 7 | 163 | 02 | 004 |


Description

Quantity

Change Point

Remarks

|                                          |   |  |  |
|------------------------------------------|---|--|--|
| Rotor.-starter motor-starter.....        | 1 |  |  |
| Relay.-starter motor .....               | 1 |  |  |
| Gear.-starter motor .....                | 1 |  |  |
| Lever.-starter motor-assembly .....      | 1 |  |  |
| Brush Assy.-starter motor-assembly ..... | 1 |  |  |
| Kit.-starter motor-assembly .....        | 1 |  |  |



ZM0060

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS.....  
ALTERNATOR COMPONENTS.....  
ALTERNATOR-1800CC PETROL.....  
BATTERY AND FITTINGS.....  
BATTERY & CABLES.....  
BATTERY TRAY ASSY.....  
BURGLAR ALARM.....  
BURGLAR ALARM.....  
ECU AND SENSORS.....  
ECU'S AND SENSORS.....  
ELECTRICAL COMPONENTS.....  
ROTOR.....  
FUSEBOX AND RELAYS.....  
FUSEBOX ASSY.....  
RELAYS.....  
HORN.....  
HORN.....  
IGNITION AND ENGINE ELECTRICS.....  
IGNITION COMPONENTS.....  
IN CAR ENTERTAINMENT.....  
AERIAL AND MOUNTING.....  
CD PLAYER AND FITTINGS.....  
RADIO CASSETTE AND FITTINGS.....

1. K 04  
1. K 05  
1. K 04  
1. L 07  
1. L 07  
1. L 08  
1. L 06  
1. L 06  
1. K 03  
1. K 03  
1. K 02  
1. K 02  
1. L 03  
1. L 03  
1. L 04  
1. L 05  
1. L 05  
1. K 02  
1. K 02  
1. M 03  
1. M 06  
1. M 04  
1. M 03  
SPEAKER AND FITTINGS.....  
INSTRUMENTS.....  
INSTRUMENTS.....  
SPEEDO CABLE AND FIXINGS.....  
LIGHTING.....  
DOOR WARNING LAMPS.....  
DRIVING AND FOG LAMPS.....  
HEADLAMPS & SIDE LAMPS.....  
HIGH LEVEL STOP AND NUMBER PLATE.....  
INTERIOR LAMPS.....  
REAR LAMPS.....  
STARTER MOTOR COMPONENTS.....  
STARTER MOTOR INJECTION XU7 JP.....  
SWITCHES.....  
SWITCHES & DIGITAL CLOCK - FASCIA.....  
SWITCHES - BODY.....  
SWITCHES - DOOR.....  
WIRING.....  
SUPPLEMENTARY FRONT HARNESS.....

1. M 05  
1. K 14  
1. K 15  
1. K 14  
1. K 08  
1. K 13  
1. K 11  
1. K 08  
1. K 10  
1. K 12  
1. K 09  
1. K 07  
1. K 06  
1. K 16  
1. K 18  
1. K 16  
1. L 02  
1. L 09  
1. M 02



# SAMAND

K08

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### LIGHTING

#### HEADLAMPS & SIDE LAMPS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 054 | 01 | 012 |
| 1  | 054 | 02 | 013 |
| 2  | 054 | 13 | 006 |
| 3  | 181 | 28 | 027 |
| 4  | 161 | 04 | 002 |
| 5  | 054 | 13 | 007 |
| 6  | 061 | 40 | 001 |
| 7  | 161 | 05 | 001 |
| 8  | 181 | 28 | 026 |
| 9  | 161 | 01 | 022 |
| 70 | 040 | 14 | 014 |





Description

|                                                       |   |
|-------------------------------------------------------|---|
| Light.-headlamp.-assembly-front LH.-with flasher .... | 1 |
| Light.-headlamp.-assembly-front RH.-with flasher....  | 1 |
| Light.-assembly-side repeater .....                   | 2 |
| Bracket.....                                          | 4 |
| Lamp.....                                             | 4 |
| Light.-side repeater.....                             | 2 |
| Cap.....                                              | 2 |
| Lamp.....                                             | 4 |
| Bracket.....                                          | 2 |
| Lamp.....                                             | 2 |
| Screw.-flanged-M6 x 100-22-inner.....                 | 3 |

Quantity

Change Point

Remarks



ZM0005

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                    |        |
|----|------------------------------------|--------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1.K 04 |
| 1D | ALTERNATOR COMPONENTS.....         | 1.K 05 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1.K 04 |
| 1F | BATTERY AND FITTINGS.....          | 1.L 07 |
| 1G | BATTERY & CABLES.....              | 1.L 07 |
| 1H | BATTERY TRAY ASSY.....             | 1.L 08 |
| 1I | BURGLAR ALARM.....                 | 1.L 06 |
| 1J | BURGLAR ALARM.....                 | 1.L 06 |
| 1K | ECU AND SENSORS.....               | 1.K 03 |
| 2C | ECU'S AND SENSORS.....             | 1.K 03 |
| 2F | ELECTRICAL COMPONENTS.....         | 1.K 02 |
| 2H | ROTOR.....                         | 1.K 02 |
| 2I | FUSEBOX AND RELAYS.....            | 1.L 03 |
|    | FUSEBOX ASSY.....                  | 1.L 03 |
|    | RELAYS.....                        | 1.L 04 |
|    | HORN.....                          | 1.L 05 |
|    | HORN.....                          | 1.L 05 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1.K 02 |
|    | IGNITION COMPONENTS.....           | 1.K 02 |
|    | IN CAR ENTERTAINMENT.....          | 1.M 03 |
|    | AERIAL AND MOUNTING.....           | 1.M 06 |
|    | CD PLAYER AND FITTINGS.....        | 1.M 04 |
|    | RADIO CASSETTE AND FITTINGS.....   | 1.M 03 |

|                                        |        |
|----------------------------------------|--------|
| SPEAKER AND FITTINGS.....              | 1.M 05 |
| INSTRUMENTS.....                       | 1.K 14 |
| INSTRUMENTS.....                       | 1.K 14 |
| SPEEDO CABLE AND FIXINGS.....          | 1.K 15 |
| LIGHTING.....                          | 1.K 14 |
| DOOR WARNING LAMPS.....                | 1.K 08 |
| DRIVING AND FOG LAMPS.....             | 1.K 13 |
| HEADLAMPS & SIDE LAMPS.....            | 1.K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1.K 10 |
| INTERIOR LAMPS.....                    | 1.K 12 |
| REAR LAMPS.....                        | 1.K 09 |
| STARTER MOTOR COMPONENTS.....          | 1.K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1.K 06 |
| SWITCHES.....                          | 1.K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1.K 18 |
| SWITCHES - BODY.....                   | 1.K 16 |
| SWITCHES - DOOR.....                   | 1.L 02 |
| WIRING.....                            | 1.L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1.M 02 |



# SAMAND

K09

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### LIGHTING REAR LAMPS



#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 054 | 20 | 002 |
| 1  | 054 | 20 | 001 |
| 2  | 054 | 03 | 014 |
| 2  | 054 | 04 | 015 |
| 3  | 054 | 03 | 016 |
| 3  | 054 | 04 | 017 |
| 4  | 161 | 01 | 022 |
| 5  | 161 | 07 | 002 |
| 6  | 181 | 28 | 031 |
| 6  | 181 | 28 | 030 |
| 7  | 054 | 03 | 015 |
| 7  | 054 | 04 | 016 |
| 8  | 161 | 07 | 001 |
| 9  | 181 | 28 | 028 |
| 9  | 181 | 28 | 029 |
| 70 | 174 | 04 | 005 |

#### Description

|                                                  |   |
|--------------------------------------------------|---|
| Light.-assembly-tail light-trunk mounted-RH..... | 1 |
| Light.-assembly-tail light-trunk mounted-LH..... | 1 |
| Light.-assembly-tail light-body mounted-LH.....  | 1 |
| Light.-assembly-tail light-body mounted-RH.....  | 1 |
| Light.-lens.-tail light-body mounted-LH.....     | 1 |
| Light.-tail light-body mounted-RH.....           | 1 |
| Lamp.....                                        | 2 |
| Lamp.....                                        | 2 |
| Bracket.-tail light-body mounted-LH.....         | 1 |
| Bracket.-tail light-body mounted-RH.....         | 1 |
| Light.-lens.-tail light-trunk mounted-LH.....    | 1 |
| Light.-lens.-tail light-trunk mounted-RH.....    | 1 |
| Lamp.....                                        | 4 |
| Bracket.-tail light-trunk mounted-LH.....        | 1 |
| Bracket.-tail light-trunk mounted-RH.....        | 1 |
| Nut.-M6 x 100.....                               | 4 |

#### Quantity

#### Change Point

#### Remarks

ZM0004

#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

ALTERNATOR AND FITTINGS.....  
ALTERNATOR COMPONENTS.....  
ALTERNATOR-1800CC PETROL.....  
BATTERY AND FITTINGS.....  
BATTERY & CABLES.....  
BATTERY TRAY ASSY.....  
BURGLAR ALARM.....  
BURGLAR ALARM.....  
ECU AND SENSORS.....  
ECU'S AND SENSORS.....  
ELECTRICAL COMPONENTS.....  
ROTOR.....  
FUSEBOX AND RELAYS.....  
FUSEBOX ASSY.....  
RELAYS.....  
HORN.....  
HORN.....  
IGNITION AND ENGINE ELECTRICS.....  
IGNITION COMPONENTS.....  
IN CAR ENTERTAINMENT.....  
AERIAL AND MOUNTING.....  
CD PLAYER AND FITTINGS.....  
RADIO CASSETTE AND FITTINGS.....

1. K 04  
1. K 05  
1. K 04  
1. L 07  
1. L 07  
1. L 08  
1. L 08  
1. L 06  
1. L 06  
1. K 03  
1. K 03  
1. K 02  
1. K 02  
1. L 03  
1. L 03  
1. L 04  
1. L 04  
1. L 05  
1. L 05  
1. K 02  
1. K 02  
1. M 03  
1. M 06  
1. M 04  
1. M 04  
1. M 03

SPEAKER AND FITTINGS.....  
INSTRUMENTS.....  
INSTRUMENTS.....  
SPEEDO CABLE AND FIXINGS.....  
LIGHTING.....  
DOOR WARNING LAMPS.....  
DRIVING AND FOG LAMPS.....  
HEADLAMPS & SIDE LAMPS.....  
HIGH LEVEL STOP AND NUMBER PLATE.....  
INTERIOR LAMPS.....  
REAR LAMPS.....  
STARTER MOTOR COMPONENTS.....  
STARTER MOTOR INJECTION XU7 JP.....  
SWITCHES.....  
SWITCHES & DIGITAL CLOCK - FASCIA.....  
SWITCHES - BODY.....  
SWITCHES - DOOR.....  
WIRING.....  
SUPPLEMENTARY FRONT HARNESS.....

1. M 05  
1. K 14  
1. K 15  
1. K 14  
1. K 08  
1. K 13  
1. K 11  
1. K 08  
1. K 10  
1. K 12  
1. K 09  
1. K 07  
1. K 06  
1. K 16  
1. K 18  
1. K 16  
1. L 02  
1. L 02  
1. L 09  
1. M 02

# SAMAND

K10

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### LIGHTING

#### HIGH LEVEL STOP AND NUMBER PLATE LAMPS

Illus Part Number

|   |            |
|---|------------|
| 1 | 054 15 004 |
| 2 | 126 06 025 |
| 3 | 181 28 027 |
| 4 | 161 04 002 |
| 5 | 161 01 021 |
| 6 | 054 14 006 |




Description

|                                         |   |
|-----------------------------------------|---|
| Light.-assembly-high mounted stop ..... | 1 |
| Trim.....                               | 2 |
| Bracket.....                            | 2 |
| Lamp.....                               | 2 |
| Lamp.....                               | 1 |
| Light.-assembly-license plate .....     | 1 |

Quantity

Change Point

Remarks



ZM0033

## MASTER INDEX

|                                         |    |
|-----------------------------------------|----|
| ENGINE                                  | 1C |
| FLYWHEEL AND CLUTCH                     | 1D |
| GEARBOX                                 | 1E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS | 1F |
| STEERING                                | 1G |
| BRAKES AND BRAKE CONTROLS               | 1H |
| FUEL, EXHAUST AND EMISSION SYSTEM       | 1I |
| COOLING, HEATING AND AIR CONDITIONING   | 1J |
| ELECTRICAL AND INSTRUMENTS              | 1K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-  | 2C |
| FACIA, TRIM, SEATS AND FIXINGS          | 2F |
| ACCESSORIES AND PAINT                   | 2H |
| Numeric Index                           | 2I |

## GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| ALTERNATOR AND FITTINGS.....       | 1. K 04 |
| ALTERNATOR COMPONENTS.....         | 1. K 05 |
| ALTERNATOR-1800CC PETROL.....      | 1. K 04 |
| BATTERY AND FITTINGS.....          | 1. L 07 |
| BATTERY & CABLES.....              | 1. L 07 |
| BATTERY TRAY ASSY.....             | 1. L 08 |
| BURGLAR ALARM.....                 | 1. L 06 |
| BURGLAR ALARM.....                 | 1. L 06 |
| ECU AND SENSORS.....               | 1. K 03 |
| ECU'S AND SENSORS.....             | 1. K 03 |
| ELECTRICAL COMPONENTS.....         | 1. K 02 |
| ROTOR.....                         | 1. K 02 |
| FUSEBOX AND RELAYS.....            | 1. L 03 |
| FUSEBOX ASSY.....                  | 1. L 03 |
| RELAYS.....                        | 1. L 04 |
| HORN.....                          | 1. L 05 |
| HORN.....                          | 1. L 05 |
| IGNITION AND ENGINE ELECTRICS..... | 1. K 02 |
| IGNITION COMPONENTS.....           | 1. K 02 |
| IN CAR ENTERTAINMENT.....          | 1. M 03 |
| AERIAL AND MOUNTING.....           | 1. M 06 |
| CD PLAYER AND FITTINGS.....        | 1. M 04 |
| RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS.....                       | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| LIGHTING.....                          | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS.....                    | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING.....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |

# SAMAND


K11

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### LIGHTING

### DRIVING AND FOG LAMPS



#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 054 | 10 | 003 |
| 1  | 054 | 11 | 003 |
| 2  | 161 | 05 | 001 |
| 70 | 040 | 14 | 014 |
| 71 | 040 | 05 | 038 |


#### Description

|                                                 |   |
|-------------------------------------------------|---|
| Light.-fog-front LH.....                        | 1 |
| Light.-fog-front RH. ....                       | 1 |
| Lamp.....                                       | 2 |
| Screw.-flanged-M6 x 100-22-inner.....           | 2 |
| Screw.-lamp to body-vis cblx mat-tend 5L10..... | 2 |
| acz15 dlnr-outer.....                           |   |

#### Quantity

#### Change Point

#### Remarks



ZM0034

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02

# SAMAND

K12

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### LIGHTING INTERIOR LAMPS

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 054 | 08 | 006 |
| 2 | 054 | 08 | 007 |
| 3 | 054 | 09 | 004 |
| 4 | 054 | 09 | 002 |
| 5 | 161 | 04 | 002 |
| 6 | 161 | 03 | 004 |


Description

Quantity

Change Point

Remarks

|                           |   |  |  |
|---------------------------|---|--|--|
| Light-interior-rear ..... | 2 |  |  |
| Light-map .....           | 1 |  |  |
| Light-bootlid .....       | 1 |  |  |
| Light-glove box .....     | 1 |  |  |
| Lamp .....                | 3 |  |  |
| Lamp .....                | 1 |  |  |



ZM 103

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 14  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02

Illus Part Number

5 054 19 001  
6 161 04 002  
7 181 28 027


Description

Light.-open warning-front & rear-door ..... 4  
Lamp..... 4  
Bracket..... 4

Quantity

Change Point

Remarks



ZM0040

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS..... 1. K 04  
ALTERNATOR COMPONENTS..... 1. K 05  
ALTERNATOR-1800CC PETROL..... 1. K 04  
BATTERY AND FITTINGS..... 1. L 07  
BATTERY & CABLES..... 1. L 07  
BATTERY TRAY ASSY..... 1. L 08  
BURGLAR ALARM..... 1. L 06  
BURGLAR ALARM..... 1. L 06  
ECU AND SENSORS..... 1. K 03  
ECU'S AND SENSORS..... 1. K 03  
ELECTRICAL COMPONENTS..... 1. K 02  
ROTOR..... 1. K 02  
FUSEBOX AND RELAYS..... 1. L 03  
FUSEBOX ASSY..... 1. L 03  
RELAYS..... 1. L 04  
HORN..... 1. L 05  
HORN..... 1. L 05  
IGNITION AND ENGINE ELECTRICS..... 1. K 02  
IGNITION COMPONENTS..... 1. K 02  
IN CAR ENTERTAINMENT..... 1. M 03  
AERIAL AND MOUNTING..... 1. M 06  
CD PLAYER AND FITTINGS..... 1. M 04  
RADIO CASSETTE AND FITTINGS..... 1. M 03

SPEAKER AND FITTINGS..... 1. M 05  
INSTRUMENTS..... 1. K 14  
INSTRUMENTS..... 1. K 15  
SPEEDO CABLE AND FIXINGS..... 1. K 14  
LIGHTING..... 1. K 08  
DOOR WARNING LAMPS..... 1. K 13  
DRIVING AND FOG LAMPS..... 1. K 11  
HEADLAMPS & SIDE LAMPS..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE..... 1. K 10  
INTERIOR LAMPS..... 1. K 12  
REAR LAMPS..... 1. K 09  
STARTER MOTOR COMPONENTS..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP..... 1. K 06  
SWITCHES..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA..... 1. K 18  
SWITCHES - BODY..... 1. K 16  
SWITCHES - DOOR..... 1. L 02  
WIRING..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS..... 1. M 02

# SAMAND

K14

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### INSTRUMENTS

#### SPEEDO CABLE AND FIXINGS

Illus Part Number

1 138 02 011  
2 165 03 001  
3 205 02 005


Description

Control Cable.-speedo cable ..... 1  
Cable Guide.-speedo cable ..... 1  
Grommet.-speedo cable ..... 1

Quantity

Change Point

Remarks



ZM0024

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

1C ALTERNATOR AND FITTINGS ..... 1. K 04  
1D ALTERNATOR COMPONENTS ..... 1. K 05  
1E ALTERNATOR-1800CC PETROL ..... 1. K 04  
1F BATTERY AND FITTINGS ..... 1. L 07  
1G BATTERY & CABLES ..... 1. L 07  
1H BATTERY TRAY ASSY ..... 1. L 08  
1I BURGLAR ALARM ..... 1. L 06  
1J BURGLAR ALARM ..... 1. L 06  
1K ECU'S AND SENSORS ..... 1. K 03  
2C ECU'S AND SENSORS ..... 1. K 03  
2F ELECTRICAL COMPONENTS ..... 1. K 02  
2H ROTOR ..... 1. K 02  
2I FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02



# SAMAND

K15

Fiche 1

## ELECTRICAL AND INSTRUMENTS INSTRUMENTS INSTRUMENTS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 011 | 06 | 018 |
| 2  | 011 | 03 | 001 |
| 3  | 011 | 02 | 003 |
| 4  | 011 | 05 | 003 |
| 5  | 011 | 04 | 004 |
| 6  | 126 | 07 | 025 |
| 7  | 126 | 07 | 024 |
| 70 | 040 | 05 | 016 |
| 71 | 058 | 07 | 015 |
| 72 | 040 | 25 | 005 |
| 74 | 058 | 07 | 016 |



Description

|                                               |   |
|-----------------------------------------------|---|
| Instrument Cluster-KMH.....                   | 1 |
| Indicator.-fuel.....                          | 1 |
| Indicator.-temperature.....                   | 1 |
| Indicator.-tachometer.....                    | 1 |
| Indicator.-speedometer.....                   | 1 |
| Trim.-instrument housing.....                 | 1 |
| Trim.-lens and cover.....                     | 1 |
| Screw.-counter sunk-raised head-3.5 X 13..... | 1 |
| Fixing Clip.-speed-3.5 x 10.....              | 1 |
| Screw.-3.5-13-self tapping.....               | 2 |
| Fixing Clip.-speed-3.5 x 12-9.....            | 2 |

Quantity

Change Point

Remarks



ZM0007

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| ALTERNATOR AND FITTINGS.....       | 1. K 04 |
| ALTERNATOR COMPONENTS.....         | 1. K 05 |
| ALTERNATOR-1800CC PETROL.....      | 1. K 04 |
| BATTERY AND FITTINGS.....          | 1. L 07 |
| BATTERY & CABLES.....              | 1. L 07 |
| BATTERY TRAY ASSY.....             | 1. L 08 |
| BURGLAR ALARM.....                 | 1. L 06 |
| BURGLAR ALARM.....                 | 1. L 06 |
| ECU AND SENSORS.....               | 1. K 03 |
| ECU'S AND SENSORS.....             | 1. K 03 |
| ELECTRICAL COMPONENTS.....         | 1. K 02 |
| ROTOR.....                         | 1. K 02 |
| FUSEBOX AND RELAYS.....            | 1. L 03 |
| FUSEBOX ASSY.....                  | 1. L 03 |
| RELAYS.....                        | 1. L 04 |
| HORN.....                          | 1. L 05 |
| HORN.....                          | 1. L 05 |
| IGNITION AND ENGINE ELECTRICS..... | 1. K 02 |
| IGNITION COMPONENTS.....           | 1. K 02 |
| IN CAR ENTERTAINMENT.....          | 1. M 03 |
| AERIAL AND MOUNTING.....           | 1. M 06 |
| CD PLAYER AND FITTINGS.....        | 1. M 04 |
| RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS.....                       | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| LIGHTING.....                          | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS.....                    | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING.....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |

# SAMAND

K16

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### SWITCHES SWITCHES - BODY

Illus Part Number

1 094 17 001  
3 094 05 018  
4 094 05 015


Description

Switch.-contact-inertia ..... 1  
Switch.-trunk light ..... 1  
Switch.-alarm.-bonnet..... 1

Quantity

Change Point

Remarks



ZM0043

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02

# SAMAND


K17

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### SWITCHES

#### SWITCHES - STEERING COLUMN



Illus Part Number

1 094 03 020  
2 094 04 006  
3 181 34 001  
70 040 25 005  
72 040 22 038


Description

Switch-lighting-direction indicator-steering ..... 1  
column-fog ..... 1  
Switch-windscreen wiper-steering column ..... 1  
Bracket-control ..... 1  
Screw-3.5-13-self tapping ..... 4  
Screw-6x100-12 ..... 3

Quantity

Change Point

Remarks



ZM0029A

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU'S AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. L 03  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. M 03  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02

# SAMAND

K18

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### SWITCHES

### SWITCHES & DIGITAL CLOCK - FASCIA

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 094 | 11 | 007 |
| 2 | 094 | 09 | 007 |
| 6 | 094 | 05 | 017 |
| 7 | 088 | 02 | 005 |


Description

|                                  |   |
|----------------------------------|---|
| Switch.-hazzard warning .....    | 1 |
| Switch.-heated rear window ..... | 1 |
| Switch.-glove box.....           | 1 |
| Clock.-digital clock .....       | 1 |

Quantity

Change Point

Remarks



ZM0041

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX

|    |                                    |         |
|----|------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1. K 04 |
| 1D | ALTERNATOR COMPONENTS.....         | 1. K 05 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1. K 04 |
| 1F | BATTERY AND FITTINGS.....          | 1. L 07 |
| 1G | BATTERY & CABLES.....              | 1. L 07 |
| 1H | BATTERY TRAY ASSY.....             | 1. L 08 |
| 1I | BURGLAR ALARM.....                 | 1. L 06 |
| 1J | BURGLAR ALARM.....                 | 1. L 06 |
| 1K | ECU AND SENSORS.....               | 1. K 03 |
| 2C | ECU'S AND SENSORS.....             | 1. K 03 |
| 2F | ELECTRICAL COMPONENTS.....         | 1. K 02 |
| 2H | ROTOR.....                         | 1. K 02 |
| 2I | FUSEBOX AND RELAYS.....            | 1. L 03 |
|    | FUSEBOX ASSY.....                  | 1. L 03 |
|    | RELAYS.....                        | 1. L 04 |
|    | HORN.....                          | 1. L 05 |
|    | HORN.....                          | 1. L 05 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1. K 02 |
|    | IGNITION COMPONENTS.....           | 1. K 02 |
|    | IN CAR ENTERTAINMENT.....          | 1. M 03 |
|    | AERIAL AND MOUNTING.....           | 1. M 06 |
|    | CD PLAYER AND FITTINGS.....        | 1. M 04 |
|    | RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS.....                       | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| LIGHTING.....                          | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS.....                    | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING.....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |

[illegible]

# SAMAND

L02

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### SWITCHES

#### SWITCHES - DOOR

Illus Part Number

1 094 14 011  
2 094 05 016  
3 094 14 012  
4 094 20 002  
5 094 12 005


Description

Switch.-electric window lift-front & rear..... 6  
Switch.-courtesy light-front & rear-door..... 4  
Switch.-impulse-electric window lift-driver's door ..... 1  
Switch.-isolator rear window lift ..... 1  
Switch.-door mirror adjustment..... 1

Quantity

Change Point

Remarks



ZP0006

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS..... 1. K 04  
ALTERNATOR COMPONENTS..... 1. K 05  
ALTERNATOR-1800CC PETROL..... 1. K 04  
BATTERY AND FITTINGS..... 1. L 07  
BATTERY & CABLES..... 1. L 07  
BATTERY TRAY ASSY..... 1. L 08  
BURGLAR ALARM..... 1. L 06  
BURGLAR ALARM..... 1. L 06  
ECU AND SENSORS..... 1. K 03  
ECU'S AND SENSORS..... 1. K 03  
ELECTRICAL COMPONENTS..... 1. K 02  
ROTOR..... 1. K 02  
FUSEBOX AND RELAYS..... 1. L 03  
FUSEBOX ASSY..... 1. L 03  
RELAYS..... 1. L 04  
HORN..... 1. L 05  
HORN..... 1. L 05  
IGNITION AND ENGINE ELECTRICS..... 1. K 02  
IGNITION COMPONENTS..... 1. K 02  
IN CAR ENTERTAINMENT..... 1. M 03  
AERIAL AND MOUNTING..... 1. M 06  
CD PLAYER AND FITTINGS..... 1. M 04  
RADIO CASSETTE AND FITTINGS..... 1. M 03

SPEAKER AND FITTINGS..... 1. M 05  
INSTRUMENTS..... 1. K 14  
INSTRUMENTS..... 1. K 15  
SPEEDO CABLE AND FIXINGS..... 1. K 14  
LIGHTING..... 1. K 08  
DOOR WARNING LAMPS..... 1. K 13  
DRIVING AND FOG LAMPS..... 1. K 11  
HEADLAMPS & SIDE LAMPS..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE..... 1. K 10  
INTERIOR LAMPS..... 1. K 12  
REAR LAMPS..... 1. K 09  
STARTER MOTOR COMPONENTS..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP..... 1. K 06  
SWITCHES..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA..... 1. K 18  
SWITCHES - BODY..... 1. K 16  
SWITCHES - DOOR..... 1. L 02  
WIRING..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS..... 1. M 02



# SAMAND

L03

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### FUSEBOX AND RELAYS

#### FUSEBOX ASSY

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 208 | 02 | 011 |
| 2  | 208 | 02 | 012 |
| 3  | 125 | 01 | 001 |
| 3  | 125 | 03 | 001 |
| 3  | 125 | 04 | 001 |
| 3  | 125 | 06 | 001 |
| 3  | 125 | 08 | 001 |
| 4  | 237 | 03 | 011 |
| 6  | 208 | 02 | 001 |
| 7  | 040 | 23 | 007 |
| 8  | 174 | 07 | 033 |
| 9  | 040 | 22 | 059 |
| 10 | 170 | 08 | 006 |
| 11 | 125 | 10 | 001 |



Description

|                                   |   |
|-----------------------------------|---|
| BOX.-MAIN-FUSEBOX ASSY .....      | 1 |
| • Box.-fuse holder-assembly ..... | 1 |
| Fuse.-5 amp.....                  | 1 |
| Fuse.-10 amp.....                 | 1 |
| Fuse.-15 amp.....                 | 1 |
| Fuse.-20 amp.....                 | 1 |
| Fuse.-30 amp.....                 | 1 |
| Protecting Plate. ....            | 1 |
| Box. -shunt-fuseable branch.....  | 1 |
| Screw. ....                       | 2 |
| Nut.-flanged head-6 x 100 .....   | 2 |
| Screw.....                        | 1 |
| Plug/Cover. ....                  | 1 |
| Fuse.-shunt-30 amp-large .....    | 1 |

Quantity


Change Point

Remarks



DETAIL NEEDED OF SHUNT  
LOCATED INSIDE THIS FUSEBOX

ZM0026



## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02



## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 075 | 10 | 002 |
| 3  | 075 | 17 | 002 |
| 4  | 075 | 10 | 001 |
| 6  | 075 | 08 | 001 |
| 8  | 075 | 13 | 001 |
| 12 | 181 | 17 | 043 |
| 13 | 025 | 11 | 002 |
| 14 | 075 | 02 | 001 |



## Description

## Quantity

## Change Point

## Remarks

|                                                 |   |  |  |
|-------------------------------------------------|---|--|--|
| Relay-starter-Black.....                        | 7 |  |  |
| Relay-lights on warning-White.....              | 1 |  |  |
| Relay-heated rear window-time delay-Orange..... | 1 |  |  |
| Relay-wiper control unit-Blue.....              | 1 |  |  |
| Relay-blower assy-Yellow.....                   | 1 |  |  |
| Bracket-relay support.....                      | 1 |  |  |
| Clip-6.2mm-rear-harness.....                    | 1 |  |  |
| Relay-direction indicator.....                  | 1 |  |  |



## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                    |     |    |
|----|------------------------------------|-----|----|
| 1C | ALTERNATOR AND FITTINGS.....       | 1.K | 04 |
| 1D | ALTERNATOR COMPONENTS.....         | 1.K | 05 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1.K | 04 |
| 1F | BATTERY AND FITTINGS.....          | 1.L | 07 |
| 1G | BATTERY & CABLES.....              | 1.L | 07 |
| 1H | BATTERY TRAY ASSY.....             | 1.L | 08 |
| 1I | BURGLAR ALARM.....                 | 1.L | 06 |
| 1J | BURGLAR ALARM.....                 | 1.L | 06 |
| 1K | ECU AND SENSORS.....               | 1.K | 03 |
| 2C | ECU'S AND SENSORS.....             | 1.K | 03 |
| 2F | ELECTRICAL COMPONENTS.....         | 1.K | 02 |
| 2H | ROTOR.....                         | 1.K | 02 |
| 2I | FUSEBOX AND RELAYS.....            | 1.L | 03 |
|    | FUSEBOX ASSY.....                  | 1.L | 03 |
|    | RELAYS.....                        | 1.L | 04 |
|    | HORN.....                          | 1.L | 05 |
|    | HORN.....                          | 1.L | 05 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1.K | 02 |
|    | IGNITION COMPONENTS.....           | 1.K | 02 |
|    | IN CAR ENTERTAINMENT.....          | 1.M | 03 |
|    | AERIAL AND MOUNTING.....           | 1.M | 06 |
|    | CD PLAYER AND FITTINGS.....        | 1.M | 04 |
|    | RADIO CASSETTE AND FITTINGS.....   | 1.M | 03 |

|                                        |     |    |
|----------------------------------------|-----|----|
| SPEAKER AND FITTINGS.....              | 1.M | 05 |
| INSTRUMENTS.....                       | 1.K | 14 |
| INSTRUMENTS.....                       | 1.K | 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1.K | 14 |
| LIGHTING.....                          | 1.K | 08 |
| DOOR WARNING LAMPS.....                | 1.K | 13 |
| DRIVING AND FOG LAMPS.....             | 1.K | 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1.K | 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1.K | 10 |
| INTERIOR LAMPS.....                    | 1.K | 12 |
| REAR LAMPS.....                        | 1.K | 09 |
| STARTER MOTOR COMPONENTS.....          | 1.K | 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1.K | 06 |
| SWITCHES.....                          | 1.K | 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1.K | 18 |
| SWITCHES - BODY.....                   | 1.K | 16 |
| SWITCHES - DOOR.....                   | 1.L | 02 |
| WIRING.....                            | 1.L | 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1.M | 02 |

Illus Part Number

1 031 02 002



Description

Horn.-high tone..... 1

Quantity

Change Point

Remarks



ZM0023

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02

# SAMAND

L06

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### BURGLAR ALARM

### BURGLAR ALARM

Illus Part Number

1 209 08 001  
2 209 08 002




Description

Quantity

Change Point

Remarks

Buglar Alarm.-burglar alarm. .... 1  
Buglar Alarm.-alarm.-backup..... 1



ZM0045

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                    |         |                                        |         |
|----|------------------------------------|---------|----------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1. K 04 | SPEAKER AND FITTINGS.....              | 1. M 05 |
| 1D | ALTERNATOR COMPONENTS.....         | 1. K 05 | INSTRUMENTS.....                       | 1. K 14 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1. K 04 | INSTRUMENTS.....                       | 1. K 15 |
| 1F | BATTERY AND FITTINGS.....          | 1. L 07 | SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| 1G | BATTERY & CABLES.....              | 1. L 07 | LIGHTING.....                          | 1. K 08 |
| 1H | BATTERY TRAY ASSY.....             | 1. L 08 | DOOR WARNING LAMPS.....                | 1. K 13 |
| 1I | BURGLAR ALARM.....                 | 1. L 06 | DRIVING AND FOG LAMPS.....             | 1. K 11 |
| 1J | BURGLAR ALARM.....                 | 1. L 06 | HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| 1K | ECU AND SENSORS.....               | 1. K 03 | HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| 2C | ECU'S AND SENSORS.....             | 1. K 03 | INTERIOR LAMPS.....                    | 1. K 12 |
| 2F | ELECTRICAL COMPONENTS.....         | 1. K 02 | REAR LAMPS.....                        | 1. K 09 |
| 2H | ROTOR.....                         | 1. K 02 | STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| 2I | FUSEBOX AND RELAYS.....            | 1. L 03 | STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
|    | FUSEBOX ASSY.....                  | 1. L 03 | SWITCHES.....                          | 1. K 16 |
|    | RELAYS.....                        | 1. L 04 | SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
|    | HORN.....                          | 1. L 05 | SWITCHES - BODY.....                   | 1. K 16 |
|    | HORN.....                          | 1. L 05 | SWITCHES - DOOR.....                   | 1. L 02 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1. K 02 | WIRING.....                            | 1. L 09 |
|    | IGNITION COMPONENTS.....           | 1. K 02 | SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |
|    | IN CAR ENTERTAINMENT.....          | 1. M 03 |                                        |         |
|    | AERIAL AND MOUNTING.....           | 1. M 06 |                                        |         |
|    | CD PLAYER AND FITTINGS.....        | 1. M 04 |                                        |         |
|    | RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |                                        |         |

# SAMAND

L07

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### BATTERY AND FITTINGS

### BATTERY & CABLES

Illus Part Number

|   |            |
|---|------------|
| 1 | 018 02 004 |
| 2 | 137 01 004 |
| 3 | 025 16 006 |
| 4 | 078 06 062 |
| 5 | 137 01 010 |
| 6 | 025 05 004 |


Description

|                                      |   |
|--------------------------------------|---|
| Battery.....                         | 1 |
| Battery Cable.-battery-negative..... | 1 |
| Clip.-negative terminal.....         | 1 |
| Cover.-battery clamp-negative.....   | 1 |
| Battery Cable.-positive.....         | 1 |
| Clip.-battery.....                   | 1 |

Quantity

Change Point

Remarks



ZM0044

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                    |         |
|------------------------------------|---------|
| ALTERNATOR AND FITTINGS.....       | 1. K 04 |
| ALTERNATOR COMPONENTS.....         | 1. K 05 |
| ALTERNATOR-1800CC PETROL.....      | 1. K 04 |
| BATTERY AND FITTINGS.....          | 1. L 07 |
| BATTERY & CABLES.....              | 1. L 07 |
| BATTERY TRAY ASSY.....             | 1. L 08 |
| BURGLAR ALARM.....                 | 1. L 06 |
| BURGLAR ALARM.....                 | 1. L 06 |
| ECU AND SENSORS.....               | 1. K 03 |
| ECU'S AND SENSORS.....             | 1. K 03 |
| ELECTRICAL COMPONENTS.....         | 1. K 02 |
| ROTOR.....                         | 1. K 02 |
| FUSEBOX AND RELAYS.....            | 1. L 03 |
| FUSEBOX ASSY.....                  | 1. L 03 |
| RELAYS.....                        | 1. L 04 |
| HORN.....                          | 1. L 05 |
| HORN.....                          | 1. L 05 |
| IGNITION AND ENGINE ELECTRICS..... | 1. K 02 |
| IGNITION COMPONENTS.....           | 1. K 02 |
| IN CAR ENTERTAINMENT.....          | 1. M 03 |
| AERIAL AND MOUNTING.....           | 1. M 06 |
| CD PLAYER AND FITTINGS.....        | 1. M 04 |
| RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS.....                       | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| LIGHTING.....                          | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS.....                    | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING.....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |

# SAMAND

L08

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### BATTERY AND FITTINGS

#### BATTERY TRAY ASSY

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 133 | 07 | 010 |
| 4 | 178 | 08 | 002 |
| 4 | 178 | 08 | 001 |
| 5 | 174 | 07 | 033 |
| 6 | 040 | 01 | 283 |
| 7 | 007 | 02 | 002 |


Description

|                                  |   |
|----------------------------------|---|
| Assembly.-battery-painted .....  | 1 |
| Link.-battery clamp-120mm .....  | 1 |
| Link.-battery clamp-220mm .....  | 1 |
| Nut.-flanged head-6 x 100 .....  | 4 |
| Screw.-M8 x 125-16 .....         | 1 |
| foam pad-battery tray-foam ..... | 1 |

Quantity

Change Point

Remarks



ZM0022

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                     |         |
|----|-------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS .....       | 1. K 04 |
| 1D | ALTERNATOR COMPONENTS .....         | 1. K 05 |
| 1E | ALTERNATOR-1800CC PETROL .....      | 1. K 04 |
| 1F | BATTERY AND FITTINGS .....          | 1. L 07 |
| 1G | BATTERY & CABLES .....              | 1. L 07 |
| 1H | BATTERY TRAY ASSY .....             | 1. L 08 |
| 1I | BURGLAR ALARM .....                 | 1. L 06 |
| 1J | BURGLAR ALARM .....                 | 1. L 06 |
| 1K | ECU AND SENSORS .....               | 1. K 03 |
| 2C | ECU'S AND SENSORS .....             | 1. K 03 |
| 2F | ELECTRICAL COMPONENTS .....         | 1. K 02 |
| 2H | ROTOR .....                         | 1. K 02 |
| 2I | FUSEBOX AND RELAYS .....            | 1. L 03 |
|    | FUSEBOX ASSY .....                  | 1. L 03 |
|    | RELAYS .....                        | 1. L 04 |
|    | HORN .....                          | 1. L 05 |
|    | HORN .....                          | 1. L 05 |
|    | IGNITION AND ENGINE ELECTRICS ..... | 1. K 02 |
|    | IGNITION COMPONENTS .....           | 1. K 02 |
|    | IN CAR ENTERTAINMENT .....          | 1. M 03 |
|    | AERIAL AND MOUNTING .....           | 1. M 06 |
|    | CD PLAYER AND FITTINGS .....        | 1. M 04 |
|    | RADIO CASSETTE AND FITTINGS .....   | 1. M 03 |

|                                         |         |
|-----------------------------------------|---------|
| SPEAKER AND FITTINGS .....              | 1. M 05 |
| INSTRUMENTS .....                       | 1. K 14 |
| INSTRUMENTS .....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS .....          | 1. K 14 |
| LIGHTING .....                          | 1. K 08 |
| DOOR WARNING LAMPS .....                | 1. K 13 |
| DRIVING AND FOG LAMPS .....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS .....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE .....  | 1. K 10 |
| INTERIOR LAMPS .....                    | 1. K 12 |
| REAR LAMPS .....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS .....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP .....    | 1. K 06 |
| SWITCHES .....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA ..... | 1. K 18 |
| SWITCHES - BODY .....                   | 1. K 16 |
| SWITCHES - DOOR .....                   | 1. L 02 |
| WIRING .....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS .....       | 1. M 02 |

# SAMAND

L09

Fiche 1

## ELECTRICAL AND INSTRUMENTS WIRING FRONT BRAKE WEAR

Illus Part Number

1 100 12 009  
70 025 07 002





Description

Harness.-brake wear .....2  
Clip.-harness.....2

Quantity

Change Point

Remarks



ZM0018

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02



# SAMAND

L10

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### WIRING

### HARNESS - ENGINE

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 100 | 03 | 015 |
| 3 | 040 | 22 | 065 |
| 4 | 025 | 07 | 017 |
| 5 | 025 | 07 | 013 |



Description

|                                       |   |
|---------------------------------------|---|
| Harness.-Engine-sajem .....           | 1 |
| Screw.-engine harness-M5 x 0.80 ..... | 1 |
| Clip.-injection harness .....         | 1 |
| Clip.-engine harness.....             | 2 |

Quantity

Change Point

Remarks



ZM0011

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                    |         |
|----|------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1. K 04 |
| 1D | ALTERNATOR COMPONENTS.....         | 1. K 05 |
| 1E | ALTERNATOR-1800CC PETROL .....     | 1. K 04 |
| 1F | BATTERY AND FITTINGS.....          | 1. L 07 |
| 1G | BATTERY & CABLES.....              | 1. L 07 |
| 1H | BATTERY TRAY ASSY.....             | 1. L 08 |
| 1I | BURGLAR ALARM.....                 | 1. L 06 |
| 1J | BURGLAR ALARM.....                 | 1. L 06 |
| 1K | ECU AND SENSORS.....               | 1. K 03 |
| 2C | ECU'S AND SENSORS.....             | 1. K 03 |
| 2F | ELECTRICAL COMPONENTS.....         | 1. K 02 |
| 2H | ROTOR.....                         | 1. K 02 |
| 2I | FUSEBOX AND RELAYS.....            | 1. L 03 |
|    | FUSEBOX ASSY.....                  | 1. L 03 |
|    | RELAYS.....                        | 1. L 04 |
|    | HORN.....                          | 1. L 05 |
|    | HORN.....                          | 1. L 05 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1. K 02 |
|    | IGNITION COMPONENTS.....           | 1. K 02 |
|    | IN CAR ENTERTAINMENT.....          | 1. M 03 |
|    | AERIAL AND MOUNTING.....           | 1. M 06 |
|    | CD PLAYER AND FITTINGS.....        | 1. M 04 |
|    | RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |

|                                        |         |
|----------------------------------------|---------|
| SPEAKER AND FITTINGS.....              | 1. M 05 |
| INSTRUMENTS.....                       | 1. K 14 |
| INSTRUMENTS.....                       | 1. K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| LIGHTING.....                          | 1. K 08 |
| DOOR WARNING LAMPS.....                | 1. K 13 |
| DRIVING AND FOG LAMPS.....             | 1. K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| INTERIOR LAMPS.....                    | 1. K 12 |
| REAR LAMPS.....                        | 1. K 09 |
| STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
| SWITCHES.....                          | 1. K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
| SWITCHES - BODY.....                   | 1. K 16 |
| SWITCHES - DOOR.....                   | 1. L 02 |
| WIRING.....                            | 1. L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |



# SAMAND

L11

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### WIRING

#### HARNESS - FRONT DOOR LH

Illus Part Number

Description





Quantity

Change Point

Remarks

1 100 10 030  
2 100 10 031  
21 025 01 036  
22 025 11 002

Harness.-front door-LH..... 1  
Harness.-LH-front door-door switch pack..... 1  
Clip.-harness-harness-6.2mm-6.2mm..... 3  
Clip.-6.2mm-rear-harness..... 1



ZM0020

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS..... 1. K 04  
ALTERNATOR COMPONENTS..... 1. K 05  
ALTERNATOR-1800CC PETROL..... 1. K 04  
BATTERY AND FITTINGS..... 1. L 07  
BATTERY & CABLES..... 1. L 07  
BATTERY TRAY ASSY..... 1. L 08  
BURGLAR ALARM..... 1. L 06  
BURGLAR ALARM..... 1. L 06  
ECU AND SENSORS..... 1. K 03  
ECU'S AND SENSORS..... 1. K 03  
ELECTRICAL COMPONENTS..... 1. K 02  
ROTOR..... 1. K 02  
FUSEBOX AND RELAYS..... 1. L 03  
FUSEBOX ASSY..... 1. L 03  
RELAYS..... 1. L 04  
HORN..... 1. L 05  
HORN..... 1. L 05  
IGNITION AND ENGINE ELECTRICS..... 1. K 02  
IGNITION COMPONENTS..... 1. K 02  
IN CAR ENTERTAINMENT..... 1. M 03  
AERIAL AND MOUNTING..... 1. M 06  
CD PLAYER AND FITTINGS..... 1. M 04  
RADIO CASSETTE AND FITTINGS..... 1. M 03

SPEAKER AND FITTINGS..... 1. M 05  
INSTRUMENTS..... 1. K 14  
INSTRUMENTS..... 1. K 15  
SPEEDO CABLE AND FIXINGS..... 1. K 14  
LIGHTING..... 1. K 08  
DOOR WARNING LAMPS..... 1. K 13  
DRIVING AND FOG LAMPS..... 1. K 11  
HEADLAMPS & SIDE LAMPS..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE..... 1. K 10  
INTERIOR LAMPS..... 1. K 12  
REAR LAMPS..... 1. K 09  
STARTER MOTOR COMPONENTS..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP..... 1. K 06  
SWITCHES..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA..... 1. K 18  
SWITCHES - BODY..... 1. K 16  
SWITCHES - DOOR..... 1. L 02  
WIRING..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS..... 1. M 02

# SAMAND

L12

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### WIRING

#### HARNESS - FRONT DOOR RH

Illus Part Number

1 100 10 029  
21 025 01 036  
22 025 11 002



Description

Harness.-front door-RH ..... 1  
Clip.-harness-harness-6.2mm-6.2mm ..... 5  
Clip.-6.2mm-rear-harness..... 5

Quantity

Change Point

Remarks



ZM0019

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02

Illus Part Number

1 100 11 009  
1 100 11 010  
2 025 01 036



Description

Harness.-rear door-LH..... 1  
Harness.-rear door-RH..... 1  
Clip.-harness-harness-6.2mm-6.2mm ..... 3

Quantity

Change Point

Remarks



ZM0015

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS..... 1. K 04  
ALTERNATOR COMPONENTS..... 1. K 05  
ALTERNATOR-1800CC PETROL..... 1. K 04  
BATTERY AND FITTINGS..... 1. L 07  
BATTERY & CABLES..... 1. L 07  
BATTERY TRAY ASSY..... 1. L 08  
BURGLAR ALARM..... 1. L 06  
BURGLAR ALARM..... 1. L 06  
ECU AND SENSORS..... 1. K 03  
ECU'S AND SENSORS..... 1. K 03  
ELECTRICAL COMPONENTS..... 1. K 02  
ROTOR..... 1. K 02  
FUSEBOX AND RELAYS..... 1. L 03  
FUSEBOX ASSY..... 1. L 03  
RELAYS..... 1. L 04  
HORN..... 1. L 05  
HORN..... 1. L 05  
IGNITION AND ENGINE ELECTRICS..... 1. K 02  
IGNITION COMPONENTS..... 1. K 02  
IN CAR ENTERTAINMENT..... 1. M 03  
AERIAL AND MOUNTING..... 1. M 06  
CD PLAYER AND FITTINGS..... 1. M 04  
RADIO CASSETTE AND FITTINGS..... 1. M 03


SPEAKER AND FITTINGS..... 1. M 05  
INSTRUMENTS..... 1. K 14  
INSTRUMENTS..... 1. K 15  
SPEEDO CABLE AND FIXINGS..... 1. K 14  
LIGHTING..... 1. K 08  
DOOR WARNING LAMPS..... 1. K 13  
DRIVING AND FOG LAMPS..... 1. K 11  
HEADLAMPS & SIDE LAMPS..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE..... 1. K 10  
INTERIOR LAMPS..... 1. K 12  
REAR LAMPS..... 1. K 09  
STARTER MOTOR COMPONENTS..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP..... 1. K 06  
SWITCHES..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA..... 1. K 18  
SWITCHES - BODY..... 1. K 16  
SWITCHES - DOOR..... 1. L 02  
WIRING..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS..... 1. M 02

# SAMAND

L14


Fiche 1

## ELECTRICAL AND INSTRUMENTS WIRING HARNESS - MAIN (UNDER BONNET)



| Illus | Part Number |
|-------|-------------|
| 1     | 100 02 011  |
| 2     | 078 03 011  |
| 3     | 078 03 012  |
| 5     | 174 04 050  |
| 7     | 040 01 048  |
| 10    | 186 04 015  |

| Description                              | Quantity | Change Point | Remarks |
|------------------------------------------|----------|--------------|---------|
| Harness.-main-front.....                 | 1        |              |         |
| Cover.-main-harness .....                | 1        |              |         |
| Cover.-main-harness-front bulkhead ..... | 1        |              |         |
| Nut.-flanged head-M6 x 100 .....         | 6        |              |         |
| Screw.-flanged head-M6 x 100-20 .....    | 2        |              |         |
| Washer.-star-DE6 .....                   | 2        |              |         |



ZM0017

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX

|    |                                        |         |
|----|----------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS.....           | 1. K 04 |
| 1D | ALTERNATOR COMPONENTS.....             | 1. K 05 |
| 1E | ALTERNATOR-1800CC PETROL .....         | 1. K 04 |
| 1F | BATTERY AND FITTINGS.....              | 1. L 07 |
| 1G | BATTERY & CABLES .....                 | 1. L 07 |
| 1H | BATTERY TRAY ASSY .....                | 1. L 08 |
| 1I | BURGLAR ALARM .....                    | 1. L 06 |
| 1J | BURGLAR ALARM .....                    | 1. L 06 |
| 1K | ECU AND SENSORS .....                  | 1. K 03 |
| 2C | ECU'S AND SENSORS .....                | 1. K 03 |
| 2F | ELECTRICAL COMPONENTS .....            | 1. K 02 |
| 2H | ROTOR .....                            | 1. K 02 |
| 2I | FUSEBOX AND RELAYS.....                | 1. L 03 |
|    | FUSEBOX ASSY .....                     | 1. L 03 |
|    | RELAYS .....                           | 1. L 04 |
|    | HORN .....                             | 1. L 05 |
|    | HORN .....                             | 1. L 05 |
|    | IGNITION AND ENGINE ELECTRICS .....    | 1. K 02 |
|    | IGNITION COMPONENTS .....              | 1. K 02 |
|    | IN CAR ENTERTAINMENT .....             | 1. M 03 |
|    | AERIAL AND MOUNTING.....               | 1. M 06 |
|    | CD PLAYER AND FITTINGS.....            | 1. M 04 |
|    | RADIO CASSETTE AND FITTINGS.....       | 1. M 03 |
|    | SPEAKER AND FITTINGS.....              | 1. M 05 |
|    | INSTRUMENTS .....                      | 1. K 14 |
|    | INSTRUMENTS .....                      | 1. K 15 |
|    | SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
|    | LIGHTING .....                         | 1. K 08 |
|    | DOOR WARNING LAMPS.....                | 1. K 13 |
|    | DRIVING AND FOG LAMPS .....            | 1. K 11 |
|    | HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
|    | HIGH LEVEL STOP AND NUMBER PLATE ..... | 1. K 10 |
|    | INTERIOR LAMPS .....                   | 1. K 12 |
|    | REAR LAMPS.....                        | 1. K 09 |
|    | STARTER MOTOR COMPONENTS .....         | 1. K 07 |
|    | STARTER MOTOR INJECTION XU7 JP .....   | 1. K 06 |
|    | SWITCHES.....                          | 1. K 16 |
|    | SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
|    | SWITCHES - BODY.....                   | 1. K 16 |
|    | SWITCHES - DOOR.....                   | 1. L 02 |
|    | WIRING .....                           | 1. L 09 |
|    | SUPPLEMENTARY FRONT HARNESS .....      | 1. M 02 |

# SAMAND




L15

Fiche 1

ELECTRICAL AND INSTRUMENTS

WIRING

HARNESS - REAR BODY



ZM0016

X7 - Harness - Rear Body - Wiring

PERUTE LUBRICATIONS LTD.

Illus Part Number

Description

Quantity Change Remarks  
Point

1 100 13 011  
2 100 26 001  
3 025 07 020  
4 025 01 084  
5 025 11 002  
7 025 07 002  
8 025 01 113

Harness. rear-Lights.  
Harness.-bootlid.  
Clip.-harness-275mm  
Clip.  
Clip.-6.2mm-rear-harness  
Clip.-harness  
Clip.

1  
1  
5  
2  
3  
6  
1

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C ALTERNATOR AND FITTINGS.....1. K 04  
1D ALTERNATOR COMPONENTS.....1. K 05  
1E ALTERNATOR-1800CC PETROL.....1. K 04  
1F BATTERY AND FITTINGS.....1. L 07  
1G BATTERY & CABLES.....1. L 07  
1H BATTERY TRAY ASSY.....1. L 08  
1I BURGLAR ALARM.....1. L 06  
1J BURGLAR ALARM.....1. L 06  
1K ECU AND SENSORS.....1. K 03  
2C ECU'S AND SENSORS.....1. K 03  
2F ELECTRICAL COMPONENTS.....1. K 02  
2H ROTOR.....1. K 02  
2I FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

## GROUP INDEX

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XUT JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 16  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02

SAMAND

L16

Fiche 1

ELECTRICAL AND INSTRUMENTS

WIRING

HARNESS - HEATER ASSY

Illus Part Number

1 100 05 002


Description

Harness.-heater control-standard-Behr ..... 1

Quantity

Change Point

Remarks



ZM0010

MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 15  
SPEEDO CABLE AND FIXINGS ..... 1. K 14  
LIGHTING ..... 1. K 08  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02



# SAMAND

L17

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### WIRING

#### HARNESS - FRONT FASCIA

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 100 | 21 | 008 |
| 2 | 025 | 07 | 021 |
| 3 | 058 | 20 | 017 |



Description

|                           |   |
|---------------------------|---|
| Harness-front fascia..... | 1 |
| Clip.....                 | 7 |
| Fixing Clip.....          | 7 |

Quantity

Change Point

Remarks



ZM0014

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                    |        |
|------------------------------------|--------|
| ALTERNATOR AND FITTINGS.....       | 1.K 04 |
| ALTERNATOR COMPONENTS.....         | 1.K 05 |
| ALTERNATOR-1800CC PETROL.....      | 1.K 04 |
| BATTERY AND FITTINGS.....          | 1.L 07 |
| BATTERY & CABLES.....              | 1.L 07 |
| BATTERY TRAY ASSY.....             | 1.L 08 |
| BURGLAR ALARM.....                 | 1.L 06 |
| BURGLAR ALARM.....                 | 1.L 06 |
| ECU AND SENSORS.....               | 1.K 03 |
| ECU'S AND SENSORS.....             | 1.K 03 |
| ELECTRICAL COMPONENTS.....         | 1.K 02 |
| ROTOR.....                         | 1.K 02 |
| FUSEBOX AND RELAYS.....            | 1.L 03 |
| FUSEBOX ASSY.....                  | 1.L 03 |
| RELAYS.....                        | 1.L 04 |
| HORN.....                          | 1.L 05 |
| HORN.....                          | 1.L 05 |
| IGNITION AND ENGINE ELECTRICS..... | 1.K 02 |
| IGNITION COMPONENTS.....           | 1.K 02 |
| IN CAR ENTERTAINMENT.....          | 1.M 03 |
| AERIAL AND MOUNTING.....           | 1.M 06 |
| CD PLAYER AND FITTINGS.....        | 1.M 04 |
| RADIO CASSETTE AND FITTINGS.....   | 1.M 03 |

|                                        |        |
|----------------------------------------|--------|
| SPEAKER AND FITTINGS.....              | 1.M 05 |
| INSTRUMENTS.....                       | 1.K 14 |
| INSTRUMENTS.....                       | 1.K 15 |
| SPEEDO CABLE AND FIXINGS.....          | 1.K 14 |
| LIGHTING.....                          | 1.K 08 |
| DOOR WARNING LAMPS.....                | 1.K 13 |
| DRIVING AND FOG LAMPS.....             | 1.K 11 |
| HEADLAMPS & SIDE LAMPS.....            | 1.K 08 |
| HIGH LEVEL STOP AND NUMBER PLATE.....  | 1.K 10 |
| INTERIOR LAMPS.....                    | 1.K 12 |
| REAR LAMPS.....                        | 1.K 09 |
| STARTER MOTOR COMPONENTS.....          | 1.K 07 |
| STARTER MOTOR INJECTION XU7 JP.....    | 1.K 06 |
| SWITCHES.....                          | 1.K 16 |
| SWITCHES & DIGITAL CLOCK - FASCIA..... | 1.K 18 |
| SWITCHES - BODY.....                   | 1.K 16 |
| SWITCHES - DOOR.....                   | 1.L 02 |
| WIRING.....                            | 1.L 09 |
| SUPPLEMENTARY FRONT HARNESS.....       | 1.M 02 |



# SAMAND


L18

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### WIRING

#### HARNESS - INTERIOR LAMP



#### Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 100 | 12 | 011 |
| 2 | 025 | 01 | 084 |
| 3 | 007 | 02 | 006 |
| 4 | 025 | 01 | 084 |
| 5 | 025 | 07 | 015 |


#### Description

#### Quantity

#### Change Point

#### Remarks

|                                           |   |  |  |
|-------------------------------------------|---|--|--|
| Harness.-roof lamp .....                  | 1 |  |  |
| Clip.....                                 | 1 |  |  |
| foam pad-interior lamp-self adhesive..... | 6 |  |  |
| Clip.....                                 | 1 |  |  |
| Clip.-harness-17mm diameter .....         | 2 |  |  |



ZM0013

#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02


[illegible]

# SAMAND

## M02

### Fiche 1

## ELECTRICAL AND INSTRUMENTS WIRING SUPPLEMENTARY FRONT HARNESS



| Illus | Part Number |
|-------|-------------|
| 1     | 100 01 012  |
| 20    | 025 07 015  |
| 21    | 058 07 004  |
| 22    | 025 02 029  |
| 23    | 025 08 006  |
| 24    | 025 01 036  |
| 27    | 025 01 081  |
| 80    | 025 07 013  |


### Description

### Quantity

### Change Point

### Remarks

|                                        |   |  |  |
|----------------------------------------|---|--|--|
| Harness-headlamp-front panel .....     | 1 |  |  |
| Clip-harness-17mm diameter .....       | 4 |  |  |
| Fixing Clip-harness-1.50mm .....       | 4 |  |  |
| Clip-harness-17 x 14 .....             | 2 |  |  |
| Clip-harness-L10 pinc 12-14.5 .....    | 4 |  |  |
| Clip-harness-harness-6.2mm-6.2mm ..... | 3 |  |  |
| Clip-11-18 RAYMOND .....               | 2 |  |  |
| Clip-engine harness .....              | 4 |  |  |



ZM0012A

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1. K 04  
ALTERNATOR COMPONENTS ..... 1. K 05  
ALTERNATOR-1800CC PETROL ..... 1. K 04  
BATTERY AND FITTINGS ..... 1. L 07  
BATTERY & CABLES ..... 1. L 07  
BATTERY TRAY ASSY ..... 1. L 08  
BURGLAR ALARM ..... 1. L 06  
BURGLAR ALARM ..... 1. L 06  
ECU AND SENSORS ..... 1. K 03  
ECU'S AND SENSORS ..... 1. K 03  
ELECTRICAL COMPONENTS ..... 1. K 02  
ROTOR ..... 1. K 02  
FUSEBOX AND RELAYS ..... 1. L 03  
FUSEBOX ASSY ..... 1. L 03  
RELAYS ..... 1. L 04  
HORN ..... 1. L 05  
HORN ..... 1. L 05  
IGNITION AND ENGINE ELECTRICS ..... 1. K 02  
IGNITION COMPONENTS ..... 1. K 02  
IN CAR ENTERTAINMENT ..... 1. M 03  
AERIAL AND MOUNTING ..... 1. M 06  
CD PLAYER AND FITTINGS ..... 1. M 04  
RADIO CASSETTE AND FITTINGS ..... 1. M 03

SPEAKER AND FITTINGS ..... 1. M 05  
INSTRUMENTS ..... 1. K 14  
INSTRUMENTS ..... 1. K 14  
SPEEDO CABLE AND FIXINGS ..... 1. K 15  
LIGHTING ..... 1. K 14  
DOOR WARNING LAMPS ..... 1. K 13  
DRIVING AND FOG LAMPS ..... 1. K 11  
HEADLAMPS & SIDE LAMPS ..... 1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1. K 10  
INTERIOR LAMPS ..... 1. K 12  
REAR LAMPS ..... 1. K 09  
STARTER MOTOR COMPONENTS ..... 1. K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1. K 06  
SWITCHES ..... 1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1. K 18  
SWITCHES - BODY ..... 1. K 16  
SWITCHES - DOOR ..... 1. L 02  
WIRING ..... 1. L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1. M 02

Illus Part Number

1 215 01 006


Description

Radio Cassette ..... 1

Quantity

Change Point

Remarks



ZM0039

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS ..... 1.K 04  
ALTERNATOR COMPONENTS ..... 1.K 05  
ALTERNATOR-1800CC PETROL ..... 1.K 04  
BATTERY AND FITTINGS ..... 1.L 07  
BATTERY & CABLES ..... 1.L 07  
BATTERY TRAY ASSY ..... 1.L 08  
BURGLAR ALARM ..... 1.L 06  
BURGLAR ALARM ..... 1.L 06  
ECU AND SENSORS ..... 1.K 03  
ECU'S AND SENSORS ..... 1.K 03  
ELECTRICAL COMPONENTS ..... 1.K 02  
ROTOR ..... 1.K 02  
FUSEBOX AND RELAYS ..... 1.L 03  
FUSEBOX ASSY ..... 1.L 03  
RELAYS ..... 1.L 04  
HORN ..... 1.L 05  
HORN ..... 1.L 05  
IGNITION AND ENGINE ELECTRICS ..... 1.K 02  
IGNITION COMPONENTS ..... 1.K 02  
IN CAR ENTERTAINMENT ..... 1.M 03  
AERIAL AND MOUNTING ..... 1.M 06  
CD PLAYER AND FITTINGS ..... 1.M 04  
RADIO CASSETTE AND FITTINGS ..... 1.M 03

SPEAKER AND FITTINGS ..... 1.M 05  
INSTRUMENTS ..... 1.K 14  
INSTRUMENTS ..... 1.K 15  
SPEEDO CABLE AND FIXINGS ..... 1.K 14  
LIGHTING ..... 1.K 08  
DOOR WARNING LAMPS ..... 1.K 13  
DRIVING AND FOG LAMPS ..... 1.K 11  
HEADLAMPS & SIDE LAMPS ..... 1.K 08  
HIGH LEVEL STOP AND NUMBER PLATE ..... 1.K 10  
INTERIOR LAMPS ..... 1.K 12  
REAR LAMPS ..... 1.K 09  
STARTER MOTOR COMPONENTS ..... 1.K 07  
STARTER MOTOR INJECTION XU7 JP ..... 1.K 06  
SWITCHES ..... 1.K 16  
SWITCHES & DIGITAL CLOCK - FASCIA ..... 1.K 18  
SWITCHES - BODY ..... 1.K 16  
SWITCHES - DOOR ..... 1.L 02  
WIRING ..... 1.L 09  
SUPPLEMENTARY FRONT HARNESS ..... 1.M 02

# SAMAND

M04

Fiche 1

## ELECTRICAL AND INSTRUMENTS

### IN CAR ENTERTAINMENT

### CD PLAYER AND FITTINGS

Illus Part Number

1 220 01 001  
2 181 49 003  
3 181 49 004


Description

CD Changer..... 1  
Bracket.-cd player-LH..... 1  
Bracket.-cd player-RH..... 1

Quantity

Change Point

Remarks



ZM0046

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                    |         |                                        |         |
|----|------------------------------------|---------|----------------------------------------|---------|
| 1C | ALTERNATOR AND FITTINGS.....       | 1. K 04 | SPEAKER AND FITTINGS.....              | 1. M 05 |
| 1D | ALTERNATOR COMPONENTS.....         | 1. K 05 | INSTRUMENTS.....                       | 1. K 14 |
| 1E | ALTERNATOR-1800CC PETROL.....      | 1. K 04 | INSTRUMENTS.....                       | 1. K 15 |
| 1F | BATTERY AND FITTINGS.....          | 1. L 07 | SPEEDO CABLE AND FIXINGS.....          | 1. K 14 |
| 1G | BATTERY & CABLES.....              | 1. L 07 | LIGHTING.....                          | 1. K 08 |
| 1H | BATTERY TRAY ASSY.....             | 1. L 08 | DOOR WARNING LAMPS.....                | 1. K 13 |
| 1I | BURGLAR ALARM.....                 | 1. L 06 | DRIVING AND FOG LAMPS.....             | 1. K 11 |
| 1J | BURGLAR ALARM.....                 | 1. L 06 | HEADLAMPS & SIDE LAMPS.....            | 1. K 08 |
| 1K | ECU AND SENSORS.....               | 1. K 03 | HIGH LEVEL STOP AND NUMBER PLATE.....  | 1. K 10 |
| 2C | ECU'S AND SENSORS.....             | 1. K 03 | INTERIOR LAMPS.....                    | 1. K 12 |
| 2F | ELECTRICAL COMPONENTS.....         | 1. K 02 | REAR LAMPS.....                        | 1. K 09 |
| 2H | ROTOR.....                         | 1. K 02 | STARTER MOTOR COMPONENTS.....          | 1. K 07 |
| 2I | FUSEBOX AND RELAYS.....            | 1. L 03 | STARTER MOTOR INJECTION XU7 JP.....    | 1. K 06 |
|    | FUSEBOX ASSY.....                  | 1. L 03 | SWITCHES.....                          | 1. K 16 |
|    | RELAYS.....                        | 1. L 04 | SWITCHES & DIGITAL CLOCK - FASCIA..... | 1. K 18 |
|    | HORN.....                          | 1. L 05 | SWITCHES - BODY.....                   | 1. K 16 |
|    | HORN.....                          | 1. L 05 | SWITCHES - DOOR.....                   | 1. L 02 |
|    | IGNITION AND ENGINE ELECTRICS..... | 1. K 02 | WIRING.....                            | 1. L 09 |
|    | IGNITION COMPONENTS.....           | 1. K 02 | SUPPLEMENTARY FRONT HARNESS.....       | 1. M 02 |
|    | IN CAR ENTERTAINMENT.....          | 1. M 03 |                                        |         |
|    | AERIAL AND MOUNTING.....           | 1. M 06 |                                        |         |
|    | CD PLAYER AND FITTINGS.....        | 1. M 04 |                                        |         |
|    | RADIO CASSETTE AND FITTINGS.....   | 1. M 03 |                                        |         |

## Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 028 | 01 | 005 |
| 2 | 028 | 01 | 006 |
| 3 | 040 | 05 | 036 |



## Description

|                                  |    |
|----------------------------------|----|
| Speaker.-front-doors .....       | 2  |
| Speaker.-parcel shelf-rear ..... | 2  |
| Screw.-4.5 x 15 .....            | 16 |

## Quantity

## Change Point

## Remarks



ZM0038

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
RELAYS.....1. L 05  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03



SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02

# SAMAND

M06

Fiche 1

## ELECTRICAL AND INSTRUMENTS IN CAR ENTERTAINMENT AERIAL AND MOUNTING



### Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 012 | 01 | 002 |
| 2 | 137 | 05 | 005 |
| 3 | 040 | 22 | 061 |
| 4 | 174 | 20 | 001 |
| 5 | 181 | 33 | 004 |
| 6 | 186 | 24 | 030 |
| 7 | 181 | 33 | 003 |

### Description

|                                                      |   |
|------------------------------------------------------|---|
| Radio Aerial-assembly.....                           | 1 |
| Electrical Cable.-radio aerial.....                  | 1 |
| Screw.-electric aerial to body-M6 X 100 L20 STL..... | 1 |
| DAC500A.....                                         | 1 |
| Nut.....                                             | 1 |
| Bracket.....                                         | 1 |
| Washer.....                                          | 1 |
| Bracket.....                                         | 1 |

### Quantity

### Change Point

### Remarks

ZM0006

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

ALTERNATOR AND FITTINGS.....1. K 04  
ALTERNATOR COMPONENTS.....1. K 05  
ALTERNATOR-1800CC PETROL.....1. K 04  
BATTERY AND FITTINGS.....1. L 07  
BATTERY & CABLES.....1. L 07  
BATTERY TRAY ASSY.....1. L 08  
BURGLAR ALARM.....1. L 06  
BURGLAR ALARM.....1. L 06  
ECU AND SENSORS.....1. K 03  
ECU'S AND SENSORS.....1. K 03  
ELECTRICAL COMPONENTS.....1. K 02  
ROTOR.....1. K 02  
FUSEBOX AND RELAYS.....1. L 03  
FUSEBOX ASSY.....1. L 03  
RELAYS.....1. L 04  
RELAYS.....1. L 04  
HORN.....1. L 05  
HORN.....1. L 05  
IGNITION AND ENGINE ELECTRICS.....1. K 02  
IGNITION COMPONENTS.....1. K 02  
IN CAR ENTERTAINMENT.....1. M 03  
AERIAL AND MOUNTING.....1. M 06  
CD PLAYER AND FITTINGS.....1. M 04  
RADIO CASSETTE AND FITTINGS.....1. M 03

SPEAKER AND FITTINGS.....1. M 05  
INSTRUMENTS.....1. K 14  
INSTRUMENTS.....1. K 15  
SPEEDO CABLE AND FIXINGS.....1. K 14  
LIGHTING.....1. K 08  
DOOR WARNING LAMPS.....1. K 13  
DRIVING AND FOG LAMPS.....1. K 11  
HEADLAMPS & SIDE LAMPS.....1. K 08  
HIGH LEVEL STOP AND NUMBER PLATE.....1. K 10  
INTERIOR LAMPS.....1. K 12  
REAR LAMPS.....1. K 09  
STARTER MOTOR COMPONENTS.....1. K 07  
STARTER MOTOR INJECTION XU7 JP.....1. K 06  
SWITCHES.....1. K 16  
SWITCHES & DIGITAL CLOCK - FASCIA.....1. K 18  
SWITCHES - BODY.....1. K 16  
SWITCHES - DOOR.....1. L 02  
WIRING.....1. L 09  
SUPPLEMENTARY FRONT HARNESS.....1. M 02



# SAMAND

**B01**  
Fiche 2

## MASTER INDEX

|                                                                                                                               |                                                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|  ENGINE 1.C                                  |  ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE 2.C |
|  FLYWHEEL AND CLUTCH 1.D                      |  FACIA, TRIM, SEATS AND FIXINGS 2.F             |
|  GEARBOX 1.E                                 |  ACCESSORIES AND PAINT 2.H                      |
|  AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS 1.F | Numeric Index 2.I                                                                                                                  |
|  STEERING 1.G                                |                                                                                                                                    |
|  BRAKES AND BRAKE CONTROLS 1.H               |                                                                                                                                    |
|  FUEL, EXHAUST AND EMISSION SYSTEM 1.I      |                                                                                                                                    |
|  COOLING, HEATING AND AIR CONDITIONING 1.J  |                                                                                                                                    |
|  ELECTRICAL AND INSTRUMENTS 1.K            |                                                                                                                                    |

[illegible]

# SAMAND



C02  
Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE ENGINE MOUNTINGS ENGINE MOUNTINGS 1800cc

Illus Part Number

Description

Quantity Change Point Remarks



ZN0006

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

|    |            |                                 |   |
|----|------------|---------------------------------|---|
| 1  | 181 02 008 | Bracket.-RH                     | 1 |
| 2  | 181 02 002 | Bracket.-mounting-RH            | 1 |
| 3  | 160 02 003 | Rubber Cover.-suspension        | 1 |
| 4  | 111 03 004 | Buffer.-mounting-RH             | 1 |
| 5  | 111 03 001 | Buffer.                         | 1 |
| 6  | 186 01 169 | Washer.-10.2 x 17-13            | 3 |
| 7  | 111 03 005 | Buffer.-suspension              | 1 |
| 8  | 025 24 001 | Clip.                           | 1 |
| 10 | 181 02 017 | Bracket.-mounting-RH lower      | 1 |
| 11 | 098 01 001 | Suspension Link.-support        | 1 |
| 12 | 030 28 002 | Bush.-flexible                  | 1 |
| 13 | 040 01 088 | Screw.-cap head-M12 x 175-58    | 1 |
| 14 | 040 22 042 | Screw.-cap head                 | 1 |
| 15 | 030 28 001 | Bush.-flexible                  | 1 |
| 20 | 111 03 002 | Buffer.-LH                      | 1 |
| 21 | 042 15 004 | Dowel.-fixing                   | 1 |
| 22 | 186 01 083 | Washer.-14x48-3                 | 1 |
| 23 | 186 01 082 | Washer.-suspension              | 1 |
| 24 | 186 01 096 | Washer.-12 x 24                 | 1 |
| 40 | 083 06 005 | Safety Catch.-hoisting          | 2 |
| 41 | 040 02 095 | Screw.-socket head-M8 x 125-20  | 2 |
| 70 | 040 22 056 | Screw.-cap head-M10 x 125-80    | 1 |
| 71 | 186 03 081 | Washer.-flexible-M10 x 21.3-1   | 7 |
| 72 | 040 22 066 | Screw.-cap head-M10 x 150-70    | 2 |
| 73 | 040 03 026 | Screw.-10 x 150                 | 3 |
| 74 | 174 04 049 | Nut.-10 x 150                   | 4 |
| 75 | 040 02 056 | Screw.-M10 x 150-35             | 1 |
| 76 | 040 02 092 | Screw.-socket head-M10 x 150-70 | 2 |
| 77 | 174 08 001 | Nut.-caged-10 x 150             | 3 |
| 78 | 040 22 057 | Screw.-cap head-M8 x 100-35     | 4 |
| 79 | 174 02 003 | Nut.-self locking-10x150-9-17   | 1 |
| 80 | 174 04 009 | Nut.-self locking-12 X 175      | 2 |
| 81 | 174 04 026 | Nut.-with base-M7 x 100-6-14    | 2 |
| 82 | 040 22 058 | Screw.-M8 x 125-25              | 2 |


# SAMAND

C03

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE SUBFRAME AND FITTINGS SUBFRAME - FRONT

| Illus | Part Number | Description              | Quantity | Change Point | Remarks |
|-------|-------------|--------------------------|----------|--------------|---------|
| 1     | 073 01 001  | Subframe.-front.....     | 1        |              |         |
| 2     | 040 22 011  | Screw.-M10 x 150-45..... | 2        |              |         |
| 3     | 040 22 010  | Screw.-M14 x 2.0-60..... | 2        |              |         |
| 4     | 061 39 001  | Protectors. ....         | 2        |              |         |



ZN0019

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND

C04

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

BODY SHELL

Illus Part Number

1 024 03 004  
2 024 03 005



Description

Body Assy.-less doors, trunk lid and bonnet..... 1  
Body Assy. .... 1

Quantity

Change Point

Remarks



ZN0032

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND

C05

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

FRONT BULKHEAD

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 133 | 03 | 009 |
| 2  | 128 | 04 | 043 |
| 3  | 133 | 03 | 008 |
| 4  | 128 | 01 | 101 |
| 5  | 128 | 01 | 102 |
| 6  | 128 | 01 | 099 |
| 7  | 128 | 01 | 100 |
| 8  | 128 | 01 | 103 |
| 13 | 134 | 01 | 054 |
| 15 | 128 | 01 | 111 |
| 9  | 128 | 01 | 108 |
| 14 | 134 | 01 | 057 |
| 16 | 128 | 01 | 110 |
| 10 | 128 | 04 | 044 |
| 11 | 128 | 07 | 031 |
| 12 | 181 | 16 | 038 |
| 12 | 181 | 16 | 039 |


Description

Quantity

Change Point

Remarks

|                                           |   |  |  |
|-------------------------------------------|---|--|--|
| ASSEMBLY-FRONT END .....                  | 1 |  |  |
| • Panel.-radiator support .....           | 1 |  |  |
| • Assembly .....                          | 1 |  |  |
| • Panel.-front inner-LH .....             | 1 |  |  |
| • Panel.-front inner-RH .....             | 1 |  |  |
| • Panel.-front inner-LH .....             | 1 |  |  |
| • Panel.-front inner-RH .....             | 1 |  |  |
| • PANEL.-WHEELARCH AND SIDE RAIL-LH ..... | 1 |  |  |
| • Rail.-LH .....                          | 1 |  |  |
| • Panel.-LH .....                         | 1 |  |  |
| • PANEL.-WHEELARCH AND SIDE RAIL-RH ..... | 1 |  |  |
| • Rail.-RH .....                          | 1 |  |  |
| • Panel.-RH .....                         | 1 |  |  |
| • Panel.-dash .....                       | 1 |  |  |
| • Panel.-front floor .....                | 1 |  |  |
| Bracket.-front bumper -LH .....           | 1 |  |  |
| Bracket.-front bumper -RH .....           | 1 |  |  |



## MASTER INDEX

|                                         |    |
|-----------------------------------------|----|
| ENGINE                                  | 1C |
| FLYWHEEL AND CLUTCH                     | 1D |
| GEARBOX                                 | 1E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS | 1F |
| STEERING                                | 1G |
| BRAKES AND BRAKE CONTROLS               | 1H |
| FUEL, EXHAUST AND EMISSION SYSTEM       | 1I |
| COOLING, HEATING AND AIR CONDITIONING   | 1J |
| ELECTRICAL AND INSTRUMENTS              | 1K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-  | 2C |
| FACIA, TRIM, SEATS AND FIXINGS          | 2F |
| ACCESSORIES AND PAINT                   | 2H |
| Numeric Index                           | 2I |

## GROUP INDEX

|                                      |        |
|--------------------------------------|--------|
| BODY SHELL .....                     | 2.C 04 |
| BODY SHELL .....                     | 2.C 04 |
| BODYSIDE PANELS .....                | 2.C 08 |
| FRONT BULKHEAD .....                 | 2.C 05 |
| FRONT END SIDE MEMBERS .....         | 2.C 06 |
| MAIN FLOOR .....                     | 2.C 06 |
| REAR FLOOR .....                     | 2.C 07 |
| REAR PANELS .....                    | 2.C 10 |
| ROOF .....                           | 2.C 09 |
| STONEGUARD .....                     | 2.C 11 |
| BONNET AND FITTINGS .....            | 2.C 13 |
| BONNET AND FITTINGS .....            | 2.C 13 |
| BONNET RELEASE AND CABLE .....       | 2.C 14 |
| BONNET SEALS .....                   | 2.C 15 |
| BUMPER AND FITTINGS .....            | 2.D 15 |
| FRONT BUMPER AND FITTINGS .....      | 2.D 15 |
| REAR BUMPER AND FITTINGS .....       | 2.D 16 |
| DOOR HANDELS, LOCKS, GLASS AND ..... | 2.C 18 |
| DOOR GLASS .....                     | 2.D 02 |
| DOOR SEALS .....                     | 2.D 06 |
| FRONT DOOR HANDELS AND LOCKS .....   | 2.C 18 |
| FRONT WINDOW REGULATORS .....        | 2.D 03 |
| REAR DOOR HANDELS AND LATCHES .....  | 2.D 04 |

|                                     |        |
|-------------------------------------|--------|
| REAR WINDOW REGULATORS .....        | 2.D 05 |
| DOORS .....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS .....       | 2.C 16 |
| REAR DOOR AND FITTINGS .....        | 2.C 17 |
| ENGINE MOUNTINGS .....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc .....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS .....   | 2.D 17 |
| BADGES .....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS .....   | 2.E 04 |
| FINISHERS .....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS .....   | 2.E 02 |
| WHEEL ARCH LINERS .....             | 2.D 17 |
| FIXED GLASS .....                   | 2.D 10 |
| BACKLIGHT .....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS .....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS .....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS ..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS .....  | 2.D 09 |
| FUEL FILLER LID .....               | 2.D 09 |
| MIRRORS .....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS ..... | 2.D 14 |
| SUBFRAME AND FITTINGS .....         | 2.C 03 |
| SUBFRAME - FRONT .....              | 2.C 03 |

|                                  |        |
|----------------------------------|--------|
| SUBFRAME - REAR .....            | 2.C 04 |
| TRUNK LID AND FITTINGS .....     | 2.D 07 |
| TRUNK LID AND FITTINGS .....     | 2.D 07 |
| TRUNK LID LOCK AND LATCHES ..... | 2.D 08 |
| WIPERS AND WASHERS .....         | 2.D 12 |
| HEADLAMP WASH .....              | 2.D 12 |
| WINDSCREEN WASH .....            | 2.D 13 |
| WINDSCREEN WIPERS .....          | 2.D 12 |



# SAMAND

C06

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

MAIN FLOOR

Illus Part Number

1 128 07 032  
2 181 35 007  
3 134 02 025  
4 134 02 026  
5 134 01 052  
6 134 01 053


Description

Panel.-front seat ..... 1  
Bracket.-front seat ..... 1  
Rail.-rear-LH ..... 1  
Rail.-rear-RH ..... 1  
Rail.-inner rear-LH ..... 1  
Rail.-inner rear-RH ..... 1

Quantity

Change Point

Remarks



ZN0034

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL ..... 2. C 04  
BODY SHELL ..... 2. C 04  
BODYSIDE PANELS ..... 2. C 08  
FRONT BULKHEAD ..... 2. C 05  
FRONT END SIDE MEMBERS ..... 2. C 06  
MAIN FLOOR ..... 2. C 06  
REAR FLOOR ..... 2. C 07  
REAR PANELS ..... 2. C 10  
ROOF ..... 2. C 09  
STONEGUARD ..... 2. C 11  
BONNET AND FITTINGS ..... 2. C 13  
BONNET AND FITTINGS ..... 2. C 13  
BONNET RELEASE AND CABLE ..... 2. C 14  
BONNET SEALS ..... 2. C 15  
BUMPER AND FITTINGS ..... 2. D 15  
FRONT BUMPER AND FITTINGS ..... 2. D 15  
REAR BUMPER AND FITTINGS ..... 2. D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2. C 18  
DOOR GLASS ..... 2. D 02  
DOOR SEALS ..... 2. D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2. C 18  
FRONT WINDOW REGULATORS ..... 2. D 03  
REAR DOOR HANDELS AND LATCHES ..... 2. D 04

REAR WINDOW REGULATORS ..... 2. D 05  
DOORS ..... 2. C 16  
FRONT DOOR AND FITTINGS ..... 2. C 16  
REAR DOOR AND FITTINGS ..... 2. C 17  
ENGINE MOUNTINGS ..... 2. C 02  
ENGINE MOUNTINGS 1800cc ..... 2. C 02  
FINISHERS, BADGES AND PLUGS ..... 2. D 17  
BADGES ..... 2. E 03  
BLANKING PLUGS AND GROMMETS ..... 2. E 04  
FINISHERS ..... 2. D 18  
RUBBING STRIPS AND FITTINGS ..... 2. E 02  
WHEEL ARCH LINERS ..... 2. D 17  
FIXED GLASS ..... 2. D 10  
BACKLIGHT ..... 2. D 11  
WINDSCREEN AND FITTINGS ..... 2. D 10  
FRONT FENDERS AND FITTINGS ..... 2. C 12  
FENDER AND FRONT END FITTINGS ..... 2. C 12  
FUEL FILLER LID AND FITTINGS ..... 2. D 09  
FUEL FILLER LID ..... 2. D 09  
MIRRORS ..... 2. D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2. D 14  
SUBFRAME AND FITTINGS ..... 2. C 03  
SUBFRAME - FRONT ..... 2. C 03

SUBFRAME - REAR ..... 2. C 04  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID LOCK AND LATCHES ..... 2. D 08  
WIPERS AND WASHERS ..... 2. D 12  
HEADLAMP WASH ..... 2. D 12  
WINDSCREEN WASH ..... 2. D 13  
WINDSCREEN WIPERS ..... 2. D 12



# SAMAND

C07

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

REAR FLOOR

Illus Part Number

|    |            |
|----|------------|
| 1  | 134 02 022 |
| 2  | 128 07 033 |
| 3  | 128 14 005 |
| 4  | 134 02 027 |
| 5  | 134 02 028 |
| 6  | 134 01 055 |
| 7  | 134 01 056 |
| 8  | 133 04 021 |
| 9  | 181 23 006 |
| 10 | 128 07 034 |
| 11 | 133 04 022 |
| 12 | 133 04 023 |



Description

Quantity

Change Point

Remarks

|                                     |   |  |  |
|-------------------------------------|---|--|--|
| RAIL.-TRUNK FLOOR.....              | 1 |  |  |
| • Panel.-rear axle .....            | 1 |  |  |
| • Panel.-rear seat belt fixing..... | 1 |  |  |
| • Rail.-LH .....                    | 1 |  |  |
| • Rail.-RH .....                    | 1 |  |  |
| • Rail.-front-LH.....               | 1 |  |  |
| • Rail.-front-RH .....              | 1 |  |  |
| ASSEMBLY.-TRUNK FLOOR. ....         | 1 |  |  |
| • Bracket.-rear seat .....          | 1 |  |  |
| • Panel.-lower.....                 | 1 |  |  |
| • Assembly.-trunk floor.-front..... | 1 |  |  |
| • Assembly.-spare wheel well.....   | 1 |  |  |



ZN0037

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2 C 04 |
| BODY SHELL.....                     | 2 C 04 |
| BODYSIDE PANELS .....               | 2 C 08 |
| FRONT BULKHEAD .....                | 2 C 05 |
| FRONT END SIDE MEMBERS .....        | 2 C 06 |
| MAIN FLOOR.....                     | 2 C 06 |
| REAR FLOOR.....                     | 2 C 07 |
| REAR PANELS .....                   | 2 C 10 |
| ROOF.....                           | 2 C 09 |
| STONEGUARD.....                     | 2 C 11 |
| BONNET AND FITTINGS.....            | 2 C 13 |
| BONNET AND FITTINGS.....            | 2 C 13 |
| BONNET RELEASE AND CABLE .....      | 2 C 14 |
| BONNET SEALS .....                  | 2 C 15 |
| BUMPER AND FITTINGS.....            | 2 D 15 |
| FRONT BUMPER AND FITTINGS .....     | 2 D 15 |
| REAR BUMPER AND FITTINGS .....      | 2 D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2 C 18 |
| DOOR GLASS .....                    | 2 D 02 |
| DOOR SEALS.....                     | 2 D 06 |
| FRONT DOOR HANDELS AND LOCKS .....  | 2 C 18 |
| FRONT WINDOW REGULATORS.....        | 2 D 03 |
| REAR DOOR HANDELS AND LATCHES ..... | 2 D 04 |

|                                     |        |
|-------------------------------------|--------|
| REAR WINDOW REGULATORS.....         | 2 D 05 |
| DOORS.....                          | 2 C 16 |
| FRONT DOOR AND FITTINGS .....       | 2 C 16 |
| REAR DOOR AND FITTINGS .....        | 2 C 17 |
| ENGINE MOUNTINGS.....               | 2 C 02 |
| ENGINE MOUNTINGS 1800cc .....       | 2 C 02 |
| FINISHERS, BADGES AND PLUGS.....    | 2 D 17 |
| BADGES.....                         | 2 E 03 |
| BLANKING PLUGS AND GROMMETS.....    | 2 E 04 |
| FINISHERS.....                      | 2 D 18 |
| RUBBING STRIPS AND FITTINGS.....    | 2 E 02 |
| WHEEL ARCH LINERS.....              | 2 D 17 |
| FIXED GLASS .....                   | 2 D 10 |
| BACKLIGHT.....                      | 2 D 11 |
| WINDSCREEN AND FITTINGS .....       | 2 D 10 |
| FRONT FENDERS AND FITTINGS .....    | 2 C 12 |
| FENDER AND FRONT END FITTINGS ..... | 2 C 12 |
| FUEL FILLER LID AND FITTINGS.....   | 2 D 09 |
| FUEL FILLER LID.....                | 2 D 09 |
| MIRRORS.....                        | 2 D 14 |
| INTERIOR AND EXTERIOR MIRRORS ..... | 2 D 14 |
| SUBFRAME AND FITTINGS .....         | 2 C 03 |
| SUBFRAME - FRONT .....              | 2 C 03 |

|                                  |        |
|----------------------------------|--------|
| SUBFRAME - REAR .....            | 2 C 04 |
| TRUNK LID AND FITTINGS.....      | 2 D 07 |
| TRUNK LID AND FITTINGS.....      | 2 D 07 |
| TRUNK LID LOCK AND LATCHES ..... | 2 D 08 |
| WIPERS AND WASHERS.....          | 2 D 12 |
| HEADLAMP WASH.....               | 2 D 12 |
| WINDSCREEN WASH .....            | 2 D 13 |
| WINDSCREEN WIPERS.....           | 2 D 12 |

# SAMAND

C08

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

BODYSIDE PANELS

Illus Part Number

1 227 01 004  
1 227 01 005  
2 130 02 016  
2 130 02 017


Description

Body Side.-LH..... 1  
Body Side.-RH..... 1  
Sill.-inner-LH..... 1  
Sill.-inner-RH..... 1

Quantity

Change Point

Remarks



ZN0035

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL..... 2. C 04  
BODY SHELL..... 2. C 04  
BODYSIDE PANELS..... 2. C 08  
FRONT BULKHEAD..... 2. C 05  
FRONT END SIDE MEMBERS..... 2. C 06  
MAIN FLOOR..... 2. C 06  
REAR FLOOR..... 2. C 07  
REAR PANELS..... 2. C 10  
ROOF..... 2. C 09  
STONEGUARD..... 2. C 11  
BONNET AND FITTINGS..... 2. C 13  
BONNET AND FITTINGS..... 2. C 13  
BONNET RELEASE AND CABLE..... 2. C 14  
BONNET SEALS..... 2. C 15  
BUMPER AND FITTINGS..... 2. D 15  
FRONT BUMPER AND FITTINGS..... 2. D 15  
REAR BUMPER AND FITTINGS..... 2. D 16  
DOOR HANDELS, LOCKS, GLASS AND..... 2. C 18  
DOOR GLASS..... 2. D 02  
DOOR SEALS..... 2. D 06  
FRONT DOOR HANDELS AND LOCKS..... 2. C 18  
FRONT WINDOW REGULATORS..... 2. D 03  
REAR DOOR HANDELS AND LATCHES..... 2. D 04

REAR WINDOW REGULATORS..... 2. D 05  
DOORS..... 2. C 16  
FRONT DOOR AND FITTINGS..... 2. C 16  
REAR DOOR AND FITTINGS..... 2. C 17  
ENGINE MOUNTINGS..... 2. C 02  
ENGINE MOUNTINGS 1800cc..... 2. C 02  
FINISHERS, BADGES AND PLUGS..... 2. D 17  
BADGES..... 2. E 03  
BLANKING PLUGS AND GROMMETS..... 2. E 04  
FINISHERS..... 2. D 18  
RUBBING STRIPS AND FITTINGS..... 2. E 02  
WHEEL ARCH LINERS..... 2. D 17  
FIXED GLASS..... 2. D 10  
BACKLIGHT..... 2. D 11  
WINDSCREEN AND FITTINGS..... 2. D 10  
FRONT FENDERS AND FITTINGS..... 2. C 12  
FENDER AND FRONT END FITTINGS..... 2. C 12  
FUEL FILLER LID AND FITTINGS..... 2. D 09  
FUEL FILLER LID..... 2. D 09  
MIRRORS..... 2. D 14  
INTERIOR AND EXTERIOR MIRRORS..... 2. D 14  
SUBFRAME AND FITTINGS..... 2. C 03  
SUBFRAME - FRONT..... 2. C 03


SUBFRAME - REAR..... 2. C 04  
TRUNK LID AND FITTINGS..... 2. D 07  
TRUNK LID AND FITTINGS..... 2. D 07  
TRUNK LID LOCK AND LATCHES..... 2. D 08  
WIPERS AND WASHERS..... 2. D 12  
HEADLAMP WASH..... 2. D 12  
WINDSCREEN WASH..... 2. D 13  
WINDSCREEN WIPERS..... 2. D 12

# SAMAND

C09  
Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE BODY SHELL ROOF

| Illus | Part Number | Description                | Quantity | Change Point | Remarks |
|-------|-------------|----------------------------|----------|--------------|---------|
| 1     | 132 01 009  | ROOF PANEL.-ASSEMBLY ..... | 1        |              |         |
| 2     | 128 12 025  | • Panel.-front .....       | 1        |              |         |
| 3     | 128 12 026  | • Panel.-rear .....        | 1        |              |         |
| 4     | 128 12 027  | • Panel.-roof bow .....    | 1        |              |         |



ZN0036

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND

C10

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

### BODY SHELL

### REAR PANELS

Illus Part Number

|    |            |
|----|------------|
| 1  | 135 02 031 |
| 2  | 129 03 006 |
| 3  | 128 01 104 |
| 4  | 128 13 002 |
| 5  | 128 01 106 |
| 1  | 135 02 030 |
| 2  | 129 03 007 |
| 3  | 128 01 105 |
| 4  | 184 03 004 |
| 5  | 128 01 107 |
| 6  | 181 56 006 |
| 7  | 181 56 005 |
| 8  | 128 04 045 |
| 9  | 133 12 001 |
| 10 | 133 05 003 |
| 11 | 133 05 002 |


Description

Quantity

Change Point

Remarks

|                                   |   |  |  |
|-----------------------------------|---|--|--|
| FENDER.-REAR QUARTER-LH.....      | 1 |  |  |
| • Support.-rear lamp-LH.....      | 1 |  |  |
| PANEL.-REAR QUARTER INNER-LH..... | 1 |  |  |
| • Panel.-LH.....                  | 1 |  |  |
| • Panel.-inner wheelarch-LH.....  | 1 |  |  |
| FENDER.-REAR QUARTER-RH.....      | 1 |  |  |
| • Support.-rear lamp-RH.....      | 1 |  |  |
| PANEL.-REAR QUARTER INNER-RH..... | 1 |  |  |
| • Air Box.-RH.....                | 1 |  |  |
| • Panel.-inner wheelarch-RH.....  | 1 |  |  |
| Bracket.-parcel shelf.....        | 1 |  |  |
| Bracket.-parcel shelf.....        | 1 |  |  |
| Panel.-rear decking.....          | 1 |  |  |
| Assembly.-seat back.....          | 1 |  |  |
| ASSEMBLY.-REAR END.....           | 1 |  |  |
| • Assembly.-lower body.....       | 1 |  |  |



ZN0038

PENTEC INTERNATIONAL LTD

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2 C 04 |
| BODY SHELL.....                     | 2 C 04 |
| BODYSIDE PANELS.....                | 2 C 08 |
| FRONT BULKHEAD.....                 | 2 C 05 |
| FRONT END SIDE MEMBERS.....         | 2 C 06 |
| MAIN FLOOR.....                     | 2 C 06 |
| REAR FLOOR.....                     | 2 C 07 |
| REAR PANELS.....                    | 2 C 10 |
| ROOF.....                           | 2 C 09 |
| STONEGUARD.....                     | 2 C 11 |
| BONNET AND FITTINGS.....            | 2 C 13 |
| BONNET AND FITTINGS.....            | 2 C 13 |
| BONNET RELEASE AND CABLE.....       | 2 C 14 |
| BONNET SEALS.....                   | 2 C 15 |
| BUMPER AND FITTINGS.....            | 2 D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2 D 15 |
| REAR BUMPER AND FITTINGS.....       | 2 D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2 C 18 |
| DOOR GLASS.....                     | 2 D 02 |
| DOOR SEALS.....                     | 2 D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2 C 18 |
| FRONT WINDOW REGULATORS.....        | 2 D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2 D 04 |

|                                    |        |
|------------------------------------|--------|
| REAR WINDOW REGULATORS.....        | 2 D 05 |
| DOORS.....                         | 2 C 16 |
| FRONT DOOR AND FITTINGS.....       | 2 C 16 |
| REAR DOOR AND FITTINGS.....        | 2 C 17 |
| ENGINE MOUNTINGS.....              | 2 C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2 C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2 D 17 |
| BADGES.....                        | 2 E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2 E 04 |
| FINISHERS.....                     | 2 D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2 E 02 |
| WHEEL ARCH LINERS.....             | 2 D 17 |
| FIXED GLASS.....                   | 2 D 10 |
| BACKLIGHT.....                     | 2 D 11 |
| WINDSCREEN AND FITTINGS.....       | 2 D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2 C 12 |
| FENDER AND FRONT END FITTINGS..... | 2 C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2 D 09 |
| FUEL FILLER LID.....               | 2 D 09 |
| MIRRORS.....                       | 2 D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2 D 14 |
| SUBFRAME AND FITTINGS.....         | 2 C 03 |
| SUBFRAME - FRONT.....              | 2 C 03 |

|                                 |        |
|---------------------------------|--------|
| SUBFRAME - REAR.....            | 2 C 04 |
| TRUNK LID AND FITTINGS.....     | 2 D 07 |
| TRUNK LID AND FITTINGS.....     | 2 D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2 D 08 |
| WIPERS AND WASHERS.....         | 2 D 12 |
| HEADLAMP WASH.....              | 2 D 12 |
| WINDSCREEN WASH.....            | 2 D 13 |
| WINDSCREEN WIPERS.....          | 2 D 12 |

# SAMAND


C11

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BODY SHELL

STONEGUARD



Illus Part Number

1 133 01 003  
2 030 22 041  
3 186 01 124  
4 040 01 085  
70 058 07 018  
72 174 04 026  
73 186 02 022


Description

Assembly.-engine and gearbox..... 1  
Bush.-stoneguard to body..... 2  
Washer.-stoneguard to body-engine and gearbox.... 2  
Screw.-cap head-M8 x 125-25..... 4  
Fixing Clip.-M8 x 125-engine and gearbox ..... 1  
Nut.-stoneguard to body-with base-M7 x 100-6- ..... 3  
14.....  
Washer.-stoneguard to body-flexible.-8 x 17 ..... 3

Quantity

Change Point

Remarks



ZN0060

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL..... 2.C 04  
BODY SHELL..... 2.C 04  
BODYSIDE PANELS..... 2.C 08  
FRONT BULKHEAD..... 2.C 05  
FRONT END SIDE MEMBERS..... 2.C 08  
MAIN FLOOR..... 2.C 06  
REAR FLOOR..... 2.C 07  
REAR PANELS..... 2.C 10  
ROOF..... 2.C 09  
STONEGUARD..... 2.C 11  
BONNET AND FITTINGS..... 2.C 13  
BONNET AND FITTINGS..... 2.C 13  
BONNET RELEASE AND CABLE..... 2.C 14  
BONNET SEALS..... 2.C 15  
BUMPER AND FITTINGS..... 2.D 15  
FRONT BUMPER AND FITTINGS..... 2.D 15  
REAR BUMPER AND FITTINGS..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND..... 2.C 18  
DOOR GLASS..... 2.D 02  
DOOR SEALS..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS..... 2.C 18  
FRONT WINDOW REGULATORS..... 2.D 03  
REAR DOOR HANDELS AND LATCHES..... 2.D 04

REAR WINDOW REGULATORS..... 2.D 05  
DOORS..... 2.C 16  
FRONT DOOR AND FITTINGS..... 2.C 17  
REAR DOOR AND FITTINGS..... 2.C 17  
ENGINE MOUNTINGS..... 2.C 02  
ENGINE MOUNTINGS 1800cc..... 2.C 02  
FINISHERS, BADGES AND PLUGS..... 2.D 17  
BADGES..... 2.E 03  
BLANKING PLUGS AND GROMMETS..... 2.E 04  
FINISHERS..... 2.D 18  
RUBBING STRIPS AND FITTINGS..... 2.E 02  
WHEEL ARCH LINERS..... 2.D 17  
FIXED GLASS..... 2.D 10  
BACKLIGHT..... 2.D 11  
WINDSCREEN AND FITTINGS..... 2.D 10  
FRONT FENDERS AND FITTINGS..... 2.C 12  
FENDER AND FRONT END FITTINGS..... 2.C 12  
FUEL FILLER LID AND FITTINGS..... 2.D 09  
FUEL FILLER LID..... 2.D 09  
MIRRORS..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS..... 2.D 14  
SUBFRAME AND FITTINGS..... 2.C 03  
SUBFRAME - FRONT..... 2.C 03

SUBFRAME - REAR..... 2.C 04  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID LOCK AND LATCHES..... 2.D 08  
WIPERS AND WASHERS..... 2.D 12  
HEADLAMP WASH..... 2.D 12  
WINDSCREEN WASH..... 2.D 13  
WINDSCREEN WIPERS..... 2.D 12




# SAMAND

C12


Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FRONT FENDERS AND FITTINGS FENDER AND FRONT END FITTINGS



| Illus | Part Number |
|-------|-------------|
| 1     | 135 01 029  |
| 1     | 135 01 030  |
| 2     | 040 01 282  |
| 3     | 040 01 281  |

| Description              | Quantity | Change Point | Remarks |
|--------------------------|----------|--------------|---------|
| Fender.-front-LH .....   | 1        |              |         |
| Fender.-front-RH .....   | 1        |              |         |
| Screw.-M6 x 100-20 ..... | 14       |              |         |
| Screw.-M6 x 100-25 ..... | 30       |              |         |



ZN0039

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                      |        |                                     |        |                                  |        |
|--------------------------------------|--------|-------------------------------------|--------|----------------------------------|--------|
| BODY SHELL .....                     | 2.C 04 | REAR WINDOW REGULATORS .....        | 2.D 05 | SUBFRAME - REAR .....            | 2.C 04 |
| DOORS .....                          | 2.C 16 | TRUNK LID AND FITTINGS .....        | 2.D 07 | TRUNK LID AND FITTINGS .....     | 2.D 07 |
| FRONT BULKHEAD .....                 | 2.C 05 | TRUNK LID LOCK AND LATCHES .....    | 2.D 08 | TRUNK LID LOCK AND LATCHES ..... | 2.D 08 |
| FRONT END SIDE MEMBERS .....         | 2.C 06 | WIPERS AND WASHERS .....            | 2.D 12 | WIPERS AND WASHERS .....         | 2.D 12 |
| MAIN FLOOR .....                     | 2.C 06 | HEADLAMP WASH .....                 | 2.D 12 | HEADLAMP WASH .....              | 2.D 12 |
| REAR FLOOR .....                     | 2.C 07 | WINDSCREEN WASH .....               | 2.D 13 | WINDSCREEN WASH .....            | 2.D 13 |
| REAR PANELS .....                    | 2.C 10 | WINDSCREEN WIPERS .....             | 2.D 12 | WINDSCREEN WIPERS .....          | 2.D 12 |
| ROOF .....                           | 2.C 09 |                                     |        |                                  |        |
| STONEGUARD .....                     | 2.C 11 |                                     |        |                                  |        |
| BONNET AND FITTINGS .....            | 2.C 13 |                                     |        |                                  |        |
| BONNET RELEASE AND CABLE .....       | 2.C 14 |                                     |        |                                  |        |
| BONNET SEALS .....                   | 2.C 15 |                                     |        |                                  |        |
| BUMPER AND FITTINGS .....            | 2.D 15 |                                     |        |                                  |        |
| FRONT BUMPER AND FITTINGS .....      | 2.D 15 |                                     |        |                                  |        |
| REAR BUMPER AND FITTINGS .....       | 2.D 16 |                                     |        |                                  |        |
| DOOR HANDELS, LOCKS, GLASS AND ..... | 2.C 18 |                                     |        |                                  |        |
| DOOR GLASS .....                     | 2.D 02 |                                     |        |                                  |        |
| DOOR SEALS .....                     | 2.D 06 |                                     |        |                                  |        |
| FRONT DOOR HANDELS AND LOCKS .....   | 2.C 18 |                                     |        |                                  |        |
| FRONT WINDOW REGULATORS .....        | 2.D 03 |                                     |        |                                  |        |
| REAR DOOR HANDELS AND LATCHES .....  | 2.D 04 |                                     |        |                                  |        |
|                                      |        | REAR WINDOW REGULATORS .....        | 2.D 05 |                                  |        |
|                                      |        | DOORS .....                         | 2.C 16 |                                  |        |
|                                      |        | FRONT DOOR AND FITTINGS .....       | 2.C 16 |                                  |        |
|                                      |        | REAR DOOR AND FITTINGS .....        | 2.C 17 |                                  |        |
|                                      |        | ENGINE MOUNTINGS .....              | 2.C 02 |                                  |        |
|                                      |        | ENGINE MOUNTINGS 1800cc .....       | 2.C 02 |                                  |        |
|                                      |        | FINISHERS, BADGES AND PLUGS .....   | 2.D 17 |                                  |        |
|                                      |        | BADGES .....                        | 2.E 03 |                                  |        |
|                                      |        | BLANKING PLUGS AND GROMMETS .....   | 2.E 04 |                                  |        |
|                                      |        | FINISHERS .....                     | 2.D 18 |                                  |        |
|                                      |        | RUBBING STRIPS AND FITTINGS .....   | 2.E 02 |                                  |        |
|                                      |        | WHEEL ARCH LINERS .....             | 2.D 17 |                                  |        |
|                                      |        | FIXED GLASS .....                   | 2.D 10 |                                  |        |
|                                      |        | BACKLIGHT .....                     | 2.D 11 |                                  |        |
|                                      |        | WINDSCREEN AND FITTINGS .....       | 2.D 10 |                                  |        |
|                                      |        | FRONT FENDERS AND FITTINGS .....    | 2.C 12 |                                  |        |
|                                      |        | FENDER AND FRONT END FITTINGS ..... | 2.C 12 |                                  |        |
|                                      |        | FUEL FILLER LID AND FITTINGS .....  | 2.D 09 |                                  |        |
|                                      |        | FUEL FILLER LID .....               | 2.D 09 |                                  |        |
|                                      |        | MIRRORS .....                       | 2.D 14 |                                  |        |
|                                      |        | INTERIOR AND EXTERIOR MIRRORS ..... | 2.D 14 |                                  |        |
|                                      |        | SUBFRAME AND FITTINGS .....         | 2.C 03 |                                  |        |
|                                      |        | SUBFRAME - FRONT .....              | 2.C 03 |                                  |        |

# SAMAND

C13

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BONNET AND FITTINGS

BONNET AND FITTINGS

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 060 | 05 | 012 |
| 2 | 083 | 11 | 006 |
| 3 | 164 | 03 | 012 |
| 3 | 164 | 03 | 011 |
| 4 | 040 | 01 | 281 |
| 5 | 178 | 07 | 004 |
| 6 | 025 | 01 | 108 |
| 7 | 025 | 01 | 107 |



Description

|                                  |   |
|----------------------------------|---|
| DOOR ASSY.....                   | 1 |
| • Safety Catch.....              | 1 |
| Hinge.-assembly-RH.....          | 1 |
| Hinge.-bonnet-assembly-LH.....   | 1 |
| Screw.-M6 x 100-25.....          | 4 |
| Link.-bonnet.....                | 1 |
| Clip.....                        | 1 |
| Clip.-bonnet stay fastening..... | 1 |

Quantity

Change Point

Remarks



ZN0040

## MASTER INDEX

## GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12



# SAMAND


C14

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

### BONNET AND FITTINGS

### BONNET RELEASE AND CABLE



#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 138 | 03 | 015 |
| 2  | 083 | 11 | 005 |
| 3  | 015 | 11 | 004 |
| 4  | 058 | 10 | 004 |
| 5  | 040 | 22 | 036 |
| 6  | 186 | 01 | 176 |
| 7  | 136 | 03 | 004 |
| 8  | 083 | 11 | 002 |
| 9  | 040 | 14 | 014 |
| 10 | 025 | 01 | 087 |


#### Description

|                                                  |   |
|--------------------------------------------------|---|
| Control Cable.-bonnet release .....              | 1 |
| Safety Catch.-assembly-bonnet.-with spring ..... | 1 |
| assist.....                                      | 1 |
| Lever.-bonnet release .....                      | 1 |
| Fixing Clip.-bonnet release .....                | 1 |
| Screw.-flanged-M6 x 100-35.....                  | 1 |
| Washer.-plain-6 x 18.....                        | 1 |
| Lock.-bonnet.....                                | 1 |
| Safety Catch.-bonnet.....                        | 1 |
| Screw.-flanged-M6 x 100-22-inner.....            | 2 |
| Clip.....                                        | 2 |

#### Quantity

#### Change Point

#### Remarks



ZN0001

#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03  
SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND

C15

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

BONNET AND FITTINGS

BONNET SEALS

Illus Part Number

1 182 02 012  
2 182 02 013


Description

Rubber Seal.-bonnet front ..... 1  
Rubber Seal.-bonnet rear ..... 1

Quantity

Change Point

Remarks



ZN0056

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL ..... 2.C 04  
BODY SHELL ..... 2.C 04  
BODYSIDE PANELS ..... 2.C 08  
FRONT BULKHEAD ..... 2.C 05  
FRONT END SIDE MEMBERS ..... 2.C 06  
MAIN FLOOR ..... 2.C 06  
REAR FLOOR ..... 2.C 07  
REAR PANELS ..... 2.C 10  
ROOF ..... 2.C 09  
STONEGUARD ..... 2.C 11  
BONNET AND FITTINGS ..... 2.C 13  
BONNET AND FITTINGS ..... 2.C 13  
BONNET RELEASE AND CABLE ..... 2.C 14  
BONNET SEALS ..... 2.C 15  
BUMPER AND FITTINGS ..... 2.D 15  
FRONT BUMPER AND FITTINGS ..... 2.D 15  
REAR BUMPER AND FITTINGS ..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2.C 18  
DOOR GLASS ..... 2.D 02  
DOOR SEALS ..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2.C 18  
FRONT WINDOW REGULATORS ..... 2.D 03  
REAR DOOR HANDELS AND LATCHES ..... 2.D 04

REAR WINDOW REGULATORS ..... 2.D 05  
DOORS ..... 2.C 16  
FRONT DOOR AND FITTINGS ..... 2.C 16  
REAR DOOR AND FITTINGS ..... 2.C 17  
ENGINE MOUNTINGS ..... 2.C 02  
ENGINE MOUNTINGS 1800cc ..... 2.C 02  
FINISHERS, BADGES AND PLUGS ..... 2.D 17  
BADGES ..... 2.E 03  
BLANKING PLUGS AND GROMMETS ..... 2.E 04  
FINISHERS ..... 2.D 18  
RUBBING STRIPS AND FITTINGS ..... 2.E 02  
WHEEL ARCH LINERS ..... 2.D 17  
FIXED GLASS ..... 2.D 10  
BACKLIGHT ..... 2.D 11  
WINDSCREEN AND FITTINGS ..... 2.D 10  
FRONT FENDERS AND FITTINGS ..... 2.C 12  
FENDER AND FRONT END FITTINGS ..... 2.C 12  
FUEL FILLER LID AND FITTINGS ..... 2.D 09  
FUEL FILLER LID ..... 2.D 09  
MIRRORS ..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2.D 14  
SUBFRAME AND FITTINGS ..... 2.C 03  
SUBFRAME - FRONT ..... 2.C 03

SUBFRAME - REAR ..... 2.C 04  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID LOCK AND LATCHES ..... 2.D 08  
WIPERS AND WASHERS ..... 2.D 12  
HEADLAMP WASH ..... 2.D 12  
WINDSCREEN WASH ..... 2.D 13  
WINDSCREEN WIPERS ..... 2.D 13

# SAMAND



C16

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

DOORS

FRONT DOOR AND FITTINGS



Illus Part Number

1 060 01 012  
2 060 01 013  
3 181 41 007  
4 164 01 013  
5 164 02 012  
6 174 04 026  
7 040 01 281

1 060 02 012  
2 060 02 013  
3 181 41 007  
4 164 01 014  
5 164 02 014  
6 174 04 026  
7 040 01 281

8 061 21 012  
9 061 21 011

Description

DOOR ASSY.-FRONT-LH ..... 1  
• Door Assy.-outer-front door-LH ..... 1  
• Bracket.-front door ..... 1  
Hinge.-front door-LH upper ..... 1  
Hinge.-front door-LH lower ..... 1  
Nut.-with base-M7 x 100-6-14 ..... 2  
Screw.-M6 x 100-25 ..... 4

DOOR ASSY.-RH-FRONT ..... 1  
• Door Assy.-outer-front door-RH ..... 1  
Bracket.-front door ..... 1  
Hinge.-front door-RH upper ..... 1  
Hinge.-front door-RH lower ..... 1  
Nut.-with base-M7 x 100-6-14 ..... 2  
Screw.-M6 x 100-25 ..... 4

Cap. .... 6  
Cap. .... 2

Quantity

Change Point

Remarks

ZG0004

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL ..... 2. C 04  
BODY SHELL ..... 2. C 04  
BODYSIDE PANELS ..... 2. C 08  
FRONT BULKHEAD ..... 2. C 05  
FRONT END SIDE MEMBERS ..... 2. C 06  
MAIN FLOOR ..... 2. C 06  
REAR FLOOR ..... 2. C 07  
REAR PANELS ..... 2. C 10  
ROOF ..... 2. C 09  
STONEGUARD ..... 2. C 11  
BONNET AND FITTINGS ..... 2. C 13  
BONNET AND FITTINGS ..... 2. C 13  
BONNET RELEASE AND CABLE ..... 2. C 14  
BONNET SEALS ..... 2. C 15  
BUMPER AND FITTINGS ..... 2. D 15  
FRONT BUMPER AND FITTINGS ..... 2. D 15  
REAR BUMPER AND FITTINGS ..... 2. D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2. C 18  
DOOR GLASS ..... 2. D 02  
DOOR SEALS ..... 2. D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2. C 18  
FRONT WINDOW REGULATORS ..... 2. D 03  
REAR DOOR HANDELS AND LATCHES ..... 2. D 04

REAR WINDOW REGULATORS ..... 2. D 05  
DOORS ..... 2. C 16  
FRONT DOOR AND FITTINGS ..... 2. C 16  
REAR DOOR AND FITTINGS ..... 2. C 17  
ENGINE MOUNTINGS ..... 2. C 02  
ENGINE MOUNTINGS 1800cc ..... 2. C 02  
FINISHERS, BADGES AND PLUGS ..... 2. D 17  
BADGES ..... 2. E 03  
BLANKING PLUGS AND GROMMETS ..... 2. E 04  
FINISHERS ..... 2. D 18  
RUBBING STRIPS AND FITTINGS ..... 2. E 02  
WHEEL ARCH LINERS ..... 2. D 17  
FIXED GLASS ..... 2. D 10  
BACKLIGHT ..... 2. D 11  
WINDSCREEN AND FITTINGS ..... 2. D 10  
FRONT FENDERS AND FITTINGS ..... 2. C 12  
FENDER AND FRONT END FITTINGS ..... 2. C 12  
FUEL FILLER LID AND FITTINGS ..... 2. D 09  
FUEL FILLER LID ..... 2. D 09  
MIRRORS ..... 2. D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2. D 14  
SUBFRAME AND FITTINGS ..... 2. C 03  
SUBFRAME - FRONT ..... 2. C 03

SUBFRAME - REAR ..... 2. C 04  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID LOCK AND LATCHES ..... 2. D 08  
WIPERS AND WASHERS ..... 2. D 12  
HEADLAMP WASH ..... 2. D 12  
WINDSCREEN WASH ..... 2. D 13  
WINDSCREEN WIPERS ..... 2. D 12

# SAMAND



C17

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOORS

### REAR DOOR AND FITTINGS

| Illus | Part Number | Description                            | Quantity | Change Point | Remarks |
|-------|-------------|----------------------------------------|----------|--------------|---------|
| 1     | 060 03 015  | DOOR ASSY.-REAR-LH.....                | 1        |              |         |
| 2     | 198 02 005  | • Door Panel.-rear-LH.....             | 1        |              |         |
| 3     | 164 02 016  | Hinge.-rear door upper-LH.....         | 1        |              |         |
| 4     | 164 02 012  | Hinge.-front door-LH lower.....        | 1        |              |         |
| 1     | 060 04 015  | DOOR ASSY.-REAR DOOR-RH.....           | 1        |              |         |
| 2     | 198 02 006  | • Door Panel.-rear door-outer RH.....  | 1        |              |         |
| 3     | 164 02 017  | Hinge.-rear door upper-RH.....         | 1        |              |         |
| 4     | 164 02 014  | Hinge.-front door-RH lower.....        | 1        |              |         |
| 5     | 181 41 009  | Bracket.-rear door.....                | 2        |              |         |
| 6     | 174 04 026  | Nut.-with base-M7 x 100-6-14.....      | 4        |              |         |
| 7     | 040 01 281  | Screw.-M6 x 100-25.....                | 8        |              |         |
| 8     | 061 21 007  | Protectors.-rear door lower hinge..... | 2        |              |         |
| 9     | 061 21 012  | Cap.....                               | 2        |              |         |



ZN0041

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03  
SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12



پایگاه اینترنتی آب و آهن و آتش (مهندسی مکانیک)

# SAMAND

## C18

### Fiche 2

#### ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS FRONT DOOR HANDELS AND LOCKS



ZP0023

#### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 063 | 04 | 008 |
| 1  | 063 | 05 | 008 |
| 2  | 126 | 09 | 021 |
| 2  | 126 | 09 | 022 |
| 4  | 136 | 01 | 016 |
| 4  | 136 | 01 | 011 |
| 5  | 178 | 02 | 056 |
| 5  | 178 | 02 | 057 |
| 6  | 178 | 02 | 049 |
| 6  | 178 | 02 | 050 |
| 7  | 178 | 02 | 058 |
| 7  | 178 | 02 | 059 |
| 8  | 007 | 02 | 004 |
| 10 | 058 | 04 | 009 |
| 18 | 169 | 01 | 001 |
| 19 | 058 | 04 | 006 |
| 20 | 205 | 02 | 034 |
| 21 | 083 | 07 | 001 |
| 71 | 040 | 02 | 080 |
| 72 | 040 | 01 | 113 |
| 73 | 040 | 01 | 291 |
| 74 | 174 | 04 | 045 |

#### Description

|                                     |   |
|-------------------------------------|---|
| Handle.-front door-LH.....          | 1 |
| Handle.-front door-RH.....          | 1 |
| Trim.-front door-LH.....            | 1 |
| Trim.-front door-RH.....            | 1 |
| Lock.-front door lock-LH.....       | 1 |
| Lock.-front door lock-RH.....       | 1 |
| Link.-door lock-front LH.....       | 1 |
| Link.-door lock-front RH.....       | 1 |
| Link.-front door-LH.....            | 1 |
| Link.-front door-RH.....            | 1 |
| Link.-lock barrel-LH.....           | 1 |
| Link.-lock barrel-RH.....           | 1 |
| foam pad-door lock.....             | 2 |
| Fixing Clip.-lock barrel.....       | 2 |
| Actuator.-door locks-front.....     | 2 |
| Fixing Clip.....                    | 2 |
| Grommet.-door lock front-Black..... | 4 |
| Safety Catch.-door lock.....        | 2 |
| Screw.-M6 x 100-12.....             | 6 |
| Screw.-cap head-M6 x 100-20.....    | 2 |
| Screw.-with washer-M6 x 100-20..... | 4 |
| Nut.-with washer-M6.....            | 2 |

#### Quantity

#### Change Point

#### Remarks

#### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

#### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 07  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12





# SAMAND

D02

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS DOOR GLASS

Illus Part Number

|   |            |
|---|------------|
| 1 | 107 05 023 |
| 1 | 107 05 024 |
| 2 | 107 06 023 |
| 2 | 107 06 024 |
| 3 | 030 22 044 |
| 4 | 025 13 004 |
| 5 | 025 13 003 |
| 6 | 107 03 016 |
| 6 | 107 03 017 |
| 7 | 182 03 104 |
| 7 | 182 03 105 |


Description

|                                     |   |
|-------------------------------------|---|
| Glass.-Tinted..-front door-LH ..... | 1 |
| Glass.-Tinted..-front door-RH ..... | 1 |
| Glass.-Tinted..-rear door-LH .....  | 1 |
| Glass.-Tinted..-rear door-RH .....  | 1 |
| Bush.....                           | 4 |
| Clip.....                           | 4 |
| Clip.....                           | 4 |
| Glass.-rear door-LH .....           | 1 |
| Glass.-rear door-RH .....           | 1 |
| Rubber Seal.-rear door-LH .....     | 1 |
| Rubber Seal.-rear door-RH .....     | 1 |

Quantity

Change Point

Remarks



ZN0028

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL..... 2.C 04  
BODY SHELL..... 2.C 04  
BODYSIDE PANELS..... 2.C 08  
FRONT BULKHEAD..... 2.C 05  
FRONT END SIDE MEMBERS..... 2.C 06  
MAIN FLOOR..... 2.C 06  
REAR FLOOR..... 2.C 07  
REAR PANELS..... 2.C 10  
ROOF..... 2.C 09  
STONEGUARD..... 2.C 11  
BONNET AND FITTINGS..... 2.C 13  
BONNET AND FITTINGS..... 2.C 13  
BONNET RELEASE AND CABLE..... 2.C 14  
BONNET SEALS..... 2.C 15  
BUMPER AND FITTINGS..... 2.D 15  
FRONT BUMPER AND FITTINGS..... 2.D 15  
REAR BUMPER AND FITTINGS..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND..... 2.C 18  
DOOR GLASS..... 2.D 02  
DOOR SEALS..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS..... 2.C 18  
FRONT WINDOW REGULATORS..... 2.D 03  
REAR DOOR HANDELS AND LATCHES..... 2.D 04

REAR WINDOW REGULATORS..... 2.D 05  
DOORS..... 2.C 16  
FRONT DOOR AND FITTINGS..... 2.C 16  
REAR DOOR AND FITTINGS..... 2.C 17  
ENGINE MOUNTINGS..... 2.C 02  
ENGINE MOUNTINGS 1800cc..... 2.C 02  
FINISHERS, BADGES AND PLUGS..... 2.D 17  
BADGES..... 2.E 03  
BLANKING PLUGS AND GROMMETS..... 2.E 04  
FINISHERS..... 2.D 18  
RUBBING STRIPS AND FITTINGS..... 2.E 02  
WHEEL ARCH LINERS..... 2.D 17  
FIXED GLASS..... 2.D 10  
BACKLIGHT..... 2.D 11  
WINDSCREEN AND FITTINGS..... 2.D 10  
FRONT FENDERS AND FITTINGS..... 2.C 12  
FENDER AND FRONT END FITTINGS..... 2.C 12  
FUEL FILLER LID AND FITTINGS..... 2.D 09  
FUEL FILLER LID..... 2.D 09  
MIRRORS..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS..... 2.D 14  
SUBFRAME AND FITTINGS..... 2.C 03  
SUBFRAME - FRONT..... 2.C 03

SUBFRAME - REAR..... 2.C 04  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID LOCK AND LATCHES..... 2.D 08  
WIPERS AND WASHERS..... 2.D 12  
HEADLAMP WASH..... 2.D 12  
WINDSCREEN WASH..... 2.D 13  
WINDSCREEN WIPERS..... 2.D 12



# SAMAND

D03

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS FRONT WINDOW REGULATORS

Illus Part Number

|   |        |     |
|---|--------|-----|
| 1 | 182 03 | 108 |
| 1 | 182 03 | 109 |
| 2 | 217 01 | 008 |
| 2 | 217 01 | 009 |
| 3 | 174 04 | 044 |
| 4 | 079 01 | 036 |
| 4 | 079 01 | 037 |
| 5 | 174 04 | 029 |
| 6 | 075 13 | 002 |



Description

|                                    |    |
|------------------------------------|----|
| Rubber Seal.-front door-LH .....   | 1  |
| Rubber Seal.-front door-RH .....   | 1  |
| Window Lifter.-front door-LH ..... | 1  |
| Window Lifter.-front door-RH ..... | 1  |
| Nut.-flanged-M6 x 100-12 .....     | 10 |
| Slide.-insert-front door-LH .....  | 1  |
| Slide.-insert-front door-RH .....  | 1  |
| Nut.-flanged-M6 .....              | 4  |
| Relay.-electric window lift .....  | 1  |

Quantity

Change Point

Remarks



7P0031

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX

|    |                                      |        |
|----|--------------------------------------|--------|
| 1C | BODY SHELL .....                     | 2.C 04 |
| 1D | BODY SHELL .....                     | 2.C 04 |
| 1E | BODYSIDE PANELS .....                | 2.C 08 |
| 1F | FRONT BULKHEAD .....                 | 2.C 05 |
| 1G | FRONT END SIDE MEMBERS .....         | 2.C 06 |
| 1H | MAIN FLOOR .....                     | 2.C 06 |
| 1I | REAR FLOOR .....                     | 2.C 07 |
| 1J | REAR PANELS .....                    | 2.C 10 |
| 1K | ROOF .....                           | 2.C 09 |
| 2C | STONEGUARD .....                     | 2.C 11 |
| 2F | BONNET AND FITTINGS .....            | 2.C 13 |
| 2H | BONNET AND FITTINGS .....            | 2.C 13 |
| 2I | BONNET RELEASE AND CABLE .....       | 2.C 14 |
|    | BONNET SEALS .....                   | 2.C 15 |
|    | BUMPER AND FITTINGS .....            | 2.D 15 |
|    | FRONT BUMPER AND FITTINGS .....      | 2.D 15 |
|    | REAR BUMPER AND FITTINGS .....       | 2.D 16 |
|    | DOOR HANDELS, LOCKS, GLASS AND ..... | 2.C 18 |
|    | DOOR GLASS .....                     | 2.D 02 |
|    | DOOR SEALS .....                     | 2.D 06 |
|    | FRONT DOOR HANDELS AND LOCKS .....   | 2.C 18 |
|    | FRONT WINDOW REGULATORS .....        | 2.D 03 |
|    | REAR DOOR HANDELS AND LATCHES .....  | 2.D 04 |


|                                     |        |
|-------------------------------------|--------|
| REAR WINDOW REGULATORS .....        | 2.D 05 |
| DOORS .....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS .....       | 2.C 16 |
| REAR DOOR AND FITTINGS .....        | 2.C 17 |
| ENGINE MOUNTINGS .....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc .....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS .....   | 2.D 17 |
| BADGES .....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS .....   | 2.E 04 |
| FINISHERS .....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS .....   | 2.E 02 |
| WHEEL ARCH LINERS .....             | 2.D 17 |
| FIXED GLASS .....                   | 2.D 10 |
| BACKLIGHT .....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS .....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS .....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS ..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS .....  | 2.D 09 |
| FUEL FILLER LID .....               | 2.D 09 |
| MIRRORS .....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS ..... | 2.D 14 |
| SUBFRAME AND FITTINGS .....         | 2.C 03 |
| SUBFRAME - FRONT .....              | 2.C 03 |
| SUBFRAME - REAR .....               | 2.C 04 |
| TRUNK LID AND FITTINGS .....        | 2.D 07 |
| TRUNK LID AND FITTINGS .....        | 2.D 07 |
| TRUNK LID LOCK AND LATCHES .....    | 2.D 08 |
| WIPERS AND WASHERS .....            | 2.D 12 |
| HEADLAMP WASH .....                 | 2.D 12 |
| WINDSCREEN WASH .....               | 2.D 13 |
| WINDSCREEN WIPERS .....             | 2.D 12 |

# SAMAND

D04

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS REAR DOOR HANDELS AND LATCHES



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 063 | 04 | 010 |
| 1  | 063 | 05 | 010 |
| 2  | 126 | 09 | 023 |
| 2  | 126 | 09 | 024 |
| 5  | 136 | 01 | 016 |
| 5  | 136 | 01 | 011 |
| 6  | 178 | 02 | 051 |
| 6  | 178 | 02 | 052 |
| 7  | 178 | 02 | 053 |
| 7  | 178 | 02 | 054 |
| 8  | 178 | 02 | 060 |
| 8  | 178 | 02 | 061 |
| 3  | 040 | 01 | 113 |
| 4  | 174 | 04 | 045 |
| 5  | 136 | 01 | 021 |
| 5  | 136 | 01 | 023 |
| 9  | 169 | 01 | 002 |
| 10 | 058 | 20 | 019 |
| 11 | 015 | 08 | 005 |
| 12 | 040 | 02 | 080 |
| 13 | 040 | 01 | 291 |
| 14 | 025 | 01 | 056 |
| 15 | 083 | 07 | 001 |
| 16 | 007 | 02 | 004 |
| 17 | 058 | 04 | 006 |

Description

Quantity

Change Point

Remarks

|                                     |   |  |  |
|-------------------------------------|---|--|--|
| Handle.-rear door-LH.....           | 1 |  |  |
| Handle.-rear door-RH.....           | 1 |  |  |
| Trim.-rear door-LH.....             | 1 |  |  |
| Trim.-rear door-RH.....             | 1 |  |  |
| Lock.-rear door lock-LH.....        | 1 |  |  |
| Lock.-rear door lock-RH.....        | 1 |  |  |
| Link.-door lock-rear LH.....        | 1 |  |  |
| Link.-door lock-rear RH.....        | 1 |  |  |
| Link.-door lock-rear LH.....        | 1 |  |  |
| Link.-door lock-rear RH.....        | 1 |  |  |
| Link.-door lock-rear LH.....        | 1 |  |  |
| Link.-door lock-rear RH.....        | 1 |  |  |
| COMMON                              |   |  |  |
| Screw.-cap head-M6 x 100-20.....    | 2 |  |  |
| Nut.-with washer-M6.....            | 2 |  |  |
| Lock.-LH.....                       | 1 |  |  |
| Lock.-RH.....                       | 1 |  |  |
| Actuator.-rear door lock.....       | 2 |  |  |
| Fixing Clip.-rear door lock.....    | 2 |  |  |
| Lever.-rear door lock.....          | 2 |  |  |
| Screw.-M6 x 100-12.....             | 6 |  |  |
| Screw.-with washer-M6 x 100-20..... | 4 |  |  |
| Clip.-rear door lock.....           | 4 |  |  |
| Safety Catch.-door lock.....        | 2 |  |  |
| foam pad-door lock.....             | 2 |  |  |
| Fixing Clip.....                    | 2 |  |  |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |         |
|-------------------------------------|---------|
| BODY SHELL.....                     | 2. C 04 |
| BODY SHELL.....                     | 2. C 04 |
| BODYSIDE PANELS.....                | 2. C 08 |
| FRONT BULKHEAD.....                 | 2. C 05 |
| FRONT END SIDE MEMBERS.....         | 2. C 06 |
| MAIN FLOOR.....                     | 2. C 06 |
| REAR FLOOR.....                     | 2. C 07 |
| REAR PANELS.....                    | 2. C 10 |
| ROOF.....                           | 2. C 09 |
| STONEGUARD.....                     | 2. C 11 |
| BONNET AND FITTINGS.....            | 2. C 13 |
| BONNET AND FITTINGS.....            | 2. C 13 |
| BONNET RELEASE AND CABLE.....       | 2. C 14 |
| BONNET SEALS.....                   | 2. C 15 |
| BUMPER AND FITTINGS.....            | 2. D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2. D 15 |
| REAR BUMPER AND FITTINGS.....       | 2. D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2. C 18 |
| DOOR GLASS.....                     | 2. D 02 |
| DOOR SEALS.....                     | 2. D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2. C 18 |
| FRONT WINDOW REGULATORS.....        | 2. D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2. D 04 |

|                                    |         |
|------------------------------------|---------|
| REAR WINDOW REGULATORS.....        | 2. D 05 |
| DOORS.....                         | 2. C 16 |
| FRONT DOOR AND FITTINGS.....       | 2. C 16 |
| REAR DOOR AND FITTINGS.....        | 2. C 17 |
| ENGINE MOUNTINGS.....              | 2. C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2. C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2. D 17 |
| BADGES.....                        | 2. E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2. E 04 |
| FINISHERS.....                     | 2. D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2. E 02 |
| WHEEL ARCH LINERS.....             | 2. D 17 |
| FIXED GLASS.....                   | 2. D 10 |
| BACKLIGHT.....                     | 2. D 11 |
| WINDSCREEN AND FITTINGS.....       | 2. D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2. C 12 |
| FENDER AND FRONT END FITTINGS..... | 2. C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2. D 09 |
| FUEL FILLER LID.....               | 2. D 09 |
| MIRRORS.....                       | 2. D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2. D 14 |
| SUBFRAME AND FITTINGS.....         | 2. C 03 |
| SUBFRAME - FRONT.....              | 2. C 03 |



|                                 |         |
|---------------------------------|---------|
| SUBFRAME - REAR.....            | 2. C 04 |
| TRUNK LID AND FITTINGS.....     | 2. D 07 |
| TRUNK LID AND FITTINGS.....     | 2. D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2. D 08 |
| WIPERS AND WASHERS.....         | 2. D 12 |
| HEADLAMP WASH.....              | 2. D 12 |
| WINDSCREEN WASH.....            | 2. D 13 |
| WINDSCREEN WIPERS.....          | 2. D 12 |

# SAMAND

D05

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS REAR WINDOW REGULATORS



ZN0051

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 182 | 03 | 106 |
| 1 | 182 | 03 | 107 |
| 2 | 217 | 02 | 004 |
| 2 | 217 | 02 | 005 |
| 3 | 174 | 04 | 044 |
| 4 | 079 | 01 | 038 |
| 4 | 079 | 01 | 039 |
| 5 | 174 | 04 | 029 |
| 6 | 079 | 01 | 040 |
| 6 | 079 | 01 | 041 |
| 7 | 040 | 14 | 081 |
| 8 | 040 | 05 | 032 |

Description

|                                                |    |
|------------------------------------------------|----|
| Rubber Seal.-insert-rear door-LH.....          | 1  |
| Rubber Seal.-insert-rear door-RH.....          | 1  |
| Window Lifter.-rear door-LH.....               | 1  |
| Window Lifter.-rear door-RH.....               | 1  |
| Nut.-regulator fixing-flanged-M6 x 100-12..... | 10 |
| Slide.-rear door-LH.....                       | 1  |
| Slide.-rear door-RH.....                       | 1  |
| Nut.-slide fixings-flanged-M6.....             | 4  |
| Slide.-rear door-LH.....                       | 1  |
| Slide.-rear door-RH.....                       | 1  |
| Screw.-support fixing-4.2 x 8.5.....           | 2  |
| Screw.-support fixing-M6 x 100-12.....         | 2  |

Quantity

Change Point

Remarks

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2.C 04 |
| BODY SHELL.....                     | 2.C 04 |
| BODYSIDE PANELS.....                | 2.C 08 |
| FRONT BULKHEAD.....                 | 2.C 05 |
| FRONT END SIDE MEMBERS.....         | 2.C 06 |
| MAIN FLOOR.....                     | 2.C 06 |
| FRONT FLOOR.....                    | 2.C 07 |
| REAR FLOOR.....                     | 2.C 07 |
| REAR PANELS.....                    | 2.C 10 |
| ROOF.....                           | 2.C 09 |
| STONEGUARD.....                     | 2.C 11 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET RELEASE AND CABLE.....       | 2.C 14 |
| BONNET SEALS.....                   | 2.C 15 |
| BUMPER AND FITTINGS.....            | 2.D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2.D 15 |
| REAR BUMPER AND FITTINGS.....       | 2.D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2.C 18 |
| DOOR GLASS.....                     | 2.D 02 |
| DOOR SEALS.....                     | 2.D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2.C 18 |
| FRONT WINDOW REGULATORS.....        | 2.D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2.D 04 |

|                                    |        |
|------------------------------------|--------|
| REAR WINDOW REGULATORS.....        | 2.D 05 |
| DOORS.....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS.....       | 2.C 16 |
| REAR DOOR AND FITTINGS.....        | 2.C 17 |
| ENGINE MOUNTINGS.....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2.D 17 |
| BADGES.....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2.E 04 |
| FINISHERS.....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2.E 02 |
| WHEEL ARCH LINERS.....             | 2.D 17 |
| FIXED GLASS.....                   | 2.D 10 |
| BACKLIGHT.....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS.....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2.D 09 |
| FUEL FILLER LID.....               | 2.D 09 |
| MIRRORS.....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2.D 14 |
| SUBFRAME AND FITTINGS.....         | 2.C 03 |
| SUBFRAME - FRONT.....              | 2.C 03 |

|                                 |        |
|---------------------------------|--------|
| SUBFRAME - REAR.....            | 2.C 04 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2.D 08 |
| WIPERS AND WASHERS.....         | 2.D 12 |
| HEADLAMP WASH.....              | 2.D 12 |
| WINDSCREEN WASH.....            | 2.D 13 |
| WINDSCREEN WIPERS.....          | 2.D 12 |


# SAMAND

D06

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE DOOR HANDELS, LOCKS, GLASS AND FITTINGS DOOR SEALS

Illus Part Number



ZN0054

| Description                          | Quantity | Change Point | Remarks |
|--------------------------------------|----------|--------------|---------|
| Rubber Seal.-front door-LH .....     | 1        |              |         |
| Rubber Seal.-front door-RH .....     | 1        |              |         |
| Rubber Seal.-rear door-LH .....      | 1        |              |         |
| Rubber Seal.-rear door-RH .....      | 1        |              |         |
| Protector.-front door-outer LH ..... | 1        |              |         |
| Protector.-front door-outer RH ..... | 1        |              |         |
| Protector.-front door-inner LH ..... | 1        |              |         |
| Protector.-front door-inner RH ..... | 1        |              |         |
| Protector.-rear door-outer LH .....  | 1        |              |         |
| Protector.-rear door-outer RH .....  | 1        |              |         |
| Protector.-rear door-inner LH .....  | 1        |              |         |
| Protector.-rear door-inner RH .....  | 1        |              |         |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL ..... 2. C 04  
BODY SHELL ..... 2. C 04  
BODYSIDE PANELS ..... 2. C 08  
FRONT BULKHEAD ..... 2. C 05  
FRONT END SIDE MEMBERS ..... 2. C 06  
MAIN FLOOR ..... 2. C 06  
REAR FLOOR ..... 2. C 07  
REAR PANELS ..... 2. C 10  
ROOF ..... 2. C 09  
STONEGUARD ..... 2. C 11  
BONNET AND FITTINGS ..... 2. C 13  
BONNET AND FITTINGS ..... 2. C 13  
BONNET RELEASE AND CABLE ..... 2. C 14  
BONNET SEALS ..... 2. C 15  
BUMPER AND FITTINGS ..... 2. D 15  
FRONT BUMPER AND FITTINGS ..... 2. D 15  
REAR BUMPER AND FITTINGS ..... 2. D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2. C 18  
DOOR GLASS ..... 2. D 02  
DOOR SEALS ..... 2. D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2. C 18  
FRONT WINDOW REGULATORS ..... 2. D 03  
REAR DOOR HANDELS AND LATCHES ..... 2. D 04

REAR WINDOW REGULATORS ..... 2. D 05  
DOORS ..... 2. C 16  
FRONT DOOR AND FITTINGS ..... 2. C 16  
REAR DOOR AND FITTINGS ..... 2. C 17  
ENGINE MOUNTINGS ..... 2. C 02  
ENGINE MOUNTINGS 1800cc ..... 2. C 02  
FINISHERS, BADGES AND PLUGS ..... 2. D 17  
BADGES ..... 2. E 03  
BLANKING PLUGS AND GROMMETS ..... 2. E 04  
FINISHERS ..... 2. D 18  
RUBBING STRIPS AND FITTINGS ..... 2. E 02  
WHEEL ARCH LINERS ..... 2. D 17  
FIXED GLASS ..... 2. D 10  
BACKLIGHT ..... 2. D 11  
WINDSCREEN AND FITTINGS ..... 2. D 10  
FRONT FENDERS AND FITTINGS ..... 2. C 12  
FENDER AND FRONT END FITTINGS ..... 2. C 12  
FUEL FILLER LID AND FITTINGS ..... 2. D 09  
FUEL FILLER LID ..... 2. D 09  
MIRRORS ..... 2. D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2. D 14  
SUBFRAME AND FITTINGS ..... 2. C 03  
SUBFRAME - FRONT ..... 2. C 03

SUBFRAME - REAR ..... 2. C 04  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID AND FITTINGS ..... 2. D 07  
TRUNK LID LOCK AND LATCHES ..... 2. D 08  
WIPERS AND WASHERS ..... 2. D 12  
HEADLAMP WASH ..... 2. D 12  
WINDSCREEN WASH ..... 2. D 13  
WINDSCREEN WIPERS ..... 2. D 12

# SAMAND

D07

Fiche 2

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

TRUNK LID AND FITTINGS

TRUNK LID AND FITTINGS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 060 | 06 | 018 |
| 2  | 164 | 04 | 006 |
| 3  | 164 | 04 | 013 |
| 5  | 111 | 08 | 016 |
| 6  | 121 | 16 | 008 |
| 7  | 007 | 03 | 002 |
| 8  | 111 | 08 | 003 |
| 9  | 182 | 01 | 033 |
| 12 | 025 | 01 | 106 |
| 70 | 040 | 05 | 001 |
| 71 | 040 | 01 | 281 |


Description

|                              |   |
|------------------------------|---|
| Door Assy. ....              | 1 |
| Hinge.-trunk lid.-LH.....    | 1 |
| Hinge.-trunk lid.-RH.....    | 1 |
| Buffer.-trunk hinge.....     | 1 |
| Spring.-trunk lid. ....      | 2 |
| foam pad-balance spring..... | 2 |
| Buffer.-trunk lid.....       | 2 |
| Rubber Seal.-trunk lid.....  | 1 |
| Clip.....                    | 1 |
| Screw.-M6 x 100-12.....      | 4 |
| Screw.-M6 x 100-25.....      | 4 |

Quantity

Change Point

Remarks



ZN0042

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2.C 04 |
| BODY SHELL.....                     | 2.C 04 |
| BODYSIDE PANELS.....                | 2.C 08 |
| FRONT BULKHEAD.....                 | 2.C 05 |
| FRONT END SIDE MEMBERS.....         | 2.C 06 |
| MAIN FLOOR.....                     | 2.C 06 |
| REAR FLOOR.....                     | 2.C 07 |
| REAR PANELS.....                    | 2.C 10 |
| ROOF.....                           | 2.C 09 |
| STONEGUARD.....                     | 2.C 11 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET RELEASE AND CABLE.....       | 2.C 14 |
| BONNET SEALS.....                   | 2.C 15 |
| BUMPER AND FITTINGS.....            | 2.D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2.D 15 |
| REAR BUMPER AND FITTINGS.....       | 2.D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2.C 18 |
| DOOR GLASS.....                     | 2.D 02 |
| DOOR SEALS.....                     | 2.D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2.C 18 |
| FRONT WINDOW REGULATORS.....        | 2.D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2.D 04 |

|                                    |        |
|------------------------------------|--------|
| REAR WINDOW REGULATORS.....        | 2.D 05 |
| DOORS.....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS.....       | 2.C 16 |
| REAR DOOR AND FITTINGS.....        | 2.C 17 |
| ENGINE MOUNTINGS.....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2.D 17 |
| BADGES.....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2.E 04 |
| FINISHERS.....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2.E 02 |
| WHEEL ARCH LINERS.....             | 2.D 17 |
| FIXED GLASS.....                   | 2.D 10 |
| BACKLIGHT.....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS.....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2.D 09 |
| FUEL FILLER LID.....               | 2.D 09 |
| MIRRORS.....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2.D 14 |
| SUBFRAME AND FITTINGS.....         | 2.C 03 |
| SUBFRAME - FRONT.....              | 2.C 03 |

|                                 |        |
|---------------------------------|--------|
| SUBFRAME - REAR.....            | 2.C 04 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2.D 08 |
| WIPERS AND WASHERS.....         | 2.D 12 |
| HEADLAMP WASH.....              | 2.D 12 |
| WINDSCREEN WASH.....            | 2.D 13 |
| WINDSCREEN WIPERS.....          | 2.D 12 |




# SAMAND

D08

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE TRUNK LID AND FITTINGS TRUNK LID LOCK AND LATCHES



ZN0043

Illus Part Number

Description

Quantity

Change  
Point

Remarks

|    |            |
|----|------------|
| 1  | 136 04 015 |
| 2  | 040 01 039 |
| 3  | 136 04 001 |
| 4  | 178 02 055 |
| 5  | 040 14 038 |
| 6  | 083 03 003 |
| 7  | 136 04 014 |
| 8  | 138 03 014 |
| 9  | 181 32 011 |
| 10 | 174 04 037 |
| 11 | 174 03 071 |
| 12 | 181 32 012 |
| 13 | 186 04 016 |
| 14 | 040 22 060 |

|                                 |   |  |  |
|---------------------------------|---|--|--|
| Lock.-trunk lid.                | 1 |  |  |
| Screw.-M6 x 100-20              | 4 |  |  |
| Lock.-trunk lid.                | 1 |  |  |
| Link.-trunk lock actuator       | 1 |  |  |
| Screw.-4.5 x 20                 | 4 |  |  |
| Safety Catch.-trunk lid.        | 1 |  |  |
| Lock.-trunk lid lock            | 1 |  |  |
| Control Cable.-trunk lid lock   | 1 |  |  |
| Bracket.-trunk lock cable-upper | 1 |  |  |
| Nut.-flange-5 x 80              | 4 |  |  |
| Nut.-M6                         | 1 |  |  |
| Bracket.-trunk lock cable-lower | 1 |  |  |
| Washer.                         | 2 |  |  |
| Screw.                          | 2 |  |  |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2.C 04 |
| BODY SHELL.....                     | 2.C 04 |
| BODYSIDE PANELS.....                | 2.C 08 |
| FRONT BULKHEAD.....                 | 2.C 05 |
| FRONT END SIDE MEMBERS.....         | 2.C 06 |
| MAIN FLOOR.....                     | 2.C 06 |
| REAR FLOOR.....                     | 2.C 07 |
| REAR PANELS.....                    | 2.C 10 |
| ROOF.....                           | 2.C 09 |
| STONEGUARD.....                     | 2.C 11 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET RELEASE AND CABLE.....       | 2.C 14 |
| BONNET SEALS.....                   | 2.C 15 |
| BUMPER AND FITTINGS.....            | 2.D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2.D 15 |
| REAR BUMPER AND FITTINGS.....       | 2.D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2.C 18 |
| DOOR GLASS.....                     | 2.D 02 |
| DOOR SEALS.....                     | 2.D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2.C 18 |
| FRONT WINDOW REGULATORS.....        | 2.D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2.D 04 |

|                                    |        |
|------------------------------------|--------|
| REAR WINDOW REGULATORS.....        | 2.D 05 |
| DOORS.....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS.....       | 2.C 16 |
| REAR DOOR AND FITTINGS.....        | 2.C 17 |
| ENGINE MOUNTINGS.....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2.D 17 |
| BADGES.....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2.E 04 |
| FINISHERS.....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2.E 02 |
| WHEEL ARCH LINERS.....             | 2.D 17 |
| FIXED GLASS.....                   | 2.D 10 |
| BACKLIGHT.....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS.....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2.D 09 |
| FUEL FILLER LID.....               | 2.D 09 |
| MIRRORS.....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2.D 14 |
| SUBFRAME AND FITTINGS.....         | 2.C 03 |
| SUBFRAME - FRONT.....              | 2.C 03 |

|                                 |        |
|---------------------------------|--------|
| SUBFRAME - REAR.....            | 2.C 04 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2.D 08 |
| WIPERS AND WASHERS.....         | 2.D 12 |
| HEADLAMP WASH.....              | 2.D 12 |
| WINDSCREEN WASH.....            | 2.D 13 |
| WINDSCREEN WIPERS.....          | 2.D 12 |

# SAMAND

D09

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

FUEL FILLER LID AND FITTINGS

FUEL FILLER LID

Fiche 2

Illus Part Number

1 170 02 010  
2 164 05 003  
3 169 03 001  
4 040 01 160  
70 174 04 004



Description

Plug/Cover.-fuel filler..... 1  
Hinge.-fuel filler..... 1  
Actuator.-fuel filler..... 1  
Screw..... 1  
Nut.-with washer-M6-manifold-lower ..... 2

Quantity

Change Point

Remarks



ZJ0001

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL..... 2.C 04  
BODY SHELL..... 2.C 04  
BODYSIDE PANELS..... 2.C 08  
FRONT BULKHEAD..... 2.C 05  
FRONT END SIDE MEMBERS..... 2.C 06  
MAIN FLOOR..... 2.C 06  
REAR FLOOR..... 2.C 07  
REAR PANELS..... 2.C 10  
ROOF..... 2.C 09  
STONEGUARD..... 2.C 11  
BONNET AND FITTINGS..... 2.C 13  
BONNET AND FITTINGS..... 2.C 13  
BONNET RELEASE AND CABLE..... 2.C 14  
BONNET SEALS..... 2.C 15  
BUMPER AND FITTINGS..... 2.D 15  
FRONT BUMPER AND FITTINGS..... 2.D 15  
REAR BUMPER AND FITTINGS..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND..... 2.C 18  
DOOR GLASS..... 2.D 02  
DOOR SEALS..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS..... 2.C 18  
FRONT WINDOW REGULATORS..... 2.D 03  
REAR DOOR HANDELS AND LATCHES..... 2.D 04

REAR WINDOW REGULATORS..... 2.D 05  
DOORS..... 2.C 16  
FRONT DOOR AND FITTINGS..... 2.C 16  
REAR DOOR AND FITTINGS..... 2.C 17  
ENGINE MOUNTINGS..... 2.C 02  
ENGINE MOUNTINGS 1800cc..... 2.C 02  
FINISHERS, BADGES AND PLUGS..... 2.D 17  
BADGES..... 2.E 03  
BLANKING PLUGS AND GROMMETS..... 2.E 04  
FINISHERS..... 2.D 18  
RUBBING STRIPS AND FITTINGS..... 2.E 02  
WHEEL ARCH LINERS..... 2.D 17  
FIXED GLASS..... 2.D 10  
BACKLIGHT..... 2.D 11  
WINDSCREEN AND FITTINGS..... 2.D 10  
FRONT FENDERS AND FITTINGS..... 2.C 12  
FENDER AND FRONT END FITTINGS..... 2.C 12  
FUEL FILLER LID AND FITTINGS..... 2.D 09  
FUEL FILLER LID..... 2.D 09  
MIRRORS..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS..... 2.D 14  
SUBFRAME AND FITTINGS..... 2.C 03  
SUBFRAME - FRONT..... 2.C 03

SUBFRAME - REAR..... 2.C 04  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID LOCK AND LATCHES..... 2.D 08  
WIPERS AND WASHERS..... 2.D 12  
HEADLAMP WASH..... 2.D 12  
WINDSCREEN WASH..... 2.D 13  
WINDSCREEN WIPERS..... 2.D 12



# SAMAND

D10

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

### FIXED GLASS

#### WINDSCREEN AND FITTINGS

Illus Part Number

1 107 04 015  
2 182 03 110  
3 234 02 002


Description

Quantity

Change Point

Remarks

Glass.-windscreen ..... 1  
Rubber Seal.-windscreen ..... 1  
Adhesive. .... A/R



ZN0045

#### MASTER INDEX

#### GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

BODY SHELL ..... 2.C 04  
BODY SHELL ..... 2.C 04  
BODYSIDE PANELS ..... 2.C 08  
FRONT BULKHEAD ..... 2.C 05  
FRONT END SIDE MEMBERS ..... 2.C 06  
MAIN FLOOR ..... 2.C 06  
REAR FLOOR ..... 2.C 07  
REAR PANELS ..... 2.C 10  
ROOF ..... 2.C 09  
STONEGUARD ..... 2.C 11  
BONNET AND FITTINGS ..... 2.C 13  
BONNET AND FITTINGS ..... 2.C 13  
BONNET RELEASE AND CABLE ..... 2.C 14  
BONNET SEALS ..... 2.C 15  
BUMPER AND FITTINGS ..... 2.D 15  
FRONT BUMPER AND FITTINGS ..... 2.D 15  
REAR BUMPER AND FITTINGS ..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2.C 18  
DOOR GLASS ..... 2.D 02  
DOOR SEALS ..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2.C 18  
FRONT WINDOW REGULATORS ..... 2.D 03  
REAR DOOR HANDELS AND LATCHES ..... 2.D 04

REAR WINDOW REGULATORS ..... 2.D 05  
DOORS ..... 2.C 16  
FRONT DOOR AND FITTINGS ..... 2.C 16  
REAR DOOR AND FITTINGS ..... 2.C 17  
ENGINE MOUNTINGS ..... 2.C 02  
ENGINE MOUNTINGS 1800cc ..... 2.C 02  
FINISHERS, BADGES AND PLUGS ..... 2.D 17  
BADGES ..... 2.E 03  
BLANKING PLUGS AND GROMMETS ..... 2.E 04  
FINISHERS ..... 2.D 18  
RUBBING STRIPS AND FITTINGS ..... 2.E 02  
WHEEL ARCH LINERS ..... 2.D 17  
FIXED GLASS ..... 2.D 10  
BACKLIGHT ..... 2.D 11  
WINDSCREEN AND FITTINGS ..... 2.D 10  
FRONT FENDERS AND FITTINGS ..... 2.C 12  
FENDER AND FRONT END FITTINGS ..... 2.C 12  
FUEL FILLER LID AND FITTINGS ..... 2.D 09  
FUEL FILLER LID ..... 2.D 09  
MIRRORS ..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2.D 14  
SUBFRAME AND FITTINGS ..... 2.C 03  
SUBFRAME - FRONT ..... 2.C 03

SUBFRAME - REAR ..... 2.C 04  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID LOCK AND LATCHES ..... 2.D 08  
WIPERS AND WASHERS ..... 2.D 12  
HEADLAMP WASH ..... 2.D 12  
WINDSCREEN WASH ..... 2.D 13  
WINDSCREEN WIPERS ..... 2.D 12

# SAMAND

D11

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FIXED GLASS BACKLIGHT

Illus Part Number

1 107 07 013  
2 182 03 103


Description

Glass.-rear screen-Tinted..... 1  
Rubber Seal.-rear screen ..... 1

Quantity

Change Point

Remarks



ZN0044

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL..... 2.C 04  
BODY SHELL..... 2.C 04  
BODYSIDE PANELS..... 2.C 08  
FRONT BULKHEAD..... 2.C 05  
FRONT END SIDE MEMBERS..... 2.C 06  
MAIN FLOOR..... 2.C 06  
REAR FLOOR..... 2.C 07  
REAR PANELS..... 2.C 10  
ROOF..... 2.C 09  
STONEGUARD..... 2.C 11  
BONNET AND FITTINGS..... 2.C 13  
BONNET AND FITTINGS..... 2.C 13  
BONNET RELEASE AND CABLE..... 2.C 14  
BONNET SEALS..... 2.C 15  
BUMPER AND FITTINGS..... 2.D 15  
FRONT BUMPER AND FITTINGS..... 2.D 15  
REAR BUMPER AND FITTINGS..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND..... 2.C 18  
DOOR GLASS..... 2.D 02  
DOOR SEALS..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS..... 2.C 18  
FRONT WINDOW REGULATORS..... 2.D 03  
REAR DOOR HANDELS AND LATCHES..... 2.D 04

REAR WINDOW REGULATORS..... 2.D 05  
DOORS..... 2.C 16  
FRONT DOOR AND FITTINGS..... 2.C 16  
REAR DOOR AND FITTINGS..... 2.C 17  
ENGINE MOUNTINGS..... 2.C 02  
ENGINE MOUNTINGS 1800cc..... 2.C 02  
FINISHERS, BADGES AND PLUGS..... 2.D 17  
BADGES..... 2.E 03  
BLANKING PLUGS AND GROMMETS..... 2.E 04  
FINISHERS..... 2.D 18  
RUBBING STRIPS AND FITTINGS..... 2.E 02  
WHEEL ARCH LINERS..... 2.D 17  
FIXED GLASS..... 2.D 10  
BACKLIGHT..... 2.D 11  
WINDSCREEN AND FITTINGS..... 2.D 10  
FRONT FENDERS AND FITTINGS..... 2.C 12  
FENDER AND FRONT END FITTINGS..... 2.C 12  
FUEL FILLER LID AND FITTINGS..... 2.D 09  
FUEL FILLER LID..... 2.D 09  
MIRRORS..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS..... 2.D 14  
SUBFRAME AND FITTINGS..... 2.C 03  
SUBFRAME - FRONT..... 2.C 03  
SUBFRAME - REAR..... 2.C 04  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID AND FITTINGS..... 2.D 07  
TRUNK LID LOCK AND LATCHES..... 2.D 08  
WIPERS AND WASHERS..... 2.D 12  
HEADLAMP WASH..... 2.D 12  
WINDSCREEN WASH..... 2.D 13  
WINDSCREEN WIPERS..... 2.D 12

# SAMAND

D12

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

### WIPERS AND WASHERS

#### WINDSCREEN WIPERS



Illus Part Number

Description

Quantity

Change Point

Remarks



|    |     |    |     |                                        |   |  |  |
|----|-----|----|-----|----------------------------------------|---|--|--|
| 1  | 101 | 03 | 016 | MOTOR.-WINDSCREEN WIPER-ASSEMBLY ..... | 1 |  |  |
| 2  | 101 | 03 | 008 | • Motor.-windscreen wiper .....        | 1 |  |  |
| 4  | 108 | 05 | 020 | Hose .....                             | 1 |  |  |
| 5  | 020 | 01 | 013 | Arm.-windscreen wiper-LH .....         | 1 |  |  |
| 5  | 020 | 01 | 014 | Arm.-windscreen wiper-RH .....         | 1 |  |  |
| 6  | 047 | 01 | 018 | Wiper Blade.-LH .....                  | 1 |  |  |
| 6  | 047 | 01 | 017 | Wiper Blade.-RH .....                  | 1 |  |  |
| 7  | 020 | 01 | 019 | Arm.-LH .....                          | 1 |  |  |
| 7  | 020 | 01 | 018 | Arm.-RH .....                          | 1 |  |  |
| 8  | 015 | 03 | 007 | Lever.-wiper road set .....            | 1 |  |  |
| 9  | 183 | 01 | 005 | Wiper Conrod Assy. ....                | 1 |  |  |
| 70 | 040 | 01 | 279 | Screw.-M6 x 100-25 .....               | 3 |  |  |
| 71 | 186 | 01 | 177 | Washer.-6 x 22 .....                   | 3 |  |  |
| 72 | 174 | 08 | 008 | Nut.-M6-caged .....                    | 3 |  |  |
| 74 | 174 | 04 | 047 | Nut.-flanged-M8 .....                  | 2 |  |  |
| 75 | 040 | 01 | 082 | Screw.-M6 x 100-16 .....               | 3 |  |  |

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

BODY SHELL ..... 2.C 04  
BODY SHELL ..... 2.C 04  
BODYSIDE PANELS ..... 2.C 08  
FRONT BULKHEAD ..... 2.C 05  
FRONT END SIDE MEMBERS ..... 2.C 06  
MAIN FLOOR ..... 2.C 06  
REAR FLOOR ..... 2.C 07  
REAR PANELS ..... 2.C 10  
ROOF ..... 2.C 09  
STONEGUARD ..... 2.C 11  
BONNET AND FITTINGS ..... 2.C 13  
BONNET AND FITTINGS ..... 2.C 13  
BONNET RELEASE AND CABLE ..... 2.C 14  
BONNET SEALS ..... 2.C 15  
BUMPER AND FITTINGS ..... 2.D 15  
FRONT BUMPER AND FITTINGS ..... 2.D 15  
REAR BUMPER AND FITTINGS ..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2.C 18  
DOOR GLASS ..... 2.D 02  
DOOR SEALS ..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2.C 18  
FRONT WINDOW REGULATORS ..... 2.D 03  
REAR DOOR HANDELS AND LATCHES ..... 2.D 04

REAR WINDOW REGULATORS ..... 2.D 05  
DOORS ..... 2.C 16  
FRONT DOOR AND FITTINGS ..... 2.C 16  
REAR DOOR AND FITTINGS ..... 2.C 17  
ENGINE MOUNTINGS ..... 2.C 02  
ENGINE MOUNTINGS 1800cc ..... 2.C 02  
FINISHERS, BADGES AND PLUGS ..... 2.D 17  
BADGES ..... 2.E 03  
BLANKING PLUGS AND GROMMETS ..... 2.E 04  
FINISHERS ..... 2.D 18  
RUBBING STRIPS AND FITTINGS ..... 2.E 02  
WHEEL ARCH LINERS ..... 2.D 17  
FIXED GLASS ..... 2.D 10  
BACKLIGHT ..... 2.D 11  
WINDSCREEN AND FITTINGS ..... 2.D 10  
FRONT FENDERS AND FITTINGS ..... 2.C 12  
FENDER AND FRONT END FITTINGS ..... 2.C 12  
FUEL FILLER LID AND FITTINGS ..... 2.D 09  
FUEL FILLER LID ..... 2.D 09  
MIRRORS ..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2.D 14  
SUBFRAME AND FITTINGS ..... 2.C 03  
SUBFRAME - FRONT ..... 2.C 03



SUBFRAME - REAR ..... 2.C 04  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID LOCK AND LATCHES ..... 2.D 08  
WIPERS AND WASHERS ..... 2.D 12  
HEADLAMP WASH ..... 2.D 12  
WINDSCREEN WASH ..... 2.D 13  
WINDSCREEN WIPERS ..... 2.D 12

# SAMAND

D13

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE WIPERS AND WASHERS WINDSCREEN WASH



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 170 | 13 | 003 |
| 2  | 036 | 02 | 001 |
| 3  | 174 | 04 | 004 |
| 4  | 017 | 06 | 016 |
| 5  | 172 | 01 | 011 |
| 6  | 108 | 05 | 018 |
| 7  | 108 | 05 | 019 |
| 8  | 093 | 04 | 001 |
| 9  | 108 | 05 | 001 |
| 10 | 007 | 02 | 005 |

Description

|                                           |   |
|-------------------------------------------|---|
| Plug/Cover.-windscreen washer bottle..... | 1 |
| Pump.-windscreen washer.....              | 1 |
| Nut.-with washer-M6-manifold-lower.....   | 2 |
| Seal.-washer pump to bottle.....          | 1 |
| Reservoir.-windscreen washer.....         | 1 |
| Hose.-windscreen washer-bent.....         | 1 |
| Hose.-windscreen washer-4 x 6 x 850.....  | 1 |
| Union.-tee piece-windscreen washer.....   | 1 |
| Hose.-windscreen washer.....              | 2 |
| foam pad-support-windscreen washer.....   | 1 |

Quantity

Change Point

Remarks

ZN0005

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 07  
REAR FLOOR.....2.C 10  
REAR PANELS.....2.C 09  
ROOF.....2.C 11  
STONEGUARD.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND



D14

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

### MIRRORS

#### INTERIOR AND EXTERIOR MIRRORS



Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 001 | 01 | 020 |
| 2 | 107 | 01 | 018 |
| 5 | 007 | 04 | 001 |
| 6 | 126 | 08 | 023 |
| 7 | 126 | 08 | 027 |
| 8 | 181 | 11 | 010 |
| 9 | 182 | 06 | 005 |
| 1 | 001 | 01 | 021 |
| 2 | 107 | 01 | 019 |
| 6 | 126 | 08 | 024 |
| 7 | 126 | 08 | 028 |
| 8 | 181 | 11 | 009 |
| 9 | 182 | 06 | 004 |
| 3 | 001 | 02 | 005 |
| 4 | 040 | 05 | 024 |


Description

Quantity

Change Point

Remarks

|                                        |   |  |  |
|----------------------------------------|---|--|--|
| REAR VIEW MIRROR-ELECTRIC CURVED-..... | 1 |  |  |
| DRIVER'S DOOR .....                    |   |  |  |
| • Glass.-exterior mirror -LH .....     | 1 |  |  |
| foam pad-exterior mirror .....         | 2 |  |  |
| Trim.-exterior mirror -inner LH.....   | 1 |  |  |
| Trim.-LH .....                         | 1 |  |  |
| Bracket.-LH.....                       | 1 |  |  |
| Rubber Seal.-LH .....                  | 1 |  |  |
| REAR VIEW MIRROR-ELECTRIC CURVED-..... | 1 |  |  |
| PASSENGER'S DOOR.....                  |   |  |  |
| • Glass.-exterior mirror -RH .....     | 1 |  |  |
| Trim.-exterior mirror -inner-RH.....   | 1 |  |  |
| Trim.-RH .....                         | 1 |  |  |
| Bracket.-RH .....                      | 1 |  |  |
| Rubber Seal.-RH .....                  | 1 |  |  |
| Rear view mirror-interior .....        | 1 |  |  |
| Screw.....                             | 6 |  |  |



ZP0010

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                     |         |
|-------------------------------------|---------|
| BODY SHELL.....                     | 2. C 04 |
| BODY SHELL.....                     | 2. C 04 |
| BODYSIDE PANELS .....               | 2. C 08 |
| FRONT BULKHEAD .....                | 2. C 05 |
| FRONT END SIDE MEMBERS .....        | 2. C 06 |
| MAIN FLOOR.....                     | 2. C 06 |
| REAR FLOOR.....                     | 2. C 07 |
| REAR PANELS .....                   | 2. C 10 |
| ROOF.....                           | 2. C 09 |
| STONEGUARD.....                     | 2. C 11 |
| BONNET AND FITTINGS .....           | 2. C 13 |
| BONNET AND FITTINGS .....           | 2. C 13 |
| BONNET RELEASE AND CABLE .....      | 2. C 14 |
| BONNET SEALS .....                  | 2. C 15 |
| BUMPER AND FITTINGS.....            | 2. D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2. D 15 |
| REAR BUMPER AND FITTINGS.....       | 2. D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2. C 18 |
| DOOR GLASS .....                    | 2. D 02 |
| DOOR SEALS.....                     | 2. D 06 |
| FRONT DOOR HANDELS AND LOCKS .....  | 2. C 18 |
| FRONT WINDOW REGULATORS.....        | 2. D 03 |
| REAR DOOR HANDELS AND LATCHES ..... | 2. D 04 |

|                                     |         |
|-------------------------------------|---------|
| REAR WINDOW REGULATORS.....         | 2. D 05 |
| DOORS.....                          | 2. C 16 |
| FRONT DOOR AND FITTINGS .....       | 2. C 16 |
| REAR DOOR AND FITTINGS .....        | 2. C 17 |
| ENGINE MOUNTINGS .....              | 2. C 02 |
| ENGINE MOUNTINGS 1800cc .....       | 2. C 02 |
| FINISHERS, BADGES AND PLUGS.....    | 2. D 17 |
| BADGES.....                         | 2. E 03 |
| BLANKING PLUGS AND GROMMETS.....    | 2. E 04 |
| FINISHERS.....                      | 2. D 18 |
| RUBBING STRIPS AND FITTINGS .....   | 2. E 02 |
| WHEEL ARCH LINERS.....              | 2. D 17 |
| FIXED GLASS .....                   | 2. D 10 |
| BACKLIGHT.....                      | 2. D 11 |
| WINDSCREEN AND FITTINGS .....       | 2. D 10 |
| FRONT FENDERS AND FITTINGS .....    | 2. C 12 |
| FENDER AND FRONT END FITTINGS ..... | 2. C 12 |
| FUEL FILLER LID AND FITTINGS.....   | 2. D 09 |
| FUEL FILLER LID.....                | 2. D 09 |
| MIRRORS .....                       | 2. D 14 |
| INTERIOR AND EXTERIOR MIRRORS.....  | 2. D 14 |
| SUBFRAME AND FITTINGS.....          | 2. C 03 |
| SUBFRAME - FRONT .....              | 2. C 03 |

|                                  |         |
|----------------------------------|---------|
| SUBFRAME - REAR .....            | 2. C 04 |
| TRUNK LID AND FITTINGS.....      | 2. D 07 |
| TRUNK LID AND FITTINGS.....      | 2. D 07 |
| TRUNK LID LOCK AND LATCHES ..... | 2. D 08 |
| WIPERS AND WASHERS.....          | 2. D 12 |
| HEADLAMP WASH.....               | 2. D 12 |
| WINDSCREEN WASH .....            | 2. D 13 |
| WINDSCREEN WIPERS .....          | 2. D 12 |



# SAMAND

D15

ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE

FICHE2

BUMPER AND FITTINGS  
FRONT BUMPER AND FITTINGS




| Illus | Part Number | Description                         | Quantity | Change Point | Remarks |
|-------|-------------|-------------------------------------|----------|--------------|---------|
| 1     | 089 01 014  | Bumper Assy.-front bumper -assembly | 1        |              |         |
| 2     | 040 14 091  | Screw.-4.2 x 21                     | 3        |              |         |
| 3     | 103 01 002  | Grill.-radiator                     | 1        |              |         |
| 4     | 085 12 008  | Rubbing Strip.-front bumper -LH     | 1        |              |         |
| 4     | 085 12 009  | Rubbing Strip.-front bumper -RH     | 1        |              |         |
| 5     | 174 02 010  | Nut.-4.2-speed                      |          |              |         |
| 7     | 237 03 012  | Protecting Plate.-upper             | 1        |              |         |
| 8     | 174 04 043  | Nut.-flanged head-M8                | 4        |              |         |
| 9     | 040 02 055  | Screw.-10mm                         | 2        |              |         |
| 10    | 040 14 014  | Screw.-flanged-M6 x 100-22-inner    | 1        |              |         |
| 11    | 089 01 016  | Bumper Assy.                        | 1        |              |         |
| 12    | 181 16 034  | Bracket.-LH                         | 1        |              |         |
| 12    | 181 16 035  | Bracket.-RH                         | 1        |              |         |
| 15    | 040 05 003  | Screw.-M10 x 30                     | 6        |              |         |
| 17    | 181 16 041  | Bracket.                            | 6        |              |         |
| 18    | 111 06 005  | Absorber frt bumper Lh              | 1        |              |         |
| 19    | 111 06 006  | Absorber frt bumper Rh              | 1        |              |         |
| 20    | 103 01 003  | Metal grill frt bumper              | 1        |              |         |
| 21    | 025 20 003  | Metal clip                          | 1        |              |         |



# SAMAND

D16  
FICHE2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE BUMPER AND FITTINGS REAR BUMPER AND FITTINGS




| Illus | Part Number | Description                         | Quantity | Change Point | Remarks |
|-------|-------------|-------------------------------------|----------|--------------|---------|
| 1     | 089 02 013  | BUMPER ASSY.-REAR-ASSEMBLY          | 1        |              |         |
| 10    | 085 13 007  | · Rubbing Strip.-rear bumper-middle | 1        |              |         |
| 11    | 085 13 005  | · Rubbing Strip.-rear bumper-LH     | 1        |              |         |
| 12    | 085 13 006  | · Rubbing Strip.-rear bumper-RH     | 1        |              |         |
| 13    | 174 03 072  | Nut.-M10                            | 4        |              |         |
| 14    | 174 02 010  | Nut.-4.2-speed                      | 4        |              |         |
| 15    | 186 01 172  | Washer.-plain...-M10                | 4        |              |         |
| 16    | 181 16 037  | Bracket.-LH                         | 1        |              |         |
| 16    | 181 16 036  | Bracket.-RH                         | 1        |              |         |
| 17    | 181 16 040  | Bracket.                            | 6        |              |         |
| 18    | 040 14 091  | Screw.-4.2 x 21                     | 6        |              |         |
| 19    | 111 06 009  | Foam rr bumper middle               | 1        |              |         |
| 20    | 111 06 007  | Foam rr bumper Lh                   | 1        |              |         |
| 21    | 111 06 008  | Foam rr bumper Rh                   | 1        |              |         |

# SAMAND

D17

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FINISHERS, BADGES AND PLUGS WHEEL ARCH LINERS



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 191 | 01 | 011 |
| 1  | 191 | 01 | 012 |
| 2  | 191 | 01 | 013 |
| 2  | 191 | 01 | 014 |
| 3  | 191 | 02 | 014 |
| 3  | 191 | 02 | 015 |
| 4  | 174 | 02 | 010 |
| 5  | 040 | 14 | 091 |
| 7  | 040 | 29 | 003 |
| 10 | 174 | 04 | 046 |


Description

|                                                   |    |
|---------------------------------------------------|----|
| Mudguard.-upper-front LH.....                     | 1  |
| Mudguard.-upper-front RH.....                     | 1  |
| Mudguard.-lower-front LH.....                     | 1  |
| Mudguard.-lower-front RH.....                     | 1  |
| Mudguard.-rear LH.....                            | 1  |
| Mudguard.-rear RH.....                            | 1  |
| Nut.-4.2-speed.....                               | 12 |
| Screw.-wheel arch liner-4.2 x 21.....             | 18 |
| Screw.-M6 x 100.....                              | 10 |
| Nut.-with washer-M6 x 100-heatshield to body..... | 4  |

Quantity

Change Point

Remarks



ZN0061

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                     |        |
|-------------------------------------|--------|
| BODY SHELL.....                     | 2.C 04 |
| BODY SHELL.....                     | 2.C 04 |
| BODYSIDE PANELS.....                | 2.C 08 |
| FRONT BULKHEAD.....                 | 2.C 05 |
| FRONT END SIDE MEMBERS.....         | 2.C 08 |
| MAIN FLOOR.....                     | 2.C 06 |
| REAR FLOOR.....                     | 2.C 07 |
| REAR PANELS.....                    | 2.C 10 |
| ROOF.....                           | 2.C 09 |
| STONEGUARD.....                     | 2.C 11 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET AND FITTINGS.....            | 2.C 13 |
| BONNET RELEASE AND CABLE.....       | 2.C 14 |
| BONNET SEALS.....                   | 2.C 15 |
| BUMPER AND FITTINGS.....            | 2.D 15 |
| FRONT BUMPER AND FITTINGS.....      | 2.D 15 |
| REAR BUMPER AND FITTINGS.....       | 2.D 16 |
| DOOR HANDELS, LOCKS, GLASS AND..... | 2.C 18 |
| DOOR GLASS.....                     | 2.D 02 |
| DOOR SEALS.....                     | 2.D 06 |
| FRONT DOOR HANDELS AND LOCKS.....   | 2.C 18 |
| FRONT WINDOW REGULATORS.....        | 2.D 03 |
| REAR DOOR HANDELS AND LATCHES.....  | 2.D 04 |



|                                    |        |
|------------------------------------|--------|
| REAR WINDOW REGULATORS.....        | 2.D 05 |
| DOORS.....                         | 2.C 16 |
| FRONT DOOR AND FITTINGS.....       | 2.C 16 |
| REAR DOOR AND FITTINGS.....        | 2.C 17 |
| ENGINE MOUNTINGS.....              | 2.C 02 |
| ENGINE MOUNTINGS 1800cc.....       | 2.C 02 |
| FINISHERS, BADGES AND PLUGS.....   | 2.D 17 |
| BADGES.....                        | 2.E 03 |
| BLANKING PLUGS AND GROMMETS.....   | 2.E 04 |
| FINISHERS.....                     | 2.D 18 |
| RUBBING STRIPS AND FITTINGS.....   | 2.E 02 |
| WHEEL ARCH LINERS.....             | 2.D 17 |
| FIXED GLASS.....                   | 2.D 10 |
| BACKLIGHT.....                     | 2.D 11 |
| WINDSCREEN AND FITTINGS.....       | 2.D 10 |
| FRONT FENDERS AND FITTINGS.....    | 2.C 12 |
| FENDER AND FRONT END FITTINGS..... | 2.C 12 |
| FUEL FILLER LID AND FITTINGS.....  | 2.D 09 |
| FUEL FILLER LID.....               | 2.D 09 |
| MIRRORS.....                       | 2.D 14 |
| INTERIOR AND EXTERIOR MIRRORS..... | 2.D 14 |
| SUBFRAME AND FITTINGS.....         | 2.C 03 |
| SUBFRAME - FRONT.....              | 2.C 03 |

|                                 |        |
|---------------------------------|--------|
| SUBFRAME - REAR.....            | 2.C 04 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID AND FITTINGS.....     | 2.D 07 |
| TRUNK LID LOCK AND LATCHES..... | 2.D 08 |
| WIPERS AND WASHERS.....         | 2.D 12 |
| HEADLAMP WASH.....              | 2.D 12 |
| WINDSCREEN WASH.....            | 2.D 13 |
| WINDSCREEN WIPERS.....          | 2.D 12 |

# SAMAND

## D18 FICHE2

### ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FINISHERS, BADGES AND PLUGS FINISHERS



| Illus | Part Number | Description                        | Quantity | Change Point | Remarks |
|-------|-------------|------------------------------------|----------|--------------|---------|
| 1     | 126 15 054  | Trim.-front door-LH                | 1        |              |         |
| 1     | 126 15 055  | Trim.-front door-RH                | 1        |              |         |
| 2     | 126 15 052  | Trim.-rear door-LH                 | 1        |              |         |
| 2     | 126 15 053  | Trim.-rear door-RH                 | 1        |              |         |
| 3     | 103 09 002  | Grill.-air                         | 3        |              |         |
| 4     | 133 10 007  | Assembly.-trunk lid.               | 1        |              |         |
| 5     | 058 20 020  | Fixing Clip.-trunk lid             | 2        |              |         |
| 6     | 174 04 004  | Nut.-with washer-M6-manifold-lower | 5        |              |         |
| 7     | 182 12 003  | Rubber Seal.-drip rail-LH          | 1        |              |         |
| 7     | 182 12 004  | Rubber Seal.-drip rail-RH          | 1        |              |         |
| 10    | 025 01 118  | Cap.                               | 2        |              |         |

ZN0062

[illegible]


# SAMAND

E02

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FINISHERS, BADGES AND PLUGS RUBBING STRIPS AND FITTINGS

| Illus | Part Number | Description                         | Quantity | Change Point | Remarks |
|-------|-------------|-------------------------------------|----------|--------------|---------|
| 1     | 085 03 002  | Rubbing Strip.-front fender-LH..... | 1        |              |         |
| 1     | 085 02 004  | Rubbing Strip.-front fender-RH..... | 1        |              |         |
| 2     | 085 05 007  | Rubbing Strip.-front door-LH.....   | 1        |              |         |
| 2     | 085 06 005  | Rubbing Strip.-front door-RH.....   | 1        |              |         |
| 3     | 085 07 010  | Rubbing Strip.-rear door-LH.....    | 1        |              |         |
| 3     | 085 08 009  | Rubbing Strip.-rear door-RH.....    | 1        |              |         |



ZN0046

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL.....2.C 04  
BODY SHELL.....2.C 04  
BODYSIDE PANELS.....2.C 08  
FRONT BULKHEAD.....2.C 05  
FRONT END SIDE MEMBERS.....2.C 06  
MAIN FLOOR.....2.C 06  
REAR FLOOR.....2.C 07  
REAR PANELS.....2.C 10  
ROOF.....2.C 09  
STONEGUARD.....2.C 11  
BONNET AND FITTINGS.....2.C 13  
BONNET AND FITTINGS.....2.C 13  
BONNET RELEASE AND CABLE.....2.C 14  
BONNET SEALS.....2.C 15  
BUMPER AND FITTINGS.....2.D 15  
FRONT BUMPER AND FITTINGS.....2.D 15  
REAR BUMPER AND FITTINGS.....2.D 16  
DOOR HANDELS, LOCKS, GLASS AND.....2.C 18  
DOOR GLASS.....2.D 02  
DOOR SEALS.....2.D 06  
FRONT DOOR HANDELS AND LOCKS.....2.C 18  
FRONT WINDOW REGULATORS.....2.D 03  
REAR DOOR HANDELS AND LATCHES.....2.D 04

REAR WINDOW REGULATORS.....2.D 05  
DOORS.....2.C 16  
FRONT DOOR AND FITTINGS.....2.C 16  
REAR DOOR AND FITTINGS.....2.C 17  
ENGINE MOUNTINGS.....2.C 02  
ENGINE MOUNTINGS 1800cc.....2.C 02  
FINISHERS, BADGES AND PLUGS.....2.D 17  
BADGES.....2.E 03  
BLANKING PLUGS AND GROMMETS.....2.E 04  
FINISHERS.....2.D 18  
RUBBING STRIPS AND FITTINGS.....2.E 02  
WHEEL ARCH LINERS.....2.D 17  
FIXED GLASS.....2.D 10  
BACKLIGHT.....2.D 11  
WINDSCREEN AND FITTINGS.....2.D 10  
FRONT FENDERS AND FITTINGS.....2.C 12  
FENDER AND FRONT END FITTINGS.....2.C 12  
FUEL FILLER LID AND FITTINGS.....2.D 09  
FUEL FILLER LID.....2.D 09  
MIRRORS.....2.D 14  
INTERIOR AND EXTERIOR MIRRORS.....2.D 14  
SUBFRAME AND FITTINGS.....2.C 03  
SUBFRAME - FRONT.....2.C 03

SUBFRAME - REAR.....2.C 04  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID AND FITTINGS.....2.D 07  
TRUNK LID LOCK AND LATCHES.....2.D 08  
WIPERS AND WASHERS.....2.D 12  
HEADLAMP WASH.....2.D 12  
WINDSCREEN WASH.....2.D 13  
WINDSCREEN WIPERS.....2.D 12

# SAMAND

E03

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FINISHERS, BADGES AND PLUGS BADGES

Illus Part Number

1 003 03 007  
2 003 01 029  
3 003 01 028  
5 003 02 003


Description

Badge.-front bumper ..... 1  
Badge.-make name ..... 1  
Badge.-type name ..... 1  
Badge.-engine type..... 1

Quantity

Change Point

Remarks



ZP0001

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

BODY SHELL ..... 2.C 04  
BODY SHELL ..... 2.C 04  
BODYSIDE PANELS ..... 2.C 08  
FRONT BULKHEAD ..... 2.C 05  
FRONT END SIDE MEMBERS ..... 2.C 06  
MAIN FLOOR ..... 2.C 06  
REAR FLOOR ..... 2.C 07  
REAR PANELS ..... 2.C 10  
ROOF ..... 2.C 09  
STONEGUARD ..... 2.C 11  
BONNET AND FITTINGS ..... 2.C 13  
BONNET AND FITTINGS ..... 2.C 13  
BONNET RELEASE AND CABLE ..... 2.C 14  
BONNET SEALS ..... 2.C 15  
BUMPER AND FITTINGS ..... 2.D 15  
FRONT BUMPER AND FITTINGS ..... 2.D 15  
REAR BUMPER AND FITTINGS ..... 2.D 16  
DOOR HANDELS, LOCKS, GLASS AND ..... 2.C 18  
DOOR GLASS ..... 2.D 02  
DOOR SEALS ..... 2.D 06  
FRONT DOOR HANDELS AND LOCKS ..... 2.C 18  
FRONT WINDOW REGULATORS ..... 2.D 03  
REAR DOOR HANDELS AND LATCHES ..... 2.D 04

REAR WINDOW REGULATORS ..... 2.D 05  
DOORS ..... 2.C 16  
FRONT DOOR AND FITTINGS ..... 2.C 16  
REAR DOOR AND FITTINGS ..... 2.C 17  
ENGINE MOUNTINGS ..... 2.C 02  
ENGINE MOUNTINGS 1800cc ..... 2.C 02  
FINISHERS, BADGES AND PLUGS ..... 2.D 17  
BADGES ..... 2.E 03  
BLANKING PLUGS AND GROMMETS ..... 2.E 04  
FINISHERS ..... 2.D 18  
RUBBING STRIPS AND FITTINGS ..... 2.E 02  
WHEEL ARCH LINERS ..... 2.D 17  
FIXED GLASS ..... 2.D 10  
BACKLIGHT ..... 2.D 11  
WINDSCREEN AND FITTINGS ..... 2.D 10  
FRONT FENDERS AND FITTINGS ..... 2.C 12  
FENDER AND FRONT END FITTINGS ..... 2.C 12  
FUEL FILLER LID AND FITTINGS ..... 2.D 09  
FUEL FILLER LID ..... 2.D 09  
MIRRORS ..... 2.D 14  
INTERIOR AND EXTERIOR MIRRORS ..... 2.D 14  
SUBFRAME AND FITTINGS ..... 2.C 03  
SUBFRAME - FRONT ..... 2.C 03

SUBFRAME - REAR ..... 2.C 04  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID AND FITTINGS ..... 2.D 07  
TRUNK LID LOCK AND LATCHES ..... 2.D 08  
WIPERS AND WASHERS ..... 2.D 12  
HEADLAMP WASH ..... 2.D 12  
WINDSCREEN WASH ..... 2.D 13  
WINDSCREEN WIPERS ..... 2.D 12



# SAMAND

E04

Fiche 2

## ENGINE MOUNTINGS, BODY SHELL AND WASH-WIPE FINISHERS, BADGES AND PLUGS BLANKING PLUGS AND GROMMETS

Illus Part Number

|   |            |
|---|------------|
| 1 | 061 12 019 |
| 2 | 038 08 001 |
| 3 | 061 15 001 |
| 4 | 061 15 018 |


Description

Quantity

Change Point

Remarks

|                                     |   |
|-------------------------------------|---|
| Cap.-rectangular-front floor.....   | 2 |
| Welch Plug.-floor.-round .....      | 8 |
| Cap.-round-rear floor. ....         | 3 |
| Cap.-round-rear floor.-centre ..... | 1 |



ZN0063

### MASTER INDEX

|                                         |    |
|-----------------------------------------|----|
| ENGINE                                  | 1C |
| FLYWHEEL AND CLUTCH                     | 1D |
| GEARBOX                                 | 1E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS | 1F |
| STEERING                                | 1G |
| BRAKES AND BRAKE CONTROLS               | 1H |
| FUEL, EXHAUST AND EMISSION SYSTEM       | 1I |
| COOLING, HEATING AND AIR CONDITIONING   | 1J |
| ELECTRICAL AND INSTRUMENTS              | 1K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-  | 2C |
| FACIA, TRIM, SEATS AND FIXINGS          | 2F |
| ACCESSORIES AND PAINT                   | 2H |
| Numeric Index                           | 2I |

### GROUP INDEX

|                                      |         |
|--------------------------------------|---------|
| BODY SHELL.....                      | 2. C 04 |
| BODY SHELL.....                      | 2. C 04 |
| BODYSIDE PANELS .....                | 2. C 08 |
| FRONT BULKHEAD .....                 | 2. C 05 |
| FRONT END SIDE MEMBERS .....         | 2. C 06 |
| MAIN FLOOR.....                      | 2. C 06 |
| REAR FLOOR.....                      | 2. C 07 |
| REAR PANELS .....                    | 2. C 10 |
| ROOF.....                            | 2. C 09 |
| STONEGUARD.....                      | 2. C 11 |
| BONNET AND FITTINGS.....             | 2. C 13 |
| BONNET AND FITTINGS.....             | 2. C 13 |
| BONNET RELEASE AND CABLE .....       | 2. C 14 |
| BONNET SEALS.....                    | 2. C 15 |
| BUMPER AND FITTINGS.....             | 2. D 15 |
| FRONT BUMPER AND FITTINGS .....      | 2. D 15 |
| REAR BUMPER AND FITTINGS .....       | 2. D 16 |
| DOOR HANDELS, LOCKS, GLASS AND ..... | 2. C 18 |
| DOOR GLASS .....                     | 2. D 02 |
| DOOR SEALS.....                      | 2. D 06 |
| FRONT DOOR HANDELS AND LOCKS .....   | 2. C 18 |
| FRONT WINDOW REGULATORS.....         | 2. D 03 |
| REAR DOOR HANDELS AND LATCHES .....  | 2. D 04 |

|                                     |         |
|-------------------------------------|---------|
| REAR WINDOW REGULATORS.....         | 2. D 05 |
| DOORS.....                          | 2. C 16 |
| FRONT DOOR AND FITTINGS.....        | 2. C 16 |
| REAR DOOR AND FITTINGS .....        | 2. C 17 |
| ENGINE MOUNTINGS .....              | 2. C 02 |
| ENGINE MOUNTINGS 1800cc .....       | 2. C 02 |
| FINISHERS, BADGES AND PLUGS .....   | 2. D 17 |
| BADGES.....                         | 2. E 03 |
| BLANKING PLUGS AND GROMMETS.....    | 2. E 04 |
| FINISHERS.....                      | 2. D 18 |
| RUBBING STRIPS AND FITTINGS .....   | 2. E 02 |
| WHEEL ARCH LINERS.....              | 2. D 17 |
| FIXED GLASS .....                   | 2. D 10 |
| BACKLIGHT.....                      | 2. D 11 |
| WINDSCREEN AND FITTINGS .....       | 2. D 10 |
| FRONT FENDERS AND FITTINGS .....    | 2. C 12 |
| FENDER AND FRONT END FITTINGS ..... | 2. C 12 |
| FUEL FILLER LID AND FITTINGS .....  | 2. D 09 |
| FUEL FILLER LID.....                | 2. D 09 |
| MIRRORS.....                        | 2. D 14 |
| INTERIOR AND EXTERIOR MIRRORS.....  | 2. D 14 |
| SUBFRAME AND FITTINGS .....         | 2. C 03 |
| SUBFRAME - FRONT .....              | 2. C 03 |

|                                  |         |
|----------------------------------|---------|
| SUBFRAME - REAR.....             | 2. C 04 |
| TRUNK LID AND FITTINGS.....      | 2. D 07 |
| TRUNK LID AND FITTINGS.....      | 2. D 07 |
| TRUNK LID LOCK AND LATCHES ..... | 2. D 08 |
| WIPERS AND WASHERS .....         | 2. D 12 |
| HEADLAMP WASH .....              | 2. D 12 |
| WINDSCREEN WASH .....            | 2. D 13 |
| WINDSCREEN WIPERS.....           | 2. D 12 |



# SAMAND


F02

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

FACIA DETAILS

FACIA-COMPLETE ASSEMBLY



| Illus | Part Number |
|-------|-------------|
| 1     | 059 01 017  |
| 2     | 208 01 007  |
| 3     | 111 08 007  |
| 4     | 202 01 022  |
| 5     | 126 14 030  |
| 6     | 186 04 013  |
| 7     | 061 12 006  |
| 8     | 126 07 023  |
| 9     | 058 16 006  |
| 10    | 040 29 007  |
| 12    | 174 03 075  |
| 13    | 186 01 183  |
| 14    | 075 16 001  |


Description

Quantity

Change Point

Remarks

|                                                     |   |  |  |
|-----------------------------------------------------|---|--|--|
| DASH ASSY-ASSEMBLY.....                             | 1 |  |  |
| • Box.-glovebox-upper.....                          | 1 |  |  |
| • Buffer.-glovebox.....                             | 2 |  |  |
| • Rivet.-4.8 x 13.....                              | 2 |  |  |
| Trim.-fascia panel-finisher.-upper.....             | 1 |  |  |
| Washer.-star-M6.....                                | 3 |  |  |
| Cap.-panel-fusebox assy-Grey.....                   | 1 |  |  |
| Trim.-instrument cluster.....                       | 1 |  |  |
| Fixing Clip.-cover panel to fascia.....             | 2 |  |  |
| Screw.-M4.5 x 10-trim cover-instrument cluster..... | 2 |  |  |
| Nut.-fascia to body-hexagonal head-10 x 18.....     | 4 |  |  |
| Washer.-fascia to body-plain.-10 x 18.....          | 4 |  |  |
| Relay.-roof lamp timer.....                         | 1 |  |  |



ZP0019

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                        |        |
|----|----------------------------------------|--------|
| 1C | CARPET AND FLOOR FITTINGS.....         | 2.G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT.....  | 2.G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and.....   | 2.G 05 |
| 1F | INSULATION.....                        | 2.G 07 |
| 1G | FACIA DETAILS.....                     | 2.F 02 |
| 1H | FACIA COVERS AND FINISHERS.....        | 2.F 03 |
| 1I | FACIA-COMPLETE ASSEMBLY.....           | 2.F 02 |
| 1J | FASCIA PANEL TRIM.....                 | 2.F 05 |
| 1K | GLOVEBOX AND FIXINGS.....              | 2.F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY.....           | 2.F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS.....   | 2.F 07 |
| 2H | INTERIOR LINERS.....                   | 2.F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH..... | 2.F 08 |
|    | FRONT DOOR LINERS AND FITTINGS RH..... | 2.F 09 |
|    | HEADLINING.....                        | 2.F 14 |
|    | INTERIOR LINERS.....                   | 2.F 12 |
|    | PARCEL SHELF AND REAR END TRIM.....    | 2.F 15 |
|    | REAR DOOR LINERS AND FITTINGS LH.....  | 2.F 10 |
|    | REAR DOOR LINERS AND FITTINGS RH.....  | 2.F 11 |
|    | SEAT BELTS.....                        | 2.G 04 |
|    | SEAT BELTS AND FITTINGS.....           | 2.G 04 |
|    | SEATS.....                             | 2.F 16 |
|    | FRONT SEAT HEADRESTS AND FITTINGS..... | 2.F 18 |

# SAMAND

F03

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS  
FACIA DETAILS  
FACIA COVERS AND FINISHERS


Illus Part Number

Description

Quantity

Change  
Point

Remarks



1 126 14 024

Trim.-dash side cover-LH

1

2 126 14 026

Trim.-dash side cover-RH

1

4 126 14 027

Trim.-LH lower

1

5 040 29 006

Screw.-4.80mm-front panel-lower

2

6 040 14 019

Screw.-4.2 x 13-front panel-lower

2

8 126 14 032

Box.-glovebox-lower

1

9 126 14 028

Trim.-panel-foot heater-LH

1

10 126 14 029

Trim.-panel-foot heater-RH

1

11 040 14 071


Screw.-trim pad-foot heater

4

12 058 09 010

Fixing Clip.-trim pad-foot heater

4



ZP0004

## MASTER INDEX



ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I


## GROUP INDEX

CARPET AND FLOOR FITTINGS .....2.G 05  
CARPET AND FLOOR FITTINGS - BOOT .....2.G 06  
CARPET/FLOOR FITTINGS-FRONT and .....2.G 05  
INSULATION.....2.G 07  
FACIA DETAILS .....2.F 02  
FACIA COVERS AND FINISHERS .....2.F 03  
FACIA-COMplete ASSEMBLY .....2.F 02  
FASCIA PANEL TRIM .....2.F 05  
GLOVEBOX AND FIXINGS .....2.F 04  
TUNNEL CONSOLE ASSEMBLY .....2.F 06  
TUNNEL CONSOLE DUCTS & FITTINGS.....2.F 07  
INTERIOR LINERS.....2.F 08  
FRONT DOOR LINERS AND FITTINGS LH .....2.F 08  
FRONT DOOR LINERS AND FITTINGS RH.....2.F 09  
HEADLINING.....2.F 14  
INTERIOR LINERS.....2.F 12  
PARCEL SHELF AND REAR END TRIM .....2.F 15  
REAR DOOR LINERS AND FITTINGS LH.....2.F 10  
REAR DOOR LINERS AND FITTINGS RH .....2.F 11  
SEAT BELTS.....2.G 04  
SEAT BELTS AND FITTINGS.....2.G 04  
SEATS.....2.F 16  
FRONT SEAT HEADRESTS AND FITTINGS.....2.F 18

|        |               |                                                                         |
|--------|---------------|-------------------------------------------------------------------------|
| SAMAND | F04<br>FICHE2 | FACIA, TRIM, SEATS AND FIXINGS<br>FACIA DETAILS<br>GLOVEBOX AND FIXINGS |
|--------|---------------|-------------------------------------------------------------------------|



| Illus | Part Number | Description                                       | Quantity | Change Point | Remarks |
|-------|-------------|---------------------------------------------------|----------|--------------|---------|
| 1     | 208 01 009  | BOX.                                              | 1        |              |         |
| 2     | 170 04 007  | · PLUG/COVER.                                     | 1        |              |         |
| 3     | 170 04 009  | .. Plug/Cover.                                    | 1        |              |         |
| 4     | 208 01 011  | .. Box.-glove box                                 | 1        |              |         |
| 5     | 040 29 007  | .. Screw.-M4.5 x 10-trim cover-instrument cluster | 4        |              |         |
| 6     | 160 02 007  | .. Rubber Cover.-glovebox                         | 1        |              |         |
| 7     | 169 04 001  | Glove box-lock- actuator                          | 1        |              |         |



ZP0020

# SAMAND


F05

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

FACIA DETAILS

FASCIA PANEL TRIM



Illus Part Number

2 126 22 011  
2 126 11 011  
3 126 14 031  
4 061 13 007  
5 049 02 005  
70 040 14 088


Description

Trim.-air con controls-centre console-front ..... 1  
Trim.-feature pack-centre console-front ..... 1  
Trim.-grille-centre console-front ..... 1  
Cap. .... 1  
Ash Tray Assy.-centre console-front ..... 1  
Screw.-M2.9 ..... 2

Quantity

Change Point

Remarks



ZP0021

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

CARPET AND FLOOR FITTINGS ..... 2.G 05  
CARPET AND FLOOR FITTINGS - BOOT ..... 2.G 06  
CARPET/FLOOR FITTINGS-FRONT and ..... 2.G 05  
INSULATION ..... 2.G 07  
FACIA DETAILS ..... 2.F 02  
FACIA COVERS AND FINISHERS ..... 2.F 03  
FACIA-COMPLETE ASSEMBLY ..... 2.F 02  
FASCIA PANEL TRIM ..... 2.F 05  
GLOVEBOX AND FIXINGS ..... 2.F 04  
TUNNEL CONSOLE ASSEMBLY ..... 2.F 06  
TUNNEL CONSOLE DUCTS & FITTINGS ..... 2.F 07  
INTERIOR LINERS ..... 2.F 08  
FRONT DOOR LINERS AND FITTINGS LH ..... 2.F 08  
FRONT DOOR LINERS AND FITTINGS RH ..... 2.F 09  
HEADLINING ..... 2.F 14  
INTERIOR LINERS ..... 2.F 12  
PARCEL SHELF AND REAR END TRIM ..... 2.F 15  
REAR DOOR LINERS AND FITTINGS LH ..... 2.F 10  
REAR DOOR LINERS AND FITTINGS RH ..... 2.F 11  
SEAT BELTS ..... 2.G 04  
SEAT BELTS AND FITTINGS ..... 2.G 04  
SEATS ..... 2.F 16  
FRONT SEAT HEADRESTS AND FITTINGS ..... 2.F 18



# SAMAND






F06

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

FACIA DETAILS

TUNNEL CONSOLE ASSEMBLY



ZP0003

## Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 152 | 01 | 020 |
| 2  | 239 | 07 | 002 |
| 3  | 164 | 06 | 005 |
| 4  | 170 | 17 | 002 |
| 70 | 186 | 01 | 169 |
| 71 | 040 | 05 | 037 |
| 73 | 040 | 14 | 083 |
| 5  | 126 | 24 | 012 |
| 6  | 049 | 01 | 009 |
| 7  | 062 | 07 | 001 |
| 8  | 062 | 07 | 002 |
| 9  | 156 | 03 | 018 |
| 10 | 126 | 01 | 014 |
| 11 | 156 | 03 | 020 |
| 12 | 156 | 18 | 001 |
| 13 | 126 | 25 | 007 |

## Description

|                                            |   |
|--------------------------------------------|---|
| CENTRE CONSOLE.-REAR .....                 | 1 |
| • Socket.-centre console-rear .....        | 1 |
| • Hinge.-centre console-rear .....         | 1 |
| Plug/Cover.-centre console-rear .....      | 1 |
| Washer.-10.2 x 17-13 .....                 | 3 |
| Screw.-M5 x 80.-centre console-top .....   | 2 |
| Screw.-console to brkt-rear .....          | 3 |
| TRIM.-CENTRE CONSOLE-REAR .....            | 1 |
| • Ash Tray Assy.-centre console-rear ..... | 1 |
| Air Vent.-centre console-rear-LH .....     | 1 |
| Air Vent.-centre console-rear-RH .....     | 1 |
| GAITER.-GEAR LEVER .....                   | 1 |
| • Trim.-gear lever gaiter .....            | 1 |
| Gaiter.-handbrake surround .....           | 1 |
| GAITER.-HANDBRAKE .....                    | 1 |
| • Trim.-handbrake gaiter .....             | 1 |

## Quantity

## Change Point

## Remarks

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX


|                                         |        |
|-----------------------------------------|--------|
| CARPET AND FLOOR FITTINGS .....         | 2 G 05 |
| CARPET AND FLOOR FITTINGS - BOOT .....  | 2 G 06 |
| CARPET/FLOOR FITTINGS-FRONT and .....   | 2 G 05 |
| INSULATION .....                        | 2 G 07 |
| FACIA DETAILS .....                     | 2 F 02 |
| FACIA COVERS AND FINISHERS .....        | 2 F 03 |
| FACIA-COMplete ASSEMBLY .....           | 2 F 02 |
| FASCIA PANEL TRIM .....                 | 2 F 05 |
| GLOVEBOX AND FIXINGS .....              | 2 F 04 |
| TUNNEL CONSOLE ASSEMBLY .....           | 2 F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS .....   | 2 F 07 |
| INTERIOR LINERS .....                   | 2 F 08 |
| FRONT DOOR LINERS AND FITTINGS LH ..... | 2 F 08 |
| FRONT DOOR LINERS AND FITTINGS RH ..... | 2 F 09 |
| HEADLINING .....                        | 2 F 14 |
| INTERIOR LINERS .....                   | 2 F 12 |
| PARCEL SHELF AND REAR END TRIM .....    | 2 F 15 |
| REAR DOOR LINERS AND FITTINGS LH .....  | 2 F 10 |
| REAR DOOR LINERS AND FITTINGS RH .....  | 2 F 11 |
| SEAT BELTS .....                        | 2 G 04 |
| SEAT BELTS AND FITTINGS .....           | 2 G 04 |
| SEATS .....                             | 2 F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS ..... | 2 F 18 |

# SAMAND

F07

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS FACIA DETAILS TUNNEL CONSOLE DUCTS & FITTINGS



### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 230 | 01 | 012 |
| 3  | 230 | 01 | 013 |
| 4  | 181 | 22 | 004 |
| 5  | 181 | 22 | 005 |
| 6  | 058 | 05 | 011 |
| 7  | 181 | 22 | 006 |
| 70 | 040 | 14 | 019 |
| 71 | 174 | 08 | 007 |
| 72 | 040 | 14 | 021 |
| 73 | 174 | 14 | 011 |


### Description

|                                                     |   |
|-----------------------------------------------------|---|
| Ducting.-rear passenger-LH-centre console-rear..... | 1 |
| Ducting.-rear passenger-RH-centre console-rear..... | 1 |
| Bracket.-bracket-centre console-rear.....           | 1 |
| Bracket.-dash floor.....                            | 1 |
| Fixing Clip.-console to brkt-clamping-top.....      | 2 |
| Bracket.-front-centre console.....                  | 1 |
| Screw.-duct to bracket-4.2 x 13-front panel-.....   | 2 |
| lower.....                                          |   |
| Nut.-centre console-bracket-rear.....               | 1 |
| Screw.-console to brkt-side-M6 x 100-16.....        | 2 |
| Nut.-bracket to gearbox cover-speed-6mm x 100.....  | 2 |

### Quantity

### Change Point

### Remarks



ZP0016

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX


|    |                                        |         |
|----|----------------------------------------|---------|
| 1C | CARPET AND FLOOR FITTINGS.....         | 2. G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT.....  | 2. G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and.....   | 2. G 05 |
| 1F | INSULATION.....                        | 2. G 07 |
| 1G | FACIA DETAILS.....                     | 2. F 02 |
| 1H | FACIA COVERS AND FINISHERS.....        | 2. F 03 |
| 1I | FACIA-COMplete ASSEMBLY.....           | 2. F 02 |
| 1J | FASCIA PANEL TRIM.....                 | 2. F 05 |
| 1K | GLOVEBOX AND FIXINGS.....              | 2. F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY.....           | 2. F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS.....   | 2. F 07 |
| 2H | INTERIOR LINERS.....                   | 2. F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH..... | 2. F 08 |
|    | FRONT DOOR LINERS AND FITTINGS RH..... | 2. F 09 |
|    | HEADLINING.....                        | 2. F 14 |
|    | INTERIOR LINERS.....                   | 2. F 12 |
|    | PARCEL SHELF AND REAR END TRIM.....    | 2. F 15 |
|    | REAR DOOR LINERS AND FITTINGS LH.....  | 2. F 10 |
|    | REAR DOOR LINERS AND FITTINGS RH.....  | 2. F 11 |
|    | SEAT BELTS.....                        | 2. G 04 |
|    | SEAT BELTS AND FITTINGS.....           | 2. G 04 |
|    | SEATS.....                             | 2. F 16 |
|    | FRONT SEAT HEADRESTS AND FITTINGS..... | 2. F 18 |

# SAMAND

F08

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS FRONT DOOR LINERS AND FITTINGS LH



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 076 | 02 | 010 |
| 2  | 058 | 20 | 021 |
| 3  | 126 | 13 | 016 |
| 4  | 040 | 14 | 087 |
| 5  | 063 | 06 | 021 |
| 6  | 126 | 10 | 020 |
| 7  | 186 | 04 | 014 |
| 8  | 103 | 04 | 011 |
| 9  | 058 | 27 | 006 |
| 10 | 126 | 18 | 007 |
| 11 | 126 | 23 | 012 |
| 12 | 007 | 02 | 007 |
| 13 | 126 | 08 | 025 |
| 14 | 030 | 22 | 001 |
| 15 | 225 | 04 | 010 |
| 16 | 061 | 21 | 013 |
| 18 | 061 | 21 | 006 |
| 19 | 126 | 09 | 026 |
| 20 | 063 | 01 | 011 |
| 21 | 181 | 69 | 002 |
| 22 | 202 | 01 | 021 |
| 23 | 186 | 01 | 016 |
| 25 | 058 | 07 | 010 |
| 26 | 114 | 02 | 021 |

Description

|                                           |    |
|-------------------------------------------|----|
| DOOR CASING.-FRONT DOOR-LH-GREY.....      | 1  |
| • Fixing Clip.....                        | 8  |
| • Trim.-map-LH.....                       | 1  |
| • Screw.-M6 x 100-25.....                 | 12 |
| • Handle.-grab-front door-LH.....         | 1  |
| • Trim.-front door-LH.....                | 1  |
| • Washer.-star.....                       | 3  |
| • Grill.-loudspeaker-front door-LH.....   | 1  |
| • Fixing Clip.....                        | 2  |
| • Trim.-door lock knob.....               | 1  |
| • Trim.-switch.-front door-LH.....        | 1  |
| • foam pad-foam.....                      | 1  |
| • Trim.-exterior mirror -inner LH.....    | 1  |
| • Bush.....                               | 3  |
| • Button.-door lock.....                  | 1  |
| • Cap.-inner.....                         | 1  |
| • Cap.-front door.....                    | 1  |
| • Trim.-LH.....                           | 1  |
| • Handle.-LH.....                         | 1  |
| • Bracket.-front door-LH.....             | 1  |
| • Rivet.....                              | 4  |
| • Washer.-8 x 22mm-plain.....             | 2  |
| • Fixing Clip.....                        | 2  |
| • Isolator.-Waterproof-front door-LH..... | 1  |

Quantity

Change Point

Remarks

ZP0012

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX



|                                        |         |
|----------------------------------------|---------|
| CARPET AND FLOOR FITTINGS.....         | 2. G 05 |
| CARPET AND FLOOR FITTINGS - BOOT.....  | 2. G 06 |
| CARPET/FLOOR FITTINGS-FRONT and.....   | 2. G 05 |
| INSULATION.....                        | 2. G 07 |
| FACIA DETAILS.....                     | 2. F 02 |
| FACIA COVERS AND FINISHERS.....        | 2. F 03 |
| FACIA-COMplete ASSEMBLY.....           | 2. F 02 |
| FASCIA PANEL TRIM.....                 | 2. F 05 |
| GLOVEBOX AND FIXINGS.....              | 2. F 04 |
| TUNNEL CONSOLE ASSEMBLY.....           | 2. F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS.....   | 2. F 07 |
| INTERIOR LINERS.....                   | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS LH..... | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS RH..... | 2. F 09 |
| HEADLINING.....                        | 2. F 14 |
| INTERIOR LINERS.....                   | 2. F 12 |
| PARCEL SHELF AND REAR END TRIM.....    | 2. F 15 |
| REAR DOOR LINERS AND FITTINGS LH.....  | 2. F 10 |
| REAR DOOR LINERS AND FITTINGS RH.....  | 2. F 11 |
| SEAT BELTS.....                        | 2. G 04 |
| SEAT BELTS AND FITTINGS.....           | 2. G 04 |
| SEATS.....                             | 2. F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS..... | 2. F 18 |

# SAMAND

F09

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS FRONT DOOR LINERS AND FITTINGS RH



ZP0002

### Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 076 | 03 | 012 |
| 2  | 058 | 20 | 021 |
| 3  | 126 | 13 | 018 |
| 4  | 040 | 14 | 087 |
| 5  | 063 | 06 | 023 |
| 6  | 126 | 10 | 021 |
| 7  | 186 | 04 | 014 |
| 8  | 103 | 04 | 012 |
| 9  | 058 | 27 | 006 |
| 10 | 126 | 18 | 007 |
| 11 | 126 | 23 | 014 |
| 12 | 007 | 02 | 007 |
| 13 | 126 | 08 | 024 |
| 14 | 030 | 22 | 001 |
| 15 | 225 | 04 | 010 |
| 16 | 061 | 21 | 009 |
| 4  | 040 | 14 | 087 |
| 18 | 061 | 21 | 006 |
| 19 | 126 | 09 | 028 |
| 20 | 063 | 02 | 010 |
| 21 | 181 | 69 | 003 |
| 22 | 202 | 01 | 021 |
| 23 | 186 | 01 | 016 |
| 25 | 058 | 07 | 010 |
| 26 | 114 | 02 | 022 |

### Description

|                                            |   |
|--------------------------------------------|---|
| DOOR CASING.-FRONT DOOR-RH-GREY .....      | 1 |
| • Fixing Clip.....                         | 8 |
| • Trim.-map-front door-RH .....            | 1 |
| • Screw.-M6 x 100-25.....                  | 8 |
| • Handle.-grab-front door-RH.....          | 1 |
| • Trim.-front door-RH.....                 | 1 |
| • Washer.-star .....                       | 3 |
| • Grill.-loudspeaker-front door-RH .....   | 1 |
| • Fixing Clip.....                         | 1 |
| • Trim.-door lock knob .....               | 1 |
| • Trim.-switch.-front door-RH.....         | 1 |
| • foam pad-foam .....                      | 1 |
| • Trim.-exterior mirror -inner-RH.....     | 1 |
| • Bush. ....                               | 3 |
| • Button.-door lock .....                  | 1 |
| • Cap.-pocket moulding-inner RH .....      | 1 |
| • Screw.-M6 x 100-25.....                  | 2 |
| • Cap.-front door .....                    | 1 |
| • Trim.-RH .....                           | 1 |
| • Handle.-RH.....                          | 1 |
| • Bracket.-front door-RH .....             | 1 |
| • Rivet. ....                              | 4 |
| • Washer.-8 x 22mm-plain.....              | 2 |
| • Fixing Clip.....                         | 2 |
| • Isolator.-Waterproof-front door-LH ..... | 1 |

### Quantity

### Change Point

### Remarks

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX


|                                         |     |    |
|-----------------------------------------|-----|----|
| CARPET AND FLOOR FITTINGS.....          | 2.G | 05 |
| CARPET AND FLOOR FITTINGS - BOOT .....  | 2.G | 06 |
| CARPET/FLOOR FITTINGS-FRONT and .....   | 2.G | 05 |
| INSULATION.....                         | 2.G | 07 |
| FACIA DETAILS.....                      | 2.F | 02 |
| FACIA COVERS AND FINISHERS .....        | 2.F | 03 |
| FACIA-COMplete ASSEMBLY .....           | 2.F | 02 |
| FACIA PANEL TRIM .....                  | 2.F | 05 |
| GLOVEBOX AND FIXINGS .....              | 2.F | 04 |
| TUNNEL CONSOLE ASSEMBLY .....           | 2.F | 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS.....    | 2.F | 07 |
| INTERIOR LINERS.....                    | 2.F | 08 |
| FRONT DOOR LINERS AND FITTINGS LH ..... | 2.F | 08 |
| FRONT DOOR LINERS AND FITTINGS RH.....  | 2.F | 09 |
| HEADLINING .....                        | 2.F | 14 |
| INTERIOR LINERS.....                    | 2.F | 12 |
| PARCEL SHELF AND REAR END TRIM .....    | 2.F | 15 |
| REAR DOOR LINERS AND FITTINGS LH.....   | 2.F | 10 |
| REAR DOOR LINERS AND FITTINGS RH .....  | 2.F | 11 |
| SEAT BELTS.....                         | 2.G | 04 |
| SEAT BELTS AND FITTINGS .....           | 2.G | 04 |
| SEATS.....                              | 2.F | 16 |
| FRONT SEAT HEADRESTS AND FITTINGS.....  | 2.F | 18 |

# SAMAND

F10

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS REAR DOOR LINERS AND FITTINGS LH




Illus Part Number

Description

Quantity Change Remarks  
Point

|    |            |                                 |   |  |  |
|----|------------|---------------------------------|---|--|--|
| 1  | 076 04 011 | DOOR CASING.-REAR DOOR-LH-GREY  | 1 |  |  |
| 2  | 208 06 004 | Box.-protection-LH              | 1 |  |  |
| 73 | 040 29 005 | Screw.-M6 x 100-20              | 8 |  |  |
| 4  | 126 23 015 | Switch.-Cover -rear door-LH     | 1 |  |  |
| 5  | 063 06 025 | Handle.-grab-rear door-LH       | 1 |  |  |
| 6  | 058 20 020 | Fixing Clip.                    | 8 |  |  |
| 7  | 225 04 010 | Button.-door lock               | 1 |  |  |
| 8  | 126 18 007 | Trim.-door lock knob            | 1 |  |  |
| 9  | 063 01 011 | Handle.-LH                      | 1 |  |  |
| 10 | 126 09 026 | Trim.-LH                        | 1 |  |  |
| 11 | 181 57 005 | Bracket.-No1-rear door-LH-lower | 1 |  |  |
| 12 | 181 57 003 | Bracket.-No2-rear door-LH-upper | 1 |  |  |
| 13 | 202 01 021 | Rivet.                          | 8 |  |  |
| 14 | 040 14 087 | Screw.-M6 x 100-25              | 2 |  |  |
| 15 | 186 02 043 | Washer.-elastic                 | 2 |  |  |
| 16 | 114 02 023 | Shield.-Waterproof-rear door-LH | 1 |  |  |



ZP0007

### MASTER INDEX

### GROUP INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index


|    |                                   |         |
|----|-----------------------------------|---------|
| 1C | CARPET AND FLOOR FITTINGS         | 2. G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT  | 2. G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and   | 2. G 05 |
| 1F | INSULATION                        | 2. G 07 |
| 1G | FACIA DETAILS                     | 2. F 02 |
| 1H | FACIA COVERS AND FINISHERS        | 2. F 03 |
| 1I | FACIA-COMplete ASSEMBLY           | 2. F 02 |
| 1J | FASCIA PANEL TRIM                 | 2. F 05 |
| 1K | GLOVEBOX AND FIXINGS              | 2. F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY           | 2. F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS   | 2. F 07 |
| 2H | INTERIOR LINERS                   | 2. F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH | 2. F 08 |
| 2J | FRONT DOOR LINERS AND FITTINGS RH | 2. F 09 |
| 2K | HEADLINING                        | 2. F 14 |
| 2L | INTERIOR LINERS                   | 2. F 12 |
| 2M | PARCEL SHELF AND REAR END TRIM    | 2. F 15 |
| 2N | REAR DOOR LINERS AND FITTINGS LH  | 2. F 10 |
| 2O | REAR DOOR LINERS AND FITTINGS RH  | 2. F 11 |
| 2P | SEAT BELTS                        | 2. G 04 |
| 2Q | SEAT BELTS AND FITTINGS           | 2. G 04 |
| 2R | SEATS                             | 2. F 16 |
| 2S | FRONT SEAT HEADRESTS AND FITTINGS | 2. F 18 |

# SAMAND

F11  
Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS REAR DOOR LINERS AND FITTINGS RH

| Illus | Part Number | Description                       | Quantity | Change Point | Remarks |
|-------|-------------|-----------------------------------|----------|--------------|---------|
| 1     | 076 05 010  | DOOR CASING.-REAR DOOR-RH-GREY    | 1        |              |         |
| 2     | 208 06 006  | Box.-protection-RH                | 1        |              |         |
| 3     | 040 29 005  | Screw.-M6 x 100-20                | 8        |              |         |
| 4     | 126 23 016  | switch cover rear door_rh         | 1        |              |         |
| 5     | 063 06 027  | Handle.-grab-rear door-RH         | 1        |              |         |
| 6     | 058 20 020  | Fixing Clip.                      | 2        |              |         |
| 7     | 225 04 010  | Button.-door lock                 | 1        |              |         |
| 8     | 126 18 007  | Trim.-door lock knob              | 1        |              |         |
| 9     | 063 02 010  | Handle.-RH                        | 1        |              |         |
| 10    | 126 09 028  | Trim.-RH                          | 1        |              |         |
| 11    | 181 57 002  | Bracket.-No1-rear door-RH         | 1        |              |         |
| 12    | 181 57 004  | Bracket.-No2-rear door-RH         | 1        |              |         |
| 13    | 202 01 021  | Rivet.                            | 1        |              |         |
| 14    | 040 14 087  | Screw.-M6 x 100-25                | 2        |              |         |
| 15    | 186 02 043  | Washer.-elastic                   | 2        |              |         |
| 16    | 114 02 024  | Isolator.-Waterproof-rear door-RH | 1        |              |         |



### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                   |        |
|-----------------------------------|--------|
| CARPET AND FLOOR FITTINGS         | 2.G 05 |
| CARPET AND FLOOR FITTINGS - BOOT  | 2.G 06 |
| CARPET/FLOOR FITTINGS-FRONT and   | 2.G 05 |
| INSULATION                        | 2.G 07 |
| FACIA DETAILS                     | 2.F 02 |
| FACIA COVERS AND FINISHERS        | 2.F 03 |
| FACIA-COMplete ASSEMBLY           | 2.F 02 |
| FASCIA PANEL TRIM                 | 2.F 05 |
| GLOVEBOX AND FIXINGS              | 2.F 04 |
| TUNNEL CONSOLE ASSEMBLY           | 2.F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS   | 2.F 07 |
| INTERIOR LINERS                   | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS LH | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS RH | 2.F 09 |
| HEADLINING                        | 2.F 14 |
| INTERIOR LINERS                   | 2.F 12 |
| PARCEL SHELF AND REAR END TRIM    | 2.F 15 |
| REAR DOOR LINERS AND FITTINGS LH  | 2.F 10 |
| REAR DOOR LINERS AND FITTINGS RH  | 2.F 11 |
| SEAT BELTS                        | 2.G 04 |
| SEAT BELTS AND FITTINGS           | 2.G 04 |
| SEATS                             | 2.F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS | 2.F 18 |



# SAMAND



F12

FICHE2

FACIA, TRIM, SEATS AND FIXINGS

INTERIOR LINERS

INTERIOR LINERS



| Illus | Part Number | Description                                    | Quantity | Change Point | Remarks |
|-------|-------------|------------------------------------------------|----------|--------------|---------|
| 1     | 126 15 049  | Trim.-B/C post upper-LH-Grey                   | 1        |              |         |
| 1     | 126 15 051  | Trim.-B/C post upper-RH-Grey                   | 1        |              |         |
| 2     | 128 14 004  | Panel.-adjuster-seat belt-B/C post upper-Grey  | 1        |              |         |
| 3     | 058 27 007  | Fixing Clip.                                   | 22       |              |         |
| 4     | 040 14 084  | Screw.-3.5 x 16                                | 1        |              |         |
| 5     | 126 15 046  | Trim.-B/C post lower-RH-Grey                   | 1        |              |         |
| 5     | 126 15 045  | Trim.-B/C post lower-LH-Grey                   | 1        |              |         |
| 6     | 083 16 001  | Safety Catch.-seat belt-B/C post lower-LH-Grey | 1        |              |         |
| 6     | 083 16 003  | Safety Catch.-seat belt-B/C post lower-RH-Grey | 1        |              |         |
| 7     | 040 14 085  | Screw.-CBL 3.5 x 25                            | 3        |              |         |
| 11    | 126 19 013  | Trim.-D post lower-LH-Grey                     | 1        |              |         |
| 11    | 126 19 015  | Trim.-D post lower-RH-Grey                     | 1        |              |         |
| 22    | 237 06 012  | Protecting Plate.-D post upper                 | 2        |              |         |
| 14    | 126 15 038  | Trim.-D post upper-LH-Grey                     | 1        |              |         |
| 14    | 126 15 040  | Trim.-D post upper-RH-Grey                     | 1        |              |         |
| 16    | 040 14 086  | SCREW                                          | 2        |              |         |

ZP0015

# SAMAND

F13

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS INTERIOR LINERS



Illus Part Number

13 126 15 036  
13 126 15 042  
17 237 06 010  
17 237 06 011  
19 237 06 013  
19 237 06 015  
20 116 09 001  
20 116 09 002


Description

Trim.-A post lower-LH-Grey ..... 1  
Trim.-A post lower-RH-Grey ..... 1  
Sound Deadening.-A post lower-RH ..... 1  
Sound Deadening.-A post lower-LH ..... 1  
Sound Deadening.-A post upper-LH-Grey ..... 1  
Sound Deadening.-A post upper-RH-Grey ..... 1  
Tensioner.-seat belt-LH ..... 1  
Tensioner.-seat belt-RH ..... 1

Quantity

Change Point

Remarks



ZP0015

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX







CARPET AND FLOOR FITTINGS ..... 2.G 05  
CARPET AND FLOOR FITTINGS - BOOT ..... 2.G 06  
CARPET/FLOOR FITTINGS-FRONT and ..... 2.G 05  
INSULATION ..... 2.G 07  
FACIA DETAILS ..... 2.F 02  
FACIA COVERS AND FINISHERS ..... 2.F 03  
FACIA-COMplete ASSEMBLY ..... 2.F 02  
FASCIA PANEL TRIM ..... 2.F 05  
GLOVEBOX AND FIXINGS ..... 2.F 04  
TUNNEL CONSOLE ASSEMBLY ..... 2.F 06  
TUNNEL CONSOLE DUCTS & FITTINGS ..... 2.F 07  
INTERIOR LINERS ..... 2.F 08  
FRONT DOOR LINERS AND FITTINGS LH ..... 2.F 08  
FRONT DOOR LINERS AND FITTINGS RH ..... 2.F 09  
HEADLINING ..... 2.F 14  
INTERIOR LINERS ..... 2.F 12  
PARCEL SHELF AND REAR END TRIM ..... 2.F 15  
REAR DOOR LINERS AND FITTINGS LH ..... 2.F 10  
REAR DOOR LINERS AND FITTINGS RH ..... 2.F 11  
SEAT BELTS ..... 2.G 04  
SEAT BELTS AND FITTINGS ..... 2.G 04  
SEATS ..... 2.F 16  
FRONT SEAT HEADRESTS AND FITTINGS ..... 2.F 18

# SAMAND

F14

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS HEADLINING



Illus Part Number

Description

Quantity

Change  
Point

Remarks

- |    |            |
|----|------------|
| 1  | 126 06 019 |
| 2  | 040 14 089 |
| 3  | 126 06 023 |
| 4  | 078 02 006 |
| 5  | 063 08 011 |
| 5  | 063 08 008 |
| 6  | 040 14 082 |
| 7  | 008 01 002 |
| 8  | 008 02 003 |
| 9  | 025 01 117 |
| 10 | 181 40 002 |

- |                                 |   |
|---------------------------------|---|
| Trim.-roof.-front-Grey          | 1 |
| Screw.-console to roof-4.2 x 16 | 6 |
| Trim.-roof.-rear                | 1 |
| Cover.-roof.-Grey               | 1 |
| Handle.-grab-roof.-RR-Grey      | 2 |
| Handle.-grab-roof.-FRT-Grey     | 1 |
| Screw.-pan head-M6 x 35         | 6 |
| Sun Visors-LH-Grey              | 1 |
| Sun Visors-RH-Grey              | 1 |
| Clip.-push clip head liner      | 2 |
| Bracket.                        | 2 |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX


CARPET AND FLOOR FITTINGS .....2.G 05  
CARPET AND FLOOR FITTINGS - BOOT .....2.G 06  
CARPET/FLOOR FITTINGS-FRONT and .....2.G 05  
INSULATION .....2.G 07  
FACIA DETAILS .....2.F 02  
FACIA COVERS AND FINISHERS .....2.F 03  
FACIA-COMplete ASSEMBLY .....2.F 02  
FASCIA PANEL TRIM .....2.F 05  
GLOVEBOX AND FIXINGS .....2.F 04  
TUNNEL CONSOLE ASSEMBLY .....2.F 06  
TUNNEL CONSOLE DUCTS & FITTINGS.....2.F 07  
INTERIOR LINERS .....2.F 08  
FRONT DOOR LINERS AND FITTINGS LH .....2.F 08  
FRONT DOOR LINERS AND FITTINGS RH .....2.F 09  
HEADLINING .....2.F 14  
INTERIOR LINERS .....2.F 12  
PARCEL SHELF AND REAR END TRIM .....2.F 15  
REAR DOOR LINERS AND FITTINGS LH .....2.F 10  
REAR DOOR LINERS AND FITTINGS RH .....2.F 11  
SEAT BELTS .....2.G 04  
SEAT BELTS AND FITTINGS .....2.G 04  
SEATS .....2.F 16  
FRONT SEAT HEADRESTS AND FITTINGS .....2.F 18

# SAMAND


F15

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS INTERIOR LINERS PARCEL SHELF AND REAR END TRIM



| Illus | Part Number | Description                          | Quantity | Change Point | Remarks |
|-------|-------------|--------------------------------------|----------|--------------|---------|
| 1     | 019 01 008  | Parcel Shelf.-Grey                   | 1        |              |         |
| 2     | 103 04 009  | Grill.-loudspeaker-parcel shelf-LH   | 1        |              |         |
| 2     | 103 04 010  | Grill.-loudspeaker-parcel shelf-RH   | 1        |              |         |
| 3     | 058 27 006  | Fixing Clip.                         | 8        |              |         |
| 4     | 126 38 001  | Trim.-with high-level stop lamp-Grey | 1        |              |         |
| 5     | 083 16 005  | Safety Catch.-rear-seat belt-LH-Grey | 1        |              |         |
| 6     | 083 16 007  | Safety Catch.-rear-seat belt-RH-Grey | 1        |              |         |
| 7     | 058 09 011  | Fixing Clip.                         | 1        |              |         |
| 11    | 040 29 004  | Screw.-M6 x 100-16                   | 4        |              |         |
| 12    | 186 02 043  | Washer.-elastic                      | 2        |              |         |



ZP0013

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

### GROUP INDEX


|    |                                         |         |
|----|-----------------------------------------|---------|
| 1C | CARPET AND FLOOR FITTINGS.....          | 2. G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT .....  | 2. G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and .....   | 2. G 05 |
| 1F | INSULATION.....                         | 2. G 07 |
| 1G | FACIA DETAILS .....                     | 2. F 02 |
| 1H | FACIA COVERS AND FINISHERS .....        | 2. F 03 |
| 1I | FACIA-COMplete ASSEMBLY .....           | 2. F 02 |
| 1J | FACIA PANEL TRIM .....                  | 2. F 05 |
| 1K | GLOVEBOX AND FIXINGS .....              | 2. F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY .....           | 2. F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS.....    | 2. F 07 |
| 2H | INTERIOR LINERS .....                   | 2. F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH ..... | 2. F 08 |
|    | FRONT DOOR LINERS AND FITTINGS RH.....  | 2. F 09 |
|    | HEADLINING.....                         | 2. F 14 |
|    | INTERIOR LINERS.....                    | 2. F 12 |
|    | PARCEL SHELF AND REAR END TRIM .....    | 2. F 15 |
|    | REAR DOOR LINERS AND FITTINGS LH.....   | 2. F 10 |
|    | REAR DOOR LINERS AND FITTINGS RH .....  | 2. F 11 |
|    | SEAT BELTS .....                        | 2. G 04 |
|    | SEAT BELTS AND FITTINGS.....            | 2. G 04 |
|    | SEATS.....                              | 2. F 16 |
|    | FRONT SEAT HEADRESTS AND FITTINGS.....  | 2. F 18 |

# SAMAND

F16

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS SEATS FRONT SEAT FRAME AND FITTINGS LEFT HAND



Illus Part Number

|    |            |
|----|------------|
| 2  | 079 03 008 |
| 3  | 040 29 008 |
| 4  | 186 24 029 |
| 5  | 079 03 007 |
| 6  | 058 07 017 |
| 7  | 051 09 004 |
| 8  | 213 01 007 |
| 9  | 040 11 011 |
| 10 | 121 13 004 |
| 11 | 051 09 002 |
| 12 | 121 13 005 |
| 13 | 025 21 003 |
| 14 | 063 09 004 |
| 15 | 058 01 070 |
| 16 | 058 15 014 |
| 17 | 122 03 003 |
| 18 | 122 04 003 |
| 19 | 205 03 002 |
| 20 | 030 22 046 |

Description

|                                     |
|-------------------------------------|
| Slide.-drivers seat.                |
| Screw.-M8 x 125 - 40                |
| Washer.-seat retaining              |
| Slide.-control-seat slide unlocking |
| Fixing Clip.                        |
| Seat Adjuster.-height adjustment-LH |
| Seat Frame.-front seat-LH           |
| Screw.-lumber support               |
| Spring.-lumber support              |
| Seat Adjuster.-lumber support       |
| Spring.-lumber support              |
| Clip.-lumber support                |
| Handle.-Black                       |
| Fixing Clip.                        |
| Fixing Clip.                        |
| Seat Padding.-front seat cushion    |
| Seat Padding.-front seat backrest   |
| Grommet.-headrest                   |
| Bush.-front seat-inner              |

Quantity

Change  
Point

Remarks

|    |
|----|
| 1  |
| 6  |
| 6  |
| 1  |
| 2  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 1  |
| 26 |
| 1  |
| 1  |
| 2  |
| 2  |

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I


### GROUP INDEX

|                                   |        |
|-----------------------------------|--------|
| CARPET AND FLOOR FITTINGS         | 2.G 05 |
| CARPET AND FLOOR FITTINGS - BOOT  | 2.G 06 |
| CARPET/FLOOR FITTINGS-FRONT and   | 2.G 05 |
| INSULATION                        | 2.G 07 |
| FACIA DETAILS                     | 2.F 02 |
| FACIA COVERS AND FINISHERS        | 2.F 03 |
| FACIA-COMplete ASSEMBLY           | 2.F 02 |
| FASCIA PANEL TRIM                 | 2.F 05 |
| GLOVEBOX AND FIXINGS              | 2.F 04 |
| TUNNEL CONSOLE ASSEMBLY           | 2.F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS   | 2.F 07 |
| INTERIOR LINERS                   | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS LH | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS RH | 2.F 09 |
| HEADLINING                        | 2.F 14 |
| INTERIOR LINERS                   | 2.F 12 |
| PARCEL SHELF AND REAR END TRIM    | 2.F 15 |
| REAR DOOR LINERS AND FITTINGS LH  | 2.F 10 |
| REAR DOOR LINERS AND FITTINGS RH  | 2.F 11 |
| SEAT BELTS                        | 2.G 04 |
| SEAT BELTS AND FITTINGS           | 2.G 04 |
| SEATS                             | 2.F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS | 2.F 18 |

## SAMAND

**F17**  
**Fiche 2**

**FACIA, TRIM, SEATS AND FIXINGS**  
**SEATS**  
**FRONT SEAT FRAME AND FITTINGS RIGHT HAND**



ZP0023

| Illus | Part Number | Description                       | Quantity |
|-------|-------------|-----------------------------------|----------|
| 2     | 079 02 003  | Slide.-passenger seat             | 1        |
| 3     | 040 29 008  | Screw.-M8 x 125 - 40              | 6        |
| 4     | 186 24 029  | Washer.-seat retaining            | 6        |
| 5     | 239 04 003  | Slide.-front seat-inner           | 1        |
| 6     | 239 04 001  | Slide.-front seat-outer           | 1        |
| 8     | 213 01 008  | Seat Frame.-front seat-RH         | 1        |
| 9     | 040 11 011  | Screw.-lumber support             | 1        |
| 10    | 121 13 004  | Spring.-lumber support            | 1        |
| 11    | 051 09 002  | Seat Adjuster.-lumber support     | 1        |
| 12    | 121 13 005  | Spring.-lumber support            | 1        |
| 13    | 025 21 003  | Clip.-lumber support              | 1        |
| 14    | 063 09 004  | Handle.-Black                     | 1        |
| 15    | 058 01 070  | Fixing Clip.                      | 1        |
| 16    | 058 15 014  | Fixing Clip.                      | 26       |
| 17    | 122 03 003  | Seating.                          | 1        |
| 18    | 122 04 003  | Seat Padding.-front seat backrest | 1        |
| 19    | 205 03 002  | Grommet.-headrest                 | 2        |
| 20    | 030 22 046  | Bush.-front seat-outer            | 1        |

## MASTER INDEX


ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX

|    |                                         |        |
|----|-----------------------------------------|--------|
| 1C | CARPET AND FLOOR FITTINGS .....         | 2 G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT .....  | 2 G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and .....   | 2 G 05 |
| 1F | INSULATION .....                        | 2 G 07 |
| 1G | FACIA DETAILS .....                     | 2 F 02 |
| 1H | FACIA COVERS AND FINISHERS .....        | 2 F 03 |
| 1I | FACIA-COMPLETE ASSEMBLY .....           | 2 F 02 |
| 1J | FASCIA PANEL TRIM .....                 | 2 F 05 |
| 1K | GLOVEBOX AND FIXINGS .....              | 2 F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY .....           | 2 F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS .....   | 2 F 07 |
| 2H | INTERIOR LINERS .....                   | 2 F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH ..... | 2 F 08 |
|    | FRONT DOOR LINERS AND FITTINGS RH ..... | 2 F 09 |
|    | HEADLINING .....                        | 2 F 14 |
|    | INTERIOR LINERS .....                   | 2 F 12 |
|    | PARCEL SHELF AND REAR END TRIM .....    | 2 F 15 |
|    | REAR DOOR LINERS AND FITTINGS LH .....  | 2 F 10 |
|    | REAR DOOR LINERS AND FITTINGS RH .....  | 2 F 11 |
|    | SEAT BELTS .....                        | 2 G 04 |
|    | SEAT BELTS AND FITTINGS .....           | 2 G 04 |
|    | SEATS .....                             | 2 F 16 |
|    | FRONT SEAT HEADRESTS AND FITTINGS ..... | 2 F 18 |



|               |                             |                                                                                                   |
|---------------|-----------------------------|---------------------------------------------------------------------------------------------------|
| <b>SAMAND</b> | <b>F18</b><br><b>FICHE2</b> | <b>FACIA, TRIM, SEATS AND FIXINGS</b><br><b>SEATS</b><br><b>FRONT SEAT HEADRESTS AND FITTINGS</b> |
|---------------|-----------------------------|---------------------------------------------------------------------------------------------------|



ZP0024

| Illus | Part Number | Description                    | Quantity | Change<br>Point | Remarks |
|-------|-------------|--------------------------------|----------|-----------------|---------|
| 1     | 204 01 004  | Headrest.-front-Grey           | 1        |                 |         |
| 2     | 126 12 034  | Trim.-front seat-outer LH-Grey | 1        |                 |         |
| 3     | 126 12 030  | Trim.-front seat-inner LH-Grey | 1        |                 |         |
| 2     | 126 12 028  | Trim.-front seat-outer RH-Grey | 1        |                 |         |
| 3     | 126 12 032  | Trim.-front seat-inner RH-Grey | 1        |                 |         |
| 4     | 110 03 005  | Assembly FRT Seat LH Complete  | 1        |                 |         |
| 4     | 110 03 004  | Assembly FRT Seat RH Complete  | 1        |                 |         |
| 5     | 063 09 004  | Handle.-Black                  | 1        |                 |         |

## MASTER INDEX

## GROUP INDEX

|                                            |     |
|--------------------------------------------|-----|
| ENGINE .....                               | 1 C |
| FLYWHEEL AND CLUTCH .....                  | 1 D |
| GEARBOX .....                              | 1 E |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS..  | 1 F |
| STEERING.....                              | 1 G |
| BRAKES AND BRAKE CONTROLS.....             | 1 H |
| FUEL, EXHAUST AND EMISSION SYSTEM .....    | 1 I |
| COOLING, HEATING AND AIR CONDITIONING..... | 1 J |
| ELECTRICAL AND INSTRUMENTS .....           | 1 K |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-..   | 2 C |
| FACIA, TRIM, SEATS AND FIXINGS.....        | 2 F |
| ACCESSORIES AND PAINT .....                | 2 H |
| Numeric Index.....                         | 2 I |

|                                        |         |
|----------------------------------------|---------|
| CARPET AND FLOOR FITTINGS.....         | 2. G 05 |
| CARPET AND FLOOR FITTINGS - BOOT ..... | 2. G 06 |
| CARPET/FLOOR FITTINGS-FRONT and.....   | 2. G 05 |
| INSULATION .....                       | 2. G 07 |
| FACIA DETAILS.....                     | 2. F 02 |
| FACIA COVERS AND FINISHERS.....        | 2. F 03 |
| FACIA-COMPLETE ASSEMBLY.....           | 2. F 02 |
| FASCIA PANEL TRIM.....                 | 2. F 05 |
| GLOVEBOX AND FIXINGS .....             | 2. F 04 |
| TUNNEL CONSOLE ASSEMBLY .....          | 2. F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS .....  | 2. F 07 |
| INTERIOR LINERS .....                  | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS LH .... | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS RH ...  | 2. F 09 |
| HEADLINING.....                        | 2. F 14 |
| INTERIOR LINERS .....                  | 2. F 12 |
| PARCEL SHELF AND REAR END TRIM.....    | 2. F 15 |
| REAR DOOR LINERS AND FITTINGS LH ..... | 2. F 10 |
| REAR DOOR LINERS AND FITTINGS RH.....  | 2. F 11 |
| SEAT BELTS.....                        | 2. G 04 |
| SEAT BELTS AND FITTINGS.....           | 2. G 04 |
| SEATS .....                            | 2. F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS ..   | 2. F 18 |

# SAMAND

G02

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

SEATS

FRONT SEAT COVERS

Illus Part Number

1 078 04 034  
2 078 04 033


Description

Cover.-front seat backrest-Grey ..... 1  
Cover.-front seat cushion-Grey ..... 1

Quantity

Change Point

Remarks



ZP0026

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

CARPET AND FLOOR FITTINGS ..... 2. G 05  
CARPET AND FLOOR FITTINGS - BOOT ..... 2. G 06  
CARPET/FLOOR FITTINGS-FRONT and ..... 2. G 05  
INSULATION ..... 2. G 07  
FACIA DETAILS ..... 2. F 02  
FACIA COVERS AND FINISHERS ..... 2. F 03  
FACIA-COMplete ASSEMBLY ..... 2. F 02  
FASCIA PANEL TRIM ..... 2. F 05  
GLOVEBOX AND FIXINGS ..... 2. F 04  
TUNNEL CONSOLE ASSEMBLY ..... 2. F 06  
TUNNEL CONSOLE DUCTS & FITTINGS ..... 2. F 07  
INTERIOR LINERS ..... 2. F 08  
FRONT DOOR LINERS AND FITTINGS LH ..... 2. F 08  
FRONT DOOR LINERS AND FITTINGS RH ..... 2. F 09  
HEADLINING ..... 2. F 14  
INTERIOR LINERS ..... 2. F 12  
PARCEL SHELF AND REAR END TRIM ..... 2. F 15  
REAR DOOR LINERS AND FITTINGS LH ..... 2. F 10  
REAR DOOR LINERS AND FITTINGS RH ..... 2. F 11  
SEAT BELTS ..... 2. G 04  
SEAT BELTS AND FITTINGS ..... 2. G 04  
SEATS ..... 2. F 16  
FRONT SEAT HEADRESTS AND FITTINGS ..... 2. F 18

# SAMAND



G03

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

SEATS

REAR SEAT FRAME AND COVERS



Illus Part Number

1 110 07 001  
2 122 02 007  
3 078 04 029  
4 110 09 001  
5 122 01 007  
6 078 04 031  
7 275 01 002  
8 164 08 001  
9 202 01 023  
10 058 20 022  
11 040 01 290  
12 174 04 037  
13 170 18 001  
14 040 02 021

Description

Seating.-assembly-rear squab-Grey  
Seat Padding.-rear squab  
Cover.-rear squab-Grey  
Seating.-assembly-rear seat-Grey  
Seat Padding.-rear seat cushion  
Cover.-rear seat cushion-Grey  
Centre Armrest.-assembly-rear seat-Grey  
Hinge.-armrest-Grey  
Rivet.  
Fixing Clip.  
Screw.-with washer-M6 x 100-20  
Nut.-flange-5 x 80  
Plug/Cover.-armrest-Grey  
Screw.-M6 x 100-16

Quantity

Change  
Point

Remarks

1  
1  
1  
1  
1  
1  
1  
1  
2  
1  
1  
1  
1  
1

ZP0025

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

CARPET AND FLOOR FITTINGS .....2. G 05  
CARPET AND FLOOR FITTINGS - BOOT .....2. G 06  
CARPET/FLOOR FITTINGS-FRONT and .....2. G 05  
INSULATION.....2. G 07  
FACIA DETAILS .....2. F 02  
FACIA COVERS AND FINISHERS .....2. F 03  
FACIA-COMplete ASSEMBLY .....2. F 02  
FASCIA PANEL TRIM .....2. F 05  
GLOVEBOX AND FIXINGS .....2. F 04  
TUNNEL CONSOLE ASSEMBLY .....2. F 06  
TUNNEL CONSOLE DUCTS & FITTINGS .....2. F 07  
INTERIOR LINERS .....2. F 08  
FRONT DOOR LINERS AND FITTINGS LH .....2. F 08  
FRONT DOOR LINERS AND FITTINGS RH .....2. F 09  
HEADLINING .....2. F 14  
INTERIOR LINERS .....2. F 12  
PARCEL SHELF AND REAR END TRIM .....2. F 15  
REAR DOOR LINERS AND FITTINGS LH .....2. F 10  
REAR DOOR LINERS AND FITTINGS RH .....2. F 11  
SEAT BELTS .....2. G 04  
SEAT BELTS AND FITTINGS .....2. G 04  
SEATS .....2. F 16  
FRONT SEAT HEADRESTS AND FITTINGS .....2. F 18

# SAMAND

G04

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS

SEAT BELTS

SEAT BELTS AND FITTINGS


Illus Part Number

Description

Quantity

Change  
Point

Remarks



|    |            |                              |   |  |  |
|----|------------|------------------------------|---|--|--|
| 1  | 149 01 013 | SEAT BELT.-FRONT             | 1 |  |  |
| 2  | 186 01 179 | Washer.-crinkle-13 x 25      | 2 |  |  |
| 3  | 040 22 051 | Screw.-7/16x20-18            | 4 |  |  |
| 4  | 136 07 002 | Lock.-seat belt              | 2 |  |  |
| 5  | 225 08 002 | Button.-seat belt            | 2 |  |  |
| 6  | 040 01 280 | Screw.-with washer-7/16 - 20 | 2 |  |  |
| 7  | 040 22 052 | Screw.-7/16 - 20             | 2 |  |  |
| 8  | 149 01 014 | Seat Belt.                   | 1 |  |  |
| 9  | 128 14 002 | Panel.                       | 2 |  |  |
| 19 | 186 01 178 | Washer.                      | 2 |  |  |
| 11 | 040 22 050 | Screw.-with washer-M8 x 20   | 2 |  |  |
| 12 | 225 08 003 | Button.                      | 2 |  |  |
| 13 | 149 02 007 | SEAT BELT.-REAR              | 1 |  |  |
| 17 | 136 07 003 | Lock.-seat belt-rear LH.     | 1 |  |  |
| 18 | 149 02 008 | Seat Belt.                   | 2 |  |  |
| 20 | 186 01 173 | Washer.-flat                 | 2 |  |  |
| 21 | 040 01 272 | Screw.-M6 x 100-23           | 2 |  |  |
| 22 | 136 07 004 | Lock.-seat belt-rear RH.     | 1 |  |  |
| 23 | 030 22 047 | Spacer Tube                  | 2 |  |  |

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

## GROUP INDEX



|    |                                        |         |
|----|----------------------------------------|---------|
| 1C | CARPET AND FLOOR FITTINGS.....         | 2. G 05 |
| 1D | CARPET AND FLOOR FITTINGS - BOOT.....  | 2. G 06 |
| 1E | CARPET/FLOOR FITTINGS-FRONT and.....   | 2. G 05 |
| 1F | INSULATION.....                        | 2. G 07 |
| 1G | FACIA DETAILS.....                     | 2. F 02 |
| 1H | FACIA COVERS AND FINISHERS.....        | 2. F 03 |
| 1I | FACIA-COMplete ASSEMBLY.....           | 2. F 02 |
| 1J | FACIA PANEL TRIM.....                  | 2. F 05 |
| 1K | GLOVEBOX AND FIXINGS.....              | 2. F 04 |
| 2C | TUNNEL CONSOLE ASSEMBLY.....           | 2. F 06 |
| 2F | TUNNEL CONSOLE DUCTS & FITTINGS.....   | 2. F 07 |
| 2H | INTERIOR LINERS.....                   | 2. F 08 |
| 2I | FRONT DOOR LINERS AND FITTINGS LH..... | 2. F 08 |
|    | FRONT DOOR LINERS AND FITTINGS RH..... | 2. F 09 |
|    | HEADLINING.....                        | 2. F 14 |
|    | INTERIOR LINERS.....                   | 2. F 12 |
|    | PARCEL SHELF AND REAR END TRIM.....    | 2. F 15 |
|    | REAR DOOR LINERS AND FITTINGS LH.....  | 2. F 10 |
|    | REAR DOOR LINERS AND FITTINGS RH.....  | 2. F 11 |
|    | SEAT BELTS.....                        | 2. G 04 |
|    | SEAT BELTS AND FITTINGS.....           | 2. G 04 |
|    | SEATS.....                             | 2. F 16 |
|    | FRONT SEAT HEADRESTS AND FITTINGS..... | 2. F 18 |

# SAMAND

G05

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS CARPET AND FLOOR FITTINGS CARPET/FLOOR FITTINGS-FRONT and REAR



Illus Part Number

|   |            |
|---|------------|
| 1 | 145 04 012 |
| 2 | 114 03 048 |
| 3 | 114 03 047 |
| 4 | 114 03 050 |
| 5 | 058 09 009 |
| 6 | 114 04 011 |
| 7 | 114 04 012 |

Description

|                                    |   |
|------------------------------------|---|
| Floor Carpet.-front floor. ....    | 1 |
| Shield.-front floor.-front .....   | 1 |
| Shield.-front floor.-rear .....    | 1 |
| Shield.-under rear cushion.....    | 1 |
| Fixing Clip. ....                  | 3 |
| Shield.-footwell carpet-front..... | 2 |
| Shield.-footwell carpet-rear.....  | 1 |

Quantity

Change Point

Remarks

ZR0003

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                         |        |
|-----------------------------------------|--------|
| CARPET AND FLOOR FITTINGS .....         | 2.G 05 |
| CARPET AND FLOOR FITTINGS - BOOT .....  | 2.G 06 |
| CARPET/FLOOR FITTINGS-FRONT and .....   | 2.G 05 |
| INSULATION.....                         | 2.G 07 |
| FACIA DETAILS .....                     | 2.F 02 |
| FACIA COVERS AND FINISHERS .....        | 2.F 03 |
| FACIA-COMplete ASSEMBLY .....           | 2.F 02 |
| FASCIA PANEL TRIM .....                 | 2.F 05 |
| GLOVEBOX AND FIXINGS .....              | 2.F 04 |
| TUNNEL CONSOLE ASSEMBLY .....           | 2.F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS.....    | 2.F 07 |
| INTERIOR LINERS.....                    | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS LH ..... | 2.F 08 |
| FRONT DOOR LINERS AND FITTINGS RH.....  | 2.F 09 |
| HEADLINING.....                         | 2.F 14 |
| INTERIOR LINERS.....                    | 2.F 12 |
| PARCEL SHELF AND REAR END TRIM .....    | 2.F 15 |
| REAR DOOR LINERS AND FITTINGS LH.....   | 2.F 10 |
| REAR DOOR LINERS AND FITTINGS RH .....  | 2.F 11 |
| SEAT BELTS .....                        | 2.G 04 |
| SEAT BELTS AND FITTINGS .....           | 2.G 04 |
| SEATS.....                              | 2.F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS.....  | 2.F 18 |




# SAMAND

G06

Fiche 2

## FACIA, TRIM, SEATS AND FIXINGS CARPET AND FLOOR FITTINGS CARPET AND FLOOR FITTINGS - BOOT



Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 145 | 06 | 001 |
| 2  | 126 | 12 | 027 |
| 3  | 145 | 05 | 007 |
| 3  | 145 | 05 | 008 |
| 4  | 058 | 14 | 002 |
| 5  | 145 | 03 | 006 |
| 8  | 058 | 13 | 005 |
| 9  | 058 | 09 | 009 |
| 10 | 083 | 17 | 001 |
| 11 | 126 | 06 | 024 |
| 12 | 058 | 15 | 016 |
| 13 | 114 | 03 | 033 |
| 14 | 025 | 01 | 116 |


Description

|                                          |   |
|------------------------------------------|---|
| Floor Carpet.-trunk backrest.....        | 1 |
| Trim.-rear partition .....               | 1 |
| Floor Carpet.-rear quarter inner-LH..... | 1 |
| Floor Carpet.-rear quarter inner-RH..... | 1 |
| Fixing Clip.-wheelhouse carpet.....      | 6 |
| Floor Carpet.-trunk floor.....           | 1 |
| Fixing Clip.-trim socket.....            | 3 |
| Fixing Clip.-boot carpet to floor.....   | 3 |
| Striker.-boot floor carpet .....         | 1 |
| Trim.-rear end .....                     | 1 |
| Fixing Clip.-trim part rear end .....    | 4 |
| Shield.-under rear backrest-LH.....      | 2 |
| Clip.-backrest to body .....             | 6 |

Quantity

Change Point

Remarks



ZF 12

### MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

### GROUP INDEX

|                                         |     |    |
|-----------------------------------------|-----|----|
| CARPET AND FLOOR FITTINGS.....          | 2.G | 05 |
| CARPET AND FLOOR FITTINGS - BOOT .....  | 2.G | 06 |
| CARPET/FLOOR FITTINGS-FRONT and .....   | 2.G | 05 |
| INSULATION.....                         | 2.G | 07 |
| FACIA DETAILS .....                     | 2.F | 02 |
| FACIA COVERS AND FINISHERS .....        | 2.F | 03 |
| FACIA-COMPLETE ASSEMBLY .....           | 2.F | 02 |
| FACIA PANEL TRIM .....                  | 2.F | 05 |
| GLOVEBOX AND FIXINGS .....              | 2.F | 04 |
| TUNNEL CONSOLE ASSEMBLY .....           | 2.F | 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS .....   | 2.F | 07 |
| INTERIOR LINERS.....                    | 2.F | 08 |
| FRONT DOOR LINERS AND FITTINGS LH ..... | 2.F | 08 |
| FRONT DOOR LINERS AND FITTINGS RH.....  | 2.F | 09 |
| HEADLINING .....                        | 2.F | 14 |
| INTERIOR LINERS.....                    | 2.F | 12 |
| PARCEL SHELF AND REAR END TRIM .....    | 2.F | 15 |
| REAR DOOR LINERS AND FITTINGS LH.....   | 2.F | 10 |
| REAR DOOR LINERS AND FITTINGS RH .....  | 2.F | 11 |
| SEAT BELTS.....                         | 2.G | 04 |
| SEAT BELTS AND FITTINGS .....           | 2.G | 04 |
| SEATS.....                              | 2.F | 16 |
| FRONT SEAT HEADRESTS AND FITTINGS.....  | 2.F | 18 |

# SAMAND

G07

Fiche 2

FACIA, TRIM, SEATS AND FIXINGS  
CARPET AND FLOOR FITTINGS  
INSULATION

Illus Part Number

|   |     |    |     |
|---|-----|----|-----|
| 1 | 114 | 03 | 044 |
| 2 | 114 | 03 | 046 |
| 3 | 114 | 03 | 045 |
| 4 | 114 | 04 | 010 |
| 5 | 205 | 02 | 036 |
| 7 | 061 | 13 | 008 |


Description

Quantity

Change Point

Remarks

|                                      |   |  |  |
|--------------------------------------|---|--|--|
| Shield.-scuttle manifold centre..... | 1 |  |  |
| Shield.-scuttle manifold RH .....    | 1 |  |  |
| Shield.-scuttle manifold LH .....    | 1 |  |  |
| Shield.-front bulkhead.....          | 1 |  |  |
| Grommet.-front bulkhead.....         | 1 |  |  |
| Protectors.-dash. ....               | 3 |  |  |



ZP0018

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

|                                         |         |
|-----------------------------------------|---------|
| CARPET AND FLOOR FITTINGS .....         | 2. G 05 |
| CARPET AND FLOOR FITTINGS - BOOT .....  | 2. G 06 |
| CARPET/FLOOR FITTINGS-FRONT and .....   | 2. G 05 |
| INSULATION.....                         | 2. G 07 |
| FACIA DETAILS .....                     | 2. F 02 |
| FACIA COVERS AND FINISHERS .....        | 2. F 03 |
| FACIA-COMplete ASSEMBLY .....           | 2. F 02 |
| FASCIA PANEL TRIM .....                 | 2. F 05 |
| GLOVEBOX AND FIXINGS .....              | 2. F 04 |
| TUNNEL CONSOLE ASSEMBLY .....           | 2. F 06 |
| TUNNEL CONSOLE DUCTS & FITTINGS .....   | 2. F 07 |
| INTERIOR LINERS .....                   | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS LH ..... | 2. F 08 |
| FRONT DOOR LINERS AND FITTINGS RH ..... | 2. F 09 |
| HEADLINING .....                        | 2. F 14 |
| INTERIOR LINERS .....                   | 2. F 12 |
| PARCEL SHELF AND REAR END TRIM .....    | 2. F 15 |
| REAR DOOR LINERS AND FITTINGS LH .....  | 2. F 10 |
| REAR DOOR LINERS AND FITTINGS RH .....  | 2. F 11 |
| SEAT BELTS .....                        | 2. G 04 |
| SEAT BELTS AND FITTINGS .....           | 2. G 04 |
| SEATS .....                             | 2. F 16 |
| FRONT SEAT HEADRESTS AND FITTINGS ..... | 2. F 18 |

| SAMAND                                         |  |                    |                       |  |  |
|------------------------------------------------|--|--------------------|-----------------------|--|--|
|                                                |  | H01<br>Fiche 2     | ACCESSORIES AND PAINT |  |  |
| MASTER INDEX                                   |  | GROUP INDEX        |                       |  |  |
| ENGINE ..... 1 C                               |  |                    |                       |  |  |
| FLYWHEEL AND CLUTCH ..... 1 D                  |  | TOOLS..... 2. H 02 |                       |  |  |
| GEARBOX ..... 1 E                              |  | TOOLS..... 2. H 02 |                       |  |  |
| AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS.. 1 F  |  |                    |                       |  |  |
| STEERING..... 1 G                              |  |                    |                       |  |  |
| BRAKES AND BRAKE CONTROLS..... 1 H             |  |                    |                       |  |  |
| FUEL, EXHAUST AND EMISSION SYSTEM ..... 1 I    |  |                    |                       |  |  |
| COOLING, HEATING AND AIR CONDITIONING..... 1 J |  |                    |                       |  |  |
| ELECTRICAL AND INSTRUMENTS ..... 1 K           |  |                    |                       |  |  |
| ENGINE MOUNTINGS, BODY SHELL AND WASH-.. 2 C   |  |                    |                       |  |  |
| FACIA, TRIM, SEATS AND FIXINGS..... 2 F        |  |                    |                       |  |  |
| ACCESSORIES AND PAINT ..... 2 H                |  |                    |                       |  |  |
| Numeric Index ..... 2 I                        |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
|                                                |  |                    |                       |  |  |
| <a href="#">www.me-en.com</a>                  |  |                    |                       |  |  |

# SAMAND

H02

Fiche 2

## ACCESSORIES AND PAINT

### TOOLS TOOLS

Illus Part Number

|    |     |    |     |
|----|-----|----|-----|
| 1  | 208 | 09 | 002 |
| 2  | 277 | 01 | 001 |
| 3  | 236 | 01 | 004 |
| 4  | 236 | 01 | 005 |
| 5  | 181 | 54 | 008 |
| 6  | 235 | 01 | 003 |
| 7  | 259 | 05 | 001 |
| 8  | 278 | 01 | 001 |
| 9  | 025 | 23 | 001 |
| 10 | 181 | 54 | 009 |


Description

Quantity

Change Point

Remarks

|                                          |   |  |  |
|------------------------------------------|---|--|--|
| Box.-first aid.....                      | 1 |  |  |
| Hazard Triangle.....                     | 1 |  |  |
| Lifting Jack.-set of.....                | 1 |  |  |
| Lifting Jack.-lifting.....               | 1 |  |  |
| Bracket.-lower.....                      | 1 |  |  |
| Jack Handle.....                         | 1 |  |  |
| Wheel Trim Tool.-wheel trim removal..... | 1 |  |  |
| Centralising Tool.-centralising.....     | 1 |  |  |
| Clip.-spare wheel.....                   | 1 |  |  |
| Bracket.-upper.....                      | 1 |  |  |



ZT0001

## MASTER INDEX

ENGINE  
FLYWHEEL AND CLUTCH  
GEARBOX  
AXLES, SUSPENSION, DRIVE SHAFTS, WHEELS  
STEERING  
BRAKES AND BRAKE CONTROLS  
FUEL, EXHAUST AND EMISSION SYSTEM  
COOLING, HEATING AND AIR CONDITIONING  
ELECTRICAL AND INSTRUMENTS  
ENGINE MOUNTINGS, BODY SHELL AND WASH-  
FACIA, TRIM, SEATS AND FIXINGS  
ACCESSORIES AND PAINT  
Numeric Index

1C  
1D  
1E  
1F  
1G  
1H  
1I  
1J  
1K  
2C  
2F  
2H  
2I

## GROUP INDEX

TOOLS.....2.H 02  
TOOLS.....2.H 02

| SAMAND     |             |            |             |            |             |            |             |            |             | I01        |             | Numeric Index "00101 020 " TO "04014 078 " |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |       |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|--------------------------------------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|-------|
|            |             |            |             |            |             |            |             |            |             | Fiche 2    |             |                                            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |            |             |       |
| 001 01 020 | .....2.D 14 | 017 13 005 | .....1.F 06 | 025 01 116 | .....2.G 06 | 025 07 015 | .....1.L 18 | 030 09 004 | .....1.F 08 | 038 08 001 | .....2.E 04 | 040 01 273                                 | .....1.C 07 | 040 03 023 | .....1.J 02 | 001 01 021 | .....2.D 14 | 017 15 005 | .....1.G 05 | 025 01 117 | .....2.F 14 | 025 07 015 | .....1.M 02 | 030 09 005 | .....1.F 08 | 038 13 005 | .....1.G 05 | 040 01 274 | .....1.I 03 | 040 03 026 | .....2.C 02 | 001 02 005 | .....2.D 14 | 017 15 005 | .....1.G 07 | 025 02 008 | .....1.H 07 | 025 07 017 | .....1.L 10 | 030 10 007 | .....1.F 10 | 038 13 005 | .....1.G 07 | 040 01 274 | .....1.K 06 | 040 03 036 | .....1.I 03 | 002 02 009 | .....1.H 05 | 017 22 001 | .....1.F 07 | 025 02 008 | .....1.I 06 | 025 07 018 | .....1.I 07 | 030 10 008 | .....1.F 10 | 038 13 006 | .....1.I 12 | 040 01 275 | .....1.J 05 | 040 03 038 | .....1.C 06 | 003 01 028 | .....2.E 03 | 017 26 001 | .....1.H 06 | 025 02 009 | .....1.H 08 | 025 07 018 | .....1.J 10 | 030 14 004 | .....1.F 03 | 038 17 001 | .....1.J 09 | 040 01 276 | .....1.I 09 | 040 03 058 | .....1.I 02 | 003 01 029 | .....2.E 03 | 017 27 001 | .....1.I 04 | 025 02 017 | .....1.I 07 | 025 07 020 | .....1.L 15 | 030 14 005 | .....1.F 03 | 038 18 009 | .....1.C 08 | 040 01 277 | .....1.C 03 | 040 05 001 | .....1.H 02 | 003 02 003 | .....2.E 03 | 017 32 001 | .....1.I 03 | 025 02 022 | .....1.J 08 | 025 07 021 | .....1.L 17 | 030 14 008 | .....1.F 09 | 039 02 005 | .....1.C 04 | 040 01 277 | .....1.I 09 | 040 05 001 | .....1.H 03 | 003 03 007 | .....2.E 03 | 018 02 004 | .....1.L 07 | 025 02 029 | .....1.J 08 | 025 08 006 | .....1.M 02 | 030 17 002 | .....1.H 04 | 040 01 009 | .....1.J 07 | 040 01 277 | .....1.I 10 | 040 05 001 | .....2.D 07 | 003 05 001 | .....1.C 06 | 019 01 008 | .....2.F 15 | 025 02 029 | .....1.M 02 | 025 08 007 | .....1.C 14 | 030 18 001 | .....1.H 04 | 040 01 013 | .....1.I 11 | 040 01 278 | .....1.G 06 | 040 05 002 | .....1.I 12 | 004 01 012 | .....1.K 07 | 020 01 013 | .....2.D 12 | 025 02 032 | .....1.H 04 | 025 08 008 | .....1.I 07 | 030 18 005 | .....1.E 09 | 040 01 019 | .....1.C 11 | 040 01 279 | .....2.D 12 | 040 05 002 | .....1.J 12 | 004 02 015 | .....1.K 05 | 020 01 014 | .....2.D 12 | 025 02 044 | .....1.H 09 | 025 08 009 | .....1.I 07 | 030 18 008 | .....1.D 02 | 040 01 028 | .....1.E 03 | 040 01 280 | .....2.G 04 | 040 05 003 | .....2.D 15 | 005 01 002 | .....1.K 06 | 020 01 018 | .....2.D 12 | 025 02 075 | .....1.G 06 | 025 09 001 | .....1.D 04 | 030 18 009 | .....1.D 02 | 040 01 030 | .....1.C 07 | 040 01 281 | .....2.C 12 | 040 05 016 | .....1.K 15 | 006 01 002 | .....1.C 08 | 020 01 019 | .....2.D 12 | 025 02 076 | .....1.I 02 | 025 10 008 | .....1.H 07 | 030 19 001 | .....1.F 07 | 040 01 030 | .....1.H 08 | 040 01 281 | .....2.C 13 | 040 05 023 | .....1.D 04 | 007 02 002 | .....1.L 08 | 020 04 006 | .....1.F 03 | 025 02 077 | .....1.I 02 | 025 10 014 | .....1.G 08 | 030 22 001 | .....2.F 08 | 040 01 030 | .....1.F 08 | 040 01 281 | .....2.C 16 | 040 05 024 | .....2.D 14 | 007 02 004 | .....2.C 18 | 020 04 011 | .....1.F 03 | 025 02 078 | .....1.I 08 | 025 10 015 | .....1.K 03 | 030 22 001 | .....2.F 09 | 040 01 036 | .....1.E 08 | 040 01 281 | .....2.C 17 | 040 05 032 | .....2.D 05 | 007 02 004 | .....2.D 04 | 020 04 024 | .....1.F 03 | 025 02 079 | .....1.C 13 | 025 11 002 | .....1.J 08 | 030 22 011 | .....1.I 09 | 040 01 038 | .....1.H 02 | 040 01 281 | .....2.D 07 | 040 05 034 | .....1.K 02 | 007 02 005 | .....2.D 13 | 020 04 025 | .....1.F 03 | 025 02 080 | .....1.C 13 | 025 11 002 | .....1.L 11 | 030 22 013 | .....1.E 09 | 040 01 039 | .....2.D 08 | 040 01 282 | .....2.C 12 | 040 05 036 | .....1.M 05 | 007 02 006 | .....1.L 18 | 020 06 005 | .....1.F 09 | 025 02 081 | .....1.I 05 | 025 11 002 | .....1.L 15 | 030 22 014 | .....1.E 09 | 040 01 048 | .....1.L 14 | 040 01 283 | .....1.L 08 | 040 05 037 | .....2.F 06 | 007 02 007 | .....2.F 08 | 020 06 007 | .....1.F 09 | 025 02 082 | .....1.K 02 | 025 11 002 | .....1.L 12 | 030 22 016 | .....1.F 04 | 040 01 052 | .....1.C 10 | 040 01 287 | .....1.G 03 | 040 05 038 | .....1.K 11 | 007 02 007 | .....2.F 09 | 021 01 006 | .....1.I 06 | 025 02 083 | .....1.H 09 | 025 11 002 | .....1.L 04 | 030 22 028 | .....1.I 09 | 040 01 064 | .....1.C 04 | 040 01 288 | .....1.G 03 | 040 05 040 | .....1.J 12 | 007 03 002 | .....2.D 07 | 022 01 013 | .....1.K 05 | 025 02 084 | .....1.H 09 | 025 13 003 | .....2.D 02 | 030 22 032 | .....1.C 06 | 040 01 079 | .....1.E 03 | 040 01 289 | .....1.J 04 | 040 06 005 | .....1.J 11 | 007 04 001 | .....2.D 14 | 023 01 009 | .....1.J 15 | 025 02 085 | .....1.I 08 | 025 13 004 | .....2.D 02 | 030 22 040 | .....1.F 04 | 040 01 079 | .....1.E 06 | 040 01 290 | .....2.G 03 | 040 06 009 | .....1.H 02 | 008 01 002 | .....2.F 14 | 024 03 004 | .....2.C 04 | 025 02 086 | .....1.I 08 | 025 14 002 | .....1.J 10 | 030 22 041 | .....2.C 11 | 040 01 079 | .....1.E 07 | 040 01 291 | .....2.C 18 | 040 06 011 | .....1.H 03 | 008 02 003 | .....2.F 14 | 024 03 005 | .....2.C 04 | 025 02 087 | .....1.I 08 | 025 16 006 | .....1.L 07 | 030 22 043 | .....1.E 09 | 040 01 082 | .....2.D 12 | 040 01 291 | .....2.D 04 | 040 07 003 | .....1.C 05 | 011 02 003 | .....1.K 15 | 025 01 010 | .....1.H 04 | 025 02 088 | .....1.I 08 | 025 18 001 | .....1.I 04 | 030 22 044 | .....2.D 02 | 040 01 085 | .....2.C 11 | 040 02 017 | .....1.F 04 | 040 08 001 | .....1.F 11 | 011 03 001 | .....1.K 15 | 025 01 016 | .....1.H 09 | 025 02 089 | .....1.J 16 | 025 21 001 | .....1.J 12 | 030 22 046 | .....2.F 16 | 040 01 088 | .....2.C 02 | 040 02 017 | .....1.G 03 | 040 09 004 | .....1.C 03 | 011 04 004 | .....1.K 15 | 025 01 031 | .....1.H 09 | 025 02 091 | .....1.H 05 | 025 21 003 | .....2.F 16 | 030 22 046 | .....2.F 17 | 040 01 094 | .....1.H 04 | 040 02 020 | .....1.K 06 | 040 09 005 | .....1.C 12 | 011 05 003 | .....1.K 15 | 025 01 036 | .....1.L 11 | 025 02 092 | .....1.I 08 | 025 21 003 | .....2.F 17 | 030 24 007 | .....1.E 09 | 040 01 095 | .....1.F 03 | 040 02 021 | .....2.G 03 | 040 09 007 | .....1.C 11 | 011 06 018 | .....1.K 15 | 025 01 036 | .....1.L 12 | 025 03 018 | .....1.H 05 | 025 23 001 | .....2.H 02 | 030 28 001 | .....2.C 02 | 040 01 100 | .....1.G 06 | 040 02 037 | .....1.F 08 | 040 09 008 | .....1.J 11 | 012 01 002 | .....1.M 06 | 025 01 036 | .....1.L 13 | 025 03 018 | .....1.C 13 | 025 24 001 | .....2.C 02 | 030 28 002 | .....2.C 02 | 040 01 107 | .....1.C 04 | 040 02 038 | .....1.F 08 | 040 09 010 | .....1.C 03 | 013 01 005 | .....1.I 04 | 025 01 036 | .....1.M 02 | 025 03 018 | .....1.I 07 | 025 24 002 | .....1.F 04 | 030 29 001 | .....1.K 06 | 040 01 113 | .....1.C 10 | 040 02 039 | .....1.I 07 | 040 09 012 | .....1.C 12 | 015 01 009 | .....1.H 07 | 025 01 041 | .....1.H 09 | 025 03 018 | .....1.I 08 | 026 01 001 | .....1.C 04 | 030 29 003 | .....1.J 05 | 040 01 113 | .....2.C 18 | 040 02 041 | .....1.E 03 | 040 09 013 | .....1.J 08 | 015 02 008 | .....1.E 09 | 025 01 056 | .....2.D 04 | 025 03 018 | .....1.J 10 | 026 02 002 | .....1.C 04 | 030 29 004 | .....1.K 04 | 040 01 113 | .....2.D 04 | 040 02 042 | .....1.I 04 | 040 09 016 | .....1.C 03 | 015 03 007 | .....2.D 12 | 025 01 058 | .....1.I 11 | 025 03 018 | .....1.G 08 | 026 02 004 | .....1.C 04 | 030 31 001 | .....1.F 06 | 040 01 118 | .....1.F 06 | 040 02 042 | .....1.I 05 | 040 10 005 | .....1.C 06 | 015 04 003 | .....1.K 07 | 025 01 060 | .....1.I 08 | 025 03 019 | .....1.I 03 | 026 02 005 | .....1.C 04 | 031 02 002 | .....1.L 05 | 040 01 123 | .....1.K 04 | 040 02 050 | .....1.C 10 | 040 11 001 | .....1.C 12 | 015 06 004 | .....1.I 12 | 025 01 081 | .....1.H 05 | 025 03 019 | .....1.G 08 | 027 01 012 | .....1.D 02 | 032 01 001 | .....1.H 04 | 040 01 126 | .....1.F 08 | 040 02 055 | .....2.D 15 | 040 11 011 | .....2.F 16 | 015 07 004 | .....1.D 02 | 025 01 081 | .....1.M 02 | 025 03 020 | .....1.J 10 | 027 02 002 | .....1.F 03 | 032 02 001 | .....1.D 04 | 040 01 128 | .....1.C 04 | 040 02 056 | .....2.C 02 | 040 11 011 | .....2.F 17 | 015 08 005 | .....2.D 04 | 025 01 084 | .....1.L 15 | 025 03 021 | .....1.I 07 | 027 04 001 | .....1.K 05 | 032 03 005 | .....1.I 12 | 040 01 128 | .....1.G 05 | 040 02 058 | .....1.G 03 | 040 12 005 | .....1.J 10 | 015 11 004 | .....2.C 14 | 025 01 084 | .....1.L 18 | 025 03 029 | .....1.C 13 | 027 05 004 | .....1.F 09 | 033 02 010 | .....1.J 08 | 040 01 128 | .....1.G 07 | 040 02 059 | .....1.J 11 | 040 14 014 | .....1.J 08 | 016 01 002 | .....1.J 02 | 025 01 087 | .....2.C 14 | 025 03 029 | .....1.I 02 | 027 05 005 | .....1.F 09 | 035 01 003 | .....1.F 07 | 040 01 129 | .....1.F 03 | 040 02 062 | .....1.C 10 | 040 14 014 | .....2.C 14 | 017 01 009 | .....1.J 04 | 025 01 100 | .....1.G 08 | 025 03 029 | .....1.J 10 | 027 06 008 | .....1.E 06 | 035 01 004 | .....1.F 07 | 040 01 130 | .....1.G 06 | 040 02 080 | .....2.C 18 | 040 14 014 | .....2.D 15 | 017 01 010 | .....1.J 04 | 025 01 101 | .....1.H 09 | 025 03 031 | .....1.I 08 | 027 06 010 | .....1.E 06 | 036 01 010 | .....1.C 11 | 040 01 133 | .....1.H 03 | 040 02 080 | .....2.D 04 | 040 14 014 | .....1.K 08 | 017 02 002 | .....1.C 04 | 025 01 102 | .....1.I 08 | 025 03 032 | .....1.I 07 | 027 06 025 | .....1.E 05 | 036 02 001 | .....2.D 13 | 040 01 138 | .....1.C 04 | 040 02 085 | .....1.J 15 | 040 14 014 | .....1.K 11 | 017 02 003 | .....1.C 05 | 025 01 103 | .....1.I 08 | 025 04 010 | .....1.I 10 | 027 06 050 | .....1.E 06 | 036 03 012 | .....1.I 08 | 040 01 142 | .....1.C 12 | 040 02 086 | .....1.I 03 | 040 14 019 | .....1.J 14 | 017 02 005 | .....1.J 08 | 025 01 104 | .....1.J 16 | 025 04 011 | .....1.I 09 | 027 08 001 | .....1.F 06 | 036 05 001 | .....1.H 06 | 040 01 145 | .....1.F 04 | 040 02 087 | .....1.C 12 | 040 14 019 | .....1.J 17 | 017 05 036 | .....1.E 07 | 025 01 106 | .....2.D 07 | 025 05 004 | .....1.L 07 | 027 0 |



| SAMAND     |             |            |             |            |             |            |             |            |             | 102<br>Fiche 2 |             | Numeric Index "04014 079 " TO "09602 010 " |             |            |             |  |  |  |  |  |  |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|----------------|-------------|--------------------------------------------|-------------|------------|-------------|--|--|--|--|--|--|
| 040 14 079 | .....1.J 11 | 040 22 054 | .....1.E 03 | 042 07 029 | .....1.G 09 | 058 04 006 | .....2.C 18 | 061 02 002 | .....1.F 09 | 063 09 001     | .....2.F 16 | 077 03 001                                 | .....1.E 02 | 089 02 013 | .....2.D 16 |  |  |  |  |  |  |
| 040 14 080 | .....1.J 11 | 040 22 054 | .....1.K 04 | 042 07 030 | .....1.C 04 | 058 04 006 | .....2.D 04 | 061 02 005 | .....1.F 09 | 063 09 001     | .....2.F 17 | 078 01 001                                 | .....1.G 08 | 090 01 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 081 | .....2.D 05 | 040 22 055 | .....1.E 03 | 042 08 003 | .....1.F 07 | 058 04 009 | .....2.C 18 | 061 04 002 | .....1.C 14 | 063 09 001     | .....2.F 18 | 078 02 006                                 | .....2.F 14 | 090 02 002 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 082 | .....2.F 14 | 040 22 055 | .....1.J 07 | 042 08 004 | .....1.I 12 | 058 05 001 | .....1.I 12 | 061 04 002 | .....1.J 10 | 065 01 005     | .....1.E 05 | 078 03 011                                 | .....1.L 14 | 090 03 002 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 083 | .....2.F 06 | 040 22 056 | .....2.C 02 | 042 09 002 | .....1.D 02 | 058 05 002 | .....1.D 04 | 061 07 001 | .....1.G 07 | 065 01 006     | .....1.E 06 | 078 03 012                                 | .....1.L 14 | 090 05 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 084 | .....2.F 12 | 040 22 057 | .....2.C 02 | 042 11 001 | .....1.E 08 | 058 05 003 | .....1.E 07 | 061 07 005 | .....1.G 05 | 065 01 015     | .....1.E 05 | 078 03 013                                 | .....1.H 05 | 090 06 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 085 | .....2.F 12 | 040 22 058 | .....2.C 02 | 042 12 005 | .....1.C 11 | 058 05 011 | .....1.J 14 | 061 07 005 | .....1.G 07 | 065 01 037     | .....1.E 06 | 078 04 029                                 | .....2.G 03 | 090 07 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 087 | .....2.F 08 | 040 22 059 | .....1.L 03 | 042 15 009 | .....2.C 02 | 058 05 011 | .....2.F 07 | 061 09 001 | .....1.F 02 | 065 01 042     | .....1.E 06 | 078 04 031                                 | .....2.G 03 | 090 08 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 087 | .....2.F 10 | 040 22 060 | .....2.D 08 | 043 01 002 | .....1.J 11 | 058 05 012 | .....1.I 04 | 061 09 005 | .....1.F 02 | 065 01 045     | .....1.E 05 | 078 04 033                                 | .....2.G 02 | 090 09 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 087 | .....2.F 09 | 040 22 061 | .....1.M 06 | 043 04 003 | .....1.J 03 | 058 07 004 | .....1.H 05 | 061 09 009 | .....1.F 02 | 065 01 048     | .....1.E 05 | 078 04 034                                 | .....2.G 02 | 090 10 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 087 | .....2.F 11 | 040 22 062 | .....1.F 04 | 044 03 001 | .....1.C 05 | 058 07 004 | .....1.M 02 | 061 12 006 | .....2.F 02 | 065 01 061     | .....1.E 06 | 078 06 062                                 | .....1.L 07 | 090 11 001 | .....1.F 11 |  |  |  |  |  |  |
| 040 14 088 | .....2.F 05 | 040 22 065 | .....1.L 10 | 045 01 002 | .....1.F 03 | 058 07 010 | .....2.F 08 | 061 12 019 | .....2.E 04 | 065 01 066     | .....1.E 06 | 079 01 036                                 | .....2.D 03 | 091 01 001 | .....1.C 06 |  |  |  |  |  |  |
| 040 14 089 | .....2.F 14 | 040 22 065 | .....1.K 03 | 045 01 009 | .....1.F 09 | 058 07 010 | .....2.F 09 | 061 13 007 | .....2.F 05 | 065 01 085     | .....1.E 05 | 079 01 037                                 | .....2.D 03 | 092 01 007 | .....1.J 08 |  |  |  |  |  |  |
| 040 14 091 | .....2.D 15 | 040 22 066 | .....2.C 02 | 045 02 002 | .....1.F 09 | 058 07 015 | .....1.K 15 | 061 13 008 | .....2.G 07 | 065 03 012     | .....1.E 05 | 079 01 038                                 | .....2.D 05 | 092 01 008 | .....1.J 11 |  |  |  |  |  |  |
| 040 14 091 | .....2.D 16 | 040 23 007 | .....1.L 03 | 045 03 004 | .....1.F 02 | 058 07 016 | .....1.K 15 | 061 15 001 | .....2.E 04 | 065 04 008     | .....1.E 08 | 079 01 039                                 | .....2.D 05 | 092 01 010 | .....1.J 11 |  |  |  |  |  |  |
| 040 14 091 | .....2.D 17 | 040 24 001 | .....1.C 12 | 046 01 001 | .....1.C 11 | 058 07 017 | .....2.F 16 | 061 15 018 | .....2.E 04 | 065 04 021     | .....1.E 08 | 079 01 040                                 | .....2.D 05 | 092 01 013 | .....1.J 08 |  |  |  |  |  |  |
| 040 17 001 | .....1.C 03 | 040 24 003 | .....1.E 07 | 047 01 017 | .....2.D 12 | 058 07 018 | .....2.C 11 | 061 18 001 | .....1.F 11 | 065 05 002     | .....1.G 06 | 079 01 041                                 | .....2.D 05 | 092 01 019 | .....1.I 05 |  |  |  |  |  |  |
| 040 17 002 | .....1.C 03 | 040 25 002 | .....1.J 08 | 047 01 018 | .....2.D 12 | 058 08 001 | .....1.C 08 | 061 18 001 | .....1.J 11 | 065 06 002     | .....1.C 04 | 079 02 003                                 | .....2.F 17 | 092 01 019 | .....1.J 11 |  |  |  |  |  |  |
| 040 19 001 | .....1.C 07 | 040 25 004 | .....1.I 05 | 049 01 009 | .....2.F 06 | 058 09 009 | .....2.G 05 | 061 19 001 | .....1.K 04 | 065 06 010     | .....1.C 04 | 079 02 005                                 | .....2.F 17 | 092 02 002 | .....1.I 05 |  |  |  |  |  |  |
| 040 20 002 | .....1.F 08 | 040 25 004 | .....1.J 10 | 049 02 005 | .....2.F 05 | 058 09 009 | .....2.G 06 | 061 19 002 | .....1.K 04 | 065 07 005     | .....1.C 07 | 079 02 006                                 | .....2.F 17 | 092 02 004 | .....1.I 03 |  |  |  |  |  |  |
| 040 20 007 | .....1.G 09 | 040 25 005 | .....1.K 15 | 050 01 009 | .....1.K 05 | 058 09 010 | .....2.F 03 | 061 21 006 | .....2.F 08 | 065 08 011     | .....1.K 07 | 079 03 007                                 | .....2.F 16 | 092 02 005 | .....1.I 03 |  |  |  |  |  |  |
| 040 20 009 | .....1.E 03 | 040 25 005 | .....1.K 17 | 051 06 002 | .....1.J 13 | 058 09 011 | .....2.F 15 | 061 21 006 | .....2.F 09 | 065 11 002     | .....1.C 04 | 079 03 008                                 | .....2.F 16 | 092 03 007 | .....1.C 12 |  |  |  |  |  |  |
| 040 21 001 | .....1.F 07 | 040 28 002 | .....1.G 03 | 051 09 002 | .....2.F 16 | 058 10 004 | .....2.C 14 | 061 21 007 | .....2.C 17 | 065 11 005     | .....1.C 04 | 080 03 022                                 | .....1.C 05 | 092 03 010 | .....1.C 12 |  |  |  |  |  |  |
| 040 22 004 | .....1.I 05 | 040 29 003 | .....2.D 17 | 051 09 002 | .....2.F 17 | 058 13 005 | .....2.G 06 | 061 21 009 | .....2.F 09 | 065 13 006     | .....1.F 06 | 080 05 002                                 | .....1.I 06 | 092 05 001 | .....1.I 05 |  |  |  |  |  |  |
| 040 22 004 | .....1.J 15 | 040 29 004 | .....2.F 15 | 051 09 004 | .....2.F 16 | 058 14 002 | .....2.G 06 | 061 21 010 | .....2.D 18 | 067 02 019     | .....1.H 02 | 081 01 008                                 | .....1.F 11 | 092 06 001 | .....1.I 05 |  |  |  |  |  |  |
| 040 22 004 | .....1.K 02 | 040 29 005 | .....2.F 10 | 054 01 012 | .....1.K 08 | 058 15 013 | .....1.J 12 | 061 21 011 | .....2.C 16 | 067 03 002     | .....1.D 02 | 081 01 015                                 | .....1.F 11 | 092 07 004 | .....1.E 08 |  |  |  |  |  |  |
| 040 22 004 | .....1.G 10 | 040 29 005 | .....2.F 11 | 054 02 013 | .....1.K 08 | 058 15 014 | .....2.F 16 | 061 21 012 | .....2.C 16 | 067 04 009     | .....1.D 02 | 083 03 003                                 | .....2.D 08 | 092 11 001 | .....1.J 09 |  |  |  |  |  |  |
| 040 22 005 | .....1.C 11 | 040 29 006 | .....2.F 03 | 054 03 014 | .....1.K 09 | 058 15 014 | .....2.F 17 | 061 21 012 | .....2.C 17 | 067 04 015     | .....1.D 02 | 083 06 005                                 | .....2.C 02 | 092 14 002 | .....1.J 03 |  |  |  |  |  |  |
| 040 22 008 | .....1.C 11 | 040 29 007 | .....2.F 02 | 054 03 015 | .....1.K 09 | 058 15 015 | .....1.J 12 | 061 21 013 | .....2.F 08 | 069 05 003     | .....1.K 04 | 083 07 001                                 | .....2.C 18 | 092 14 003 | .....1.J 03 |  |  |  |  |  |  |
| 040 22 009 | .....1.C 10 | 040 29 007 | .....2.F 04 | 054 03 016 | .....1.K 09 | 058 15 016 | .....2.G 06 | 061 24 001 | .....1.J 10 | 071 01 011     | .....1.K 07 | 083 07 001                                 | .....2.D 04 | 093 02 006 | .....1.H 08 |  |  |  |  |  |  |
| 040 22 009 | .....1.H 08 | 040 29 008 | .....2.F 16 | 054 04 015 | .....1.K 09 | 058 16 006 | .....2.F 02 | 061 31 002 | .....1.I 12 | 072 01 001     | .....1.J 09 | 083 11 002                                 | .....2.C 14 | 093 04 001 | .....2.D 13 |  |  |  |  |  |  |
| 040 22 009 | .....1.D 02 | 040 29 008 | .....2.F 17 | 054 04 016 | .....1.K 09 | 058 20 017 | .....1.L 17 | 061 37 001 | .....1.I 02 | 072 02 004     | .....1.J 16 | 083 11 005                                 | .....2.C 14 | 093 11 001 | .....1.C 14 |  |  |  |  |  |  |
| 040 22 009 | .....1.J 11 | 040 30 002 | .....1.J 15 | 054 04 017 | .....1.K 09 | 058 20 019 | .....2.D 04 | 061 38 001 | .....1.I 03 | 073 01 001     | .....2.C 03 | 083 11 006                                 | .....2.C 13 | 094 01 009 | .....1.H 04 |  |  |  |  |  |  |
| 040 22 009 | .....1.K 02 | 041 07 001 | .....1.C 05 | 054 08 006 | .....1.K 12 | 058 20 020 | .....2.D 18 | 061 39 001 | .....2.C 03 | 074 01 002     | .....1.I 03 | 083 16 001                                 | .....2.F 12 | 094 03 020 | .....1.K 17 |  |  |  |  |  |  |
| 040 22 010 | .....2.C 03 | 041 10 001 | .....1.C 11 | 054 08 007 | .....1.K 12 | 058 20 020 | .....2.F 10 | 061 40 001 | .....1.K 08 | 074 01 004     | .....1.I 03 | 083 16 003                                 | .....2.F 12 | 094 04 006 | .....1.K 17 |  |  |  |  |  |  |
| 040 22 011 | .....2.C 03 | 041 11 001 | .....1.G 05 | 054 09 002 | .....1.K 12 | 058 20 020 | .....2.F 11 | 062 01 010 | .....1.J 14 | 074 03 003     | .....1.K 05 | 083 16 005                                 | .....2.F 15 | 094 05 015 | .....1.K 16 |  |  |  |  |  |  |
| 040 22 018 | .....1.C 11 | 041 11 001 | .....1.G 07 | 054 09 004 | .....1.K 12 | 058 20 021 | .....2.F 08 | 062 01 011 | .....1.J 14 | 074 04 001     | .....1.I 03 | 083 16 007                                 | .....2.F 15 | 094 05 016 | .....1.L 02 |  |  |  |  |  |  |
| 040 22 019 | .....1.C 11 | 042 01 004 | .....1.C 05 | 054 10 003 | .....1.K 11 | 058 20 021 | .....2.F 09 | 062 02 009 | .....1.J 14 | 074 04 003     | .....1.I 04 | 083 17 001                                 | .....2.G 06 | 094 05 017 | .....1.K 18 |  |  |  |  |  |  |
| 040 22 036 | .....1.J 13 | 042 02 005 | .....1.E 05 | 054 11 003 | .....1.K 11 | 058 20 022 | .....2.G 03 | 062 02 010 | .....1.J 14 | 074 06 001     | .....1.J 03 | 084 02 001                                 | .....1.C 11 | 094 05 018 | .....1.K 16 |  |  |  |  |  |  |
| 040 22 036 | .....1.J 15 | 042 02 007 | .....1.E 03 | 054 13 006 | .....1.K 08 | 058 27 005 | .....1.H 09 | 062 03 005 | .....1.J 14 | 075 01 012     | .....1.K 07 | 085 02 004                                 | .....2.E 02 | 094 09 007 | .....1.K 18 |  |  |  |  |  |  |
| 040 22 036 | .....2.C 14 | 042 02 011 | .....1.C 03 | 054 13 007 | .....1.K 08 | 058 27 006 | .....2.F 08 | 062 07 001 | .....2.F 06 | 075 02 001     | .....1.L 04 | 085 03 002                                 | .....2.E 02 | 094 10 002 | .....1.H 07 |  |  |  |  |  |  |
| 040 22 038 | .....1.K 17 | 042 02 012 | .....1.C 03 | 054 14 006 | .....1.K 10 | 058 27 006 | .....2.F 15 | 062 07 002 | .....2.F 06 | 075 04 004     | .....1.J 08 | 085 05 007                                 | .....2.E 02 | 094 11 007 | .....1.K 18 |  |  |  |  |  |  |
| 040 22 042 | .....2.C 02 | 042 02 014 | .....1.E 07 | 054 15 004 | .....1.K 10 | 058 27 006 | .....2.F 09 | 063 01 011 | .....2.F 08 | 075 08 001     | .....1.L 04 | 085 06 005                                 | .....2.E 02 | 094 12 005 | .....1.L 02 |  |  |  |  |  |  |
| 040 22 043 | .....1.F 04 | 042 02 017 | .....1.J 11 | 054 19 001 | .....1.K 13 | 058 27 007 | .....2.F 12 | 063 01 011 | .....2.F 10 | 075 09 001     | .....1.I 05 | 085 07 010                                 | .....2.E 02 | 094 14 011 | .....1.L 02 |  |  |  |  |  |  |
| 040 22 044 | .....1.J 06 | 042 03 009 | .....1.E 07 | 054 20 001 | .....1.K 09 | 058 27 008 | .....1.I 07 | 063 02 010 | .....2.F 09 | 075 10 001     | .....1.L 04 | 085 08 00                                  |             |            |             |  |  |  |  |  |  |



| SAMAND     |       |        |            |       |        |            |       |        |            |       |        | 103<br>Fiche 2 |       | Numeric Index "09602 011 " TO "16318 004 " |            |       |        |            |       |        |            |       |        |  |  |  |  |  |  |  |  |
|------------|-------|--------|------------|-------|--------|------------|-------|--------|------------|-------|--------|----------------|-------|--------------------------------------------|------------|-------|--------|------------|-------|--------|------------|-------|--------|--|--|--|--|--|--|--|--|
| 096 02 011 | ..... | 1.H 05 | 103 06 006 | ..... | 1.J 14 | 110 08 001 | ..... | 2.F 17 | 121 09 010 | ..... | 1.I 12 | 126 12 030     | ..... | 2.F 18                                     | 128 01 103 | ..... | 2.C 05 | 136 01 011 | ..... | 2.C 18 | 156 03 020 | ..... | 2.F 06 |  |  |  |  |  |  |  |  |
| 096 04 009 | ..... | 1.C 08 | 103 09 002 | ..... | 2.D 18 | 110 09 001 | ..... | 2.G 03 | 121 10 002 | ..... | 1.J 09 | 126 12 032     | ..... | 2.F 18                                     | 128 01 104 | ..... | 2.C 10 | 136 01 011 | ..... | 2.D 04 | 156 04 001 | ..... | 1.G 03 |  |  |  |  |  |  |  |  |
| 096 05 003 | ..... | 1.C 08 | 104 01 023 | ..... | 1.K 02 | 111 01 001 | ..... | 1.F 08 | 121 13 004 | ..... | 2.F 16 | 126 12 034     | ..... | 2.F 18                                     | 128 01 105 | ..... | 2.C 10 | 136 01 016 | ..... | 2.C 18 | 156 04 006 | ..... | 1.G 05 |  |  |  |  |  |  |  |  |
| 096 06 002 | ..... | 1.J 02 | 106 03 003 | ..... | 1.J 09 | 111 01 006 | ..... | 1.F 09 | 121 13 004 | ..... | 2.F 17 | 126 13 016     | ..... | 2.F 18                                     | 128 01 106 | ..... | 2.C 10 | 136 01 016 | ..... | 2.D 04 | 156 04 006 | ..... | 1.G 07 |  |  |  |  |  |  |  |  |
| 096 09 001 | ..... | 1.F 11 | 106 03 004 | ..... | 1.J 09 | 111 03 001 | ..... | 2.C 02 | 121 13 005 | ..... | 2.F 16 | 126 13 018     | ..... | 2.F 09                                     | 128 01 107 | ..... | 2.C 10 | 136 01 021 | ..... | 2.D 04 | 156 04 007 | ..... | 1.G 07 |  |  |  |  |  |  |  |  |
| 098 01 001 | ..... | 2.C 02 | 107 01 018 | ..... | 2.D 14 | 111 03 002 | ..... | 2.C 02 | 121 13 005 | ..... | 2.F 17 | 126 14 024     | ..... | 2.F 03                                     | 128 01 108 | ..... | 2.C 05 | 136 01 023 | ..... | 2.D 04 | 156 05 016 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 098 02 004 | ..... | 1.G 05 | 107 01 019 | ..... | 2.D 14 | 111 03 004 | ..... | 2.C 02 | 121 14 001 | ..... | 1.G 05 | 126 14 026     | ..... | 2.F 03                                     | 128 01 110 | ..... | 2.C 05 | 136 03 004 | ..... | 2.C 14 | 156 05 017 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 098 02 004 | ..... | 1.G 07 | 107 03 016 | ..... | 2.D 02 | 111 03 005 | ..... | 2.C 02 | 121 14 001 | ..... | 1.G 07 | 126 14 027     | ..... | 2.F 03                                     | 128 01 111 | ..... | 2.C 05 | 136 04 001 | ..... | 2.D 08 | 156 05 018 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 098 02 010 | ..... | 1.G 05 | 107 03 017 | ..... | 2.D 02 | 111 04 001 | ..... | 1.F 02 | 121 16 008 | ..... | 2.D 07 | 126 14 028     | ..... | 2.F 03                                     | 128 04 043 | ..... | 2.C 05 | 136 04 014 | ..... | 2.D 08 | 156 05 019 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 098 02 010 | ..... | 1.G 07 | 107 04 015 | ..... | 2.D 10 | 111 04 002 | ..... | 1.F 02 | 122 01 007 | ..... | 2.G 03 | 126 14 029     | ..... | 2.F 03                                     | 128 04 043 | ..... | 1.J 07 | 136 04 015 | ..... | 2.D 08 | 156 05 020 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 098 04 005 | ..... | 1.F 03 | 107 05 023 | ..... | 2.D 02 | 111 08 003 | ..... | 2.D 07 | 122 02 007 | ..... | 2.G 03 | 126 14 030     | ..... | 2.F 02                                     | 128 04 044 | ..... | 2.C 05 | 136 07 002 | ..... | 2.G 04 | 156 05 021 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 099 01 005 | ..... | 1.C 03 | 107 05 024 | ..... | 2.D 02 | 111 08 007 | ..... | 2.F 02 | 122 04 003 | ..... | 2.F 16 | 126 14 031     | ..... | 2.F 05                                     | 128 04 045 | ..... | 2.C 10 | 136 07 003 | ..... | 2.G 04 | 156 05 022 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 099 03 001 | ..... | 1.G 06 | 107 06 023 | ..... | 2.D 02 | 111 08 016 | ..... | 2.D 07 | 122 04 003 | ..... | 2.F 17 | 126 15 036     | ..... | 2.F 13                                     | 128 07 031 | ..... | 2.C 05 | 136 07 004 | ..... | 2.G 04 | 156 05 023 | ..... | 2.D 06 |  |  |  |  |  |  |  |  |
| 099 05 011 | ..... | 1.H 02 | 107 06 024 | ..... | 2.D 02 | 111 10 004 | ..... | 1.D 04 | 122 04 004 | ..... | 2.F 16 | 126 15 038     | ..... | 2.F 12                                     | 128 07 032 | ..... | 2.C 06 | 137 01 004 | ..... | 1.L 07 | 156 08 003 | ..... | 1.F 02 |  |  |  |  |  |  |  |  |
| 099 05 012 | ..... | 1.H 02 | 107 07 013 | ..... | 2.D 11 | 111 11 002 | ..... | 1.J 09 | 124 01 004 | ..... | 1.I 08 | 126 15 040     | ..... | 2.F 12                                     | 128 07 033 | ..... | 2.C 07 | 137 01 010 | ..... | 1.L 07 | 156 08 003 | ..... | 1.F 05 |  |  |  |  |  |  |  |  |
| 099 05 018 | ..... | 1.H 03 | 108 01 003 | ..... | 1.C 13 | 111 11 002 | ..... | 1.J 06 | 124 02 001 | ..... | 1.C 12 | 126 15 042     | ..... | 2.F 13                                     | 128 07 034 | ..... | 2.C 07 | 137 05 005 | ..... | 1.M 06 | 156 16 003 | ..... | 1.J 14 |  |  |  |  |  |  |  |  |
| 099 05 019 | ..... | 1.H 03 | 108 01 004 | ..... | 1.C 13 | 112 01 018 | ..... | 1.H 03 | 124 02 005 | ..... | 1.I 02 | 126 15 045     | ..... | 2.F 12                                     | 128 12 025 | ..... | 2.C 09 | 138 02 011 | ..... | 1.K 14 | 156 16 004 | ..... | 1.J 14 |  |  |  |  |  |  |  |  |
| 100 01 012 | ..... | 1.M 02 | 108 02 002 | ..... | 1.J 16 | 112 01 019 | ..... | 1.H 03 | 124 02 008 | ..... | 1.C 12 | 126 15 046     | ..... | 2.F 12                                     | 128 12 026 | ..... | 2.C 09 | 138 03 014 | ..... | 2.D 08 | 156 16 005 | ..... | 1.J 14 |  |  |  |  |  |  |  |  |
| 100 02 011 | ..... | 1.L 14 | 108 02 014 | ..... | 1.J 16 | 114 01 001 | ..... | 1.I 11 | 124 03 006 | ..... | 1.J 13 | 126 15 049     | ..... | 2.F 12                                     | 128 12 027 | ..... | 2.C 09 | 138 03 015 | ..... | 2.C 14 | 156 17 001 | ..... | 1.J 14 |  |  |  |  |  |  |  |  |
| 100 03 015 | ..... | 1.L 10 | 108 03 038 | ..... | 1.J 10 | 114 01 003 | ..... | 1.I 09 | 124 03 016 | ..... | 1.I 02 | 126 15 051     | ..... | 2.F 12                                     | 128 13 002 | ..... | 2.C 10 | 138 04 011 | ..... | 1.D 03 | 156 18 001 | ..... | 2.F 06 |  |  |  |  |  |  |  |  |
| 100 05 002 | ..... | 1.L 16 | 108 03 055 | ..... | 1.J 10 | 114 01 004 | ..... | 1.I 11 | 124 03 022 | ..... | 1.J 13 | 126 15 052     | ..... | 2.D 18                                     | 128 14 002 | ..... | 2.G 04 | 138 06 001 | ..... | 1.H 07 | 156 19 001 | ..... | 1.H 02 |  |  |  |  |  |  |  |  |
| 100 10 029 | ..... | 1.L 12 | 108 04 001 | ..... | 1.I 07 | 114 01 011 | ..... | 1.E 09 | 125 01 001 | ..... | 1.L 03 | 126 15 053     | ..... | 2.D 18                                     | 128 14 004 | ..... | 2.F 12 | 138 06 003 | ..... | 1.H 07 | 158 02 006 | ..... | 1.I 06 |  |  |  |  |  |  |  |  |
| 100 10 030 | ..... | 1.L 11 | 108 04 004 | ..... | 1.I 08 | 114 01 020 | ..... | 1.E 08 | 125 03 001 | ..... | 1.L 03 | 126 15 054     | ..... | 2.D 18                                     | 128 14 005 | ..... | 2.C 07 | 138 06 004 | ..... | 1.H 07 | 158 03 007 | ..... | 1.C 12 |  |  |  |  |  |  |  |  |
| 100 10 031 | ..... | 1.L 11 | 108 04 005 | ..... | 1.I 08 | 114 01 021 | ..... | 1.I 11 | 125 04 001 | ..... | 1.L 03 | 126 15 055     | ..... | 2.D 18                                     | 129 03 006 | ..... | 2.C 10 | 138 07 006 | ..... | 1.I 12 | 159 01 001 | ..... | 1.E 02 |  |  |  |  |  |  |  |  |
| 100 11 009 | ..... | 1.L 13 | 108 04 010 | ..... | 1.I 08 | 114 01 024 | ..... | 1.I 11 | 125 06 001 | ..... | 1.L 03 | 126 17 001     | ..... | 1.C 10                                     | 129 03 007 | ..... | 2.C 10 | 138 09 001 | ..... | 1.J 17 | 159 01 004 | ..... | 1.E 02 |  |  |  |  |  |  |  |  |
| 100 11 010 | ..... | 1.L 13 | 108 04 017 | ..... | 1.I 08 | 114 02 021 | ..... | 2.F 08 | 125 08 001 | ..... | 1.L 03 | 126 17 002     | ..... | 1.C 10                                     | 130 02 016 | ..... | 2.C 08 | 140 02 010 | ..... | 1.C 12 | 160 02 003 | ..... | 2.C 02 |  |  |  |  |  |  |  |  |
| 100 12 009 | ..... | 1.L 09 | 108 04 018 | ..... | 1.I 08 | 114 02 022 | ..... | 2.F 09 | 125 10 001 | ..... | 1.L 03 | 126 17 003     | ..... | 1.C 04                                     | 130 02 017 | ..... | 2.C 08 | 141 01 007 | ..... | 1.H 03 | 160 02 007 | ..... | 2.F 04 |  |  |  |  |  |  |  |  |
| 100 12 011 | ..... | 1.L 18 | 108 04 019 | ..... | 1.I 08 | 114 02 023 | ..... | 2.F 10 | 126 01 014 | ..... | 2.F 06 | 126 17 013     | ..... | 1.C 10                                     | 132 01 009 | ..... | 2.C 09 | 143 01 001 | ..... | 1.E 06 | 160 04 003 | ..... | 1.H 04 |  |  |  |  |  |  |  |  |
| 100 13 011 | ..... | 1.L 15 | 108 04 023 | ..... | 1.I 07 | 114 02 024 | ..... | 2.F 11 | 126 02 005 | ..... | 1.J 08 | 126 18 007     | ..... | 2.F 08                                     | 133 01 003 | ..... | 2.C 11 | 143 01 001 | ..... | 1.F 06 | 160 04 006 | ..... | 1.D 04 |  |  |  |  |  |  |  |  |
| 100 21 008 | ..... | 1.L 17 | 108 04 026 | ..... | 1.I 07 | 114 03 033 | ..... | 2.G 06 | 126 06 019 | ..... | 2.F 14 | 126 18 007     | ..... | 2.F 10                                     | 133 02 011 | ..... | 1.J 07 | 145 03 006 | ..... | 2.G 06 | 161 01 021 | ..... | 1.K 10 |  |  |  |  |  |  |  |  |
| 100 26 001 | ..... | 1.L 15 | 108 04 027 | ..... | 1.I 07 | 114 03 044 | ..... | 2.G 07 | 126 06 023 | ..... | 2.F 14 | 126 18 007     | ..... | 2.F 09                                     | 133 03 008 | ..... | 2.C 05 | 145 04 012 | ..... | 2.G 05 | 161 01 022 | ..... | 1.K 08 |  |  |  |  |  |  |  |  |
| 101 01 007 | ..... | 1.J 08 | 108 04 027 | ..... | 1.I 08 | 114 03 045 | ..... | 2.G 07 | 126 06 024 | ..... | 2.G 06 | 126 18 007     | ..... | 2.F 11                                     | 133 03 009 | ..... | 2.C 05 | 145 05 007 | ..... | 2.G 06 | 161 01 022 | ..... | 1.K 09 |  |  |  |  |  |  |  |  |
| 101 02 005 | ..... | 1.J 13 | 108 04 044 | ..... | 1.I 07 | 114 03 046 | ..... | 2.G 07 | 126 06 025 | ..... | 1.K 10 | 126 19 013     | ..... | 2.F 12                                     | 133 04 021 | ..... | 2.C 07 | 145 05 008 | ..... | 2.G 06 | 161 03 004 | ..... | 1.K 12 |  |  |  |  |  |  |  |  |
| 101 03 008 | ..... | 2.D 12 | 108 05 001 | ..... | 2.D 13 | 114 03 047 | ..... | 2.G 05 | 126 07 023 | ..... | 2.F 02 | 126 19 015     | ..... | 2.F 12                                     | 133 04 022 | ..... | 2.C 07 | 145 06 001 | ..... | 2.G 06 | 161 04 002 | ..... | 1.K 08 |  |  |  |  |  |  |  |  |
| 101 03 016 | ..... | 2.D 12 | 108 05 018 | ..... | 2.D 13 | 114 03 048 | ..... | 2.G 05 | 126 07 024 | ..... | 1.K 15 | 126 20 018     | ..... | 1.G 02                                     | 133 04 023 | ..... | 2.C 07 | 146 01 013 | ..... | 1.H 03 | 161 04 002 | ..... | 1.K 10 |  |  |  |  |  |  |  |  |
| 102 01 026 | ..... | 1.E 07 | 108 05 019 | ..... | 2.D 13 | 114 03 050 | ..... | 2.G 05 | 126 07 025 | ..... | 1.K 15 | 126 20 019     | ..... | 1.G 02                                     | 133 05 002 | ..... | 2.C 10 | 147 01 001 | ..... | 1.J 05 | 161 04 002 | ..... | 1.K 12 |  |  |  |  |  |  |  |  |
| 102 01 031 | ..... | 1.E 05 | 108 05 020 | ..... | 2.D 12 | 114 04 010 | ..... | 2.G 07 | 126 08 023 | ..... | 2.D 14 | 126 20 020     | ..... | 1.G 02                                     | 133 05 003 | ..... | 2.C 10 | 148 02 001 | ..... | 1.J 05 | 161 04 002 | ..... | 1.K 13 |  |  |  |  |  |  |  |  |
| 102 01 036 | ..... | 1.E 05 | 108 06 025 | ..... | 1.J 02 | 114 04 011 | ..... | 2.G 05 | 126 08 024 | ..... | 2.D 14 | 126 21 004     | ..... | 1.J 12                                     | 133 07 010 | ..... | 1.L 08 | 149 01 013 | ..... | 2.G 04 | 161 05 001 | ..... | 1.K 08 |  |  |  |  |  |  |  |  |
| 102 01 051 | ..... | 1.E 07 | 108 06 026 | ..... | 1.J 04 | 114 04 012 | ..... | 2.G 05 | 126 08 024 | ..... | 2.F 09 | 126 22 011     | ..... | 2.F 05                                     | 133 10 007 | ..... | 2.D 18 | 149 01 014 | ..... | 2.G 04 | 161 05 001 | ..... | 1.K 11 |  |  |  |  |  |  |  |  |
| 102 01 058 | ..... | 1.E 07 | 108 06 027 | ..... | 1.J 04 | 115 01 018 | ..... | 1.G 02 | 126 08 025 | ..... | 2.F 08 | 126 23 006     | ..... | 1.J 17                                     | 133 12 001 | ..... | 2.C 10 | 149 02 007 | ..... | 2.G 04 | 161 07 001 | ..... | 1.K 09 |  |  |  |  |  |  |  |  |
| 102 01 069 | ..... | 1.E 06 | 108 06 028 | ..... | 1.J 04 | 116 01 003 | ..... | 1.C 07 | 126 08 027 | ..... | 2.D 14 | 126 23 007     | ..... | 1.J 17                                     | 134 01 052 | ..... | 2.C 06 | 149 02 008 | ..... | 2.G 04 | 161 07 002 | ..... | 1.K 09 |  |  |  |  |  |  |  |  |
| 102 01 069 | ..... | 1.F 06 | 108 07 009 | ..... | 1.I 02 | 116 01 008 | ..... | 1.K 04 | 126 08 028 | ..... | 2.D 14 | 126 23 012     | ..... | 2.F 08                                     | 134 01 053 | ..... | 2.C 06 | 150 01 007 | ..... | 1.F 05 | 162 01 007 | ..... | 1.H 02 |  |  |  |  |  |  |  |  |
| 102 01 070 | ..... | 1.E 06 | 108        |       |        |            |       |        |            |       |        |                |       |                                            |            |       |        |            |       |        |            |       |        |  |  |  |  |  |  |  |  |

| SAMAND     |             |            |             |            |             |            |             |            |             | 104<br>Fiche 2 |             | Numeric Index "16320 001 " TO "18610 180 " |             |            |             |  |  |  |  |  |  |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|------------|-------------|----------------|-------------|--------------------------------------------|-------------|------------|-------------|--|--|--|--|--|--|
| 163 20 001 | .....1.H 03 | 169 01 002 | .....2.D 04 | 174 04 008 | .....1.F 02 | 174 07 005 | .....1.F 03 | 181 07 012 | .....1.E 09 | 181 34 001     | .....1.K 17 | 186 01 016                                 | .....2.F 09 | 186 02 032 | .....1.C 14 |  |  |  |  |  |  |
| 163 25 001 | .....1.F 03 | 169 03 001 | .....2.D 09 | 174 04 009 | .....1.F 03 | 174 07 017 | .....1.E 09 | 181 07 021 | .....1.E 07 | 181 35 006     | .....1.H 07 | 186 01 073                                 | .....1.C 03 | 186 02 032 | .....1.I 03 |  |  |  |  |  |  |
| 164 01 013 | .....2.C 16 | 170 01 007 | .....1.C 06 | 174 04 009 | .....1.F 08 | 174 07 031 | .....1.F 03 | 181 10 003 | .....1.K 06 | 181 35 007     | .....2.C 06 | 186 01 076                                 | .....1.C 04 | 186 02 032 | .....1.K 06 |  |  |  |  |  |  |
| 164 01 014 | .....2.C 16 | 170 02 010 | .....2.D 09 | 174 04 009 | .....2.C 02 | 174 07 032 | .....1.J 04 | 181 11 009 | .....2.D 14 | 181 36 001     | .....1.H 04 | 186 01 077                                 | .....1.C 07 | 186 02 032 | .....1.G 06 |  |  |  |  |  |  |
| 164 02 012 | .....2.C 16 | 170 04 007 | .....2.F 04 | 174 04 012 | .....1.I 11 | 174 07 033 | .....1.L 03 | 181 11 010 | .....2.D 14 | 181 38 002     | .....1.I 06 | 186 01 078                                 | .....1.C 08 | 186 02 041 | .....1.J 08 |  |  |  |  |  |  |
| 164 02 012 | .....2.C 17 | 170 04 009 | .....2.F 04 | 174 04 019 | .....1.K 06 | 174 07 033 | .....1.L 08 | 181 13 006 | .....1.C 11 | 181 38 003     | .....1.I 06 | 186 01 079                                 | .....1.J 11 | 186 02 043 | .....2.F 10 |  |  |  |  |  |  |
| 164 02 014 | .....2.C 16 | 170 05 008 | .....1.J 09 | 174 04 019 | .....1.K 04 | 174 08 001 | .....2.C 02 | 181 14 005 | .....1.G 03 | 181 38 004     | .....1.I 11 | 186 01 082                                 | .....2.C 02 | 186 02 043 | .....2.F 15 |  |  |  |  |  |  |
| 164 02 014 | .....2.C 17 | 170 06 005 | .....1.C 06 | 174 04 020 | .....1.G 08 | 174 08 006 | .....1.G 10 | 181 14 006 | .....1.G 03 | 181 39 006     | .....1.I 09 | 186 01 083                                 | .....2.C 02 | 186 02 043 | .....2.F 11 |  |  |  |  |  |  |
| 164 02 016 | .....2.C 17 | 170 06 006 | .....1.C 06 | 174 04 020 | .....1.K 04 | 174 08 007 | .....2.F 07 | 181 16 034 | .....2.D 15 | 181 40 002     | .....2.F 14 | 186 01 090                                 | .....1.E 05 | 186 02 044 | .....1.H 07 |  |  |  |  |  |  |
| 164 02 017 | .....2.C 17 | 170 08 006 | .....1.L 03 | 174 04 022 | .....1.I 06 | 174 08 008 | .....2.D 12 | 181 16 035 | .....2.D 15 | 181 41 007     | .....2.C 16 | 186 01 091                                 | .....1.G 05 | 186 02 045 | .....1.C 12 |  |  |  |  |  |  |
| 164 03 011 | .....2.C 13 | 170 11 004 | .....1.H 06 | 174 04 023 | .....1.I 02 | 174 12 005 | .....1.J 13 | 181 16 036 | .....2.D 16 | 181 41 009     | .....2.C 17 | 186 01 091                                 | .....1.G 07 | 186 02 046 | .....1.H 07 |  |  |  |  |  |  |
| 164 03 012 | .....2.C 13 | 170 13 003 | .....2.D 13 | 174 04 026 | .....1.C 06 | 174 14 011 | .....2.F 07 | 181 16 037 | .....2.D 16 | 181 45 004     | .....1.J 14 | 186 01 093                                 | .....1.F 08 | 186 03 024 | .....1.C 03 |  |  |  |  |  |  |
| 164 04 006 | .....2.D 07 | 170 15 001 | .....1.G 10 | 174 04 026 | .....2.C 02 | 174 15 001 | .....1.G 06 | 181 16 038 | .....2.C 05 | 181 49 003     | .....1.M 04 | 186 01 094                                 | .....1.F 08 | 186 03 026 | .....1.C 12 |  |  |  |  |  |  |
| 164 04 013 | .....2.D 07 | 170 16 001 | .....1.K 03 | 174 04 026 | .....2.C 16 | 174 20 001 | .....1.M 06 | 181 16 039 | .....2.C 05 | 181 49 004     | .....1.M 04 | 186 01 096                                 | .....1.F 03 | 186 03 028 | .....1.C 12 |  |  |  |  |  |  |
| 164 05 003 | .....2.D 09 | 170 17 002 | .....2.F 06 | 174 04 026 | .....2.C 17 | 175 05 001 | .....1.C 02 | 181 16 040 | .....2.D 15 | 181 54 008     | .....2.H 02 | 186 01 096                                 | .....2.C 02 | 186 03 030 | .....1.C 14 |  |  |  |  |  |  |
| 164 06 005 | .....2.F 06 | 170 18 001 | .....2.G 03 | 174 04 026 | .....1.K 06 | 176 02 009 | .....1.F 08 | 181 16 040 | .....2.D 16 | 181 54 009     | .....2.H 02 | 186 01 096                                 | .....1.G 06 | 186 03 031 | .....1.J 10 |  |  |  |  |  |  |
| 164 08 001 | .....2.G 03 | 171 04 002 | .....1.G 04 | 174 04 026 | .....2.C 11 | 176 02 010 | .....1.F 08 | 181 17 040 | .....1.I 03 | 181 56 005     | .....2.C 10 | 186 01 100                                 | .....1.F 02 | 186 03 038 | .....1.I 06 |  |  |  |  |  |  |
| 165 03 001 | .....1.K 14 | 172 01 011 | .....2.D 13 | 174 04 029 | .....2.D 03 | 178 01 012 | .....1.E 09 | 181 17 041 | .....1.I 03 | 181 56 006     | .....2.C 10 | 186 01 100                                 | .....1.F 05 | 186 03 047 | .....1.E 07 |  |  |  |  |  |  |
| 166 01 006 | .....1.C 12 | 172 02 006 | .....1.I 10 | 174 04 029 | .....2.D 05 | 178 01 017 | .....1.E 09 | 181 17 042 | .....1.K 02 | 181 57 002     | .....2.F 11 | 186 01 104                                 | .....1.I 03 | 186 03 049 | .....1.E 07 |  |  |  |  |  |  |
| 166 02 013 | .....1.I 08 | 172 02 026 | .....1.I 09 | 174 04 031 | .....1.H 05 | 178 01 018 | .....1.E 09 | 181 17 043 | .....1.L 04 | 181 57 003     | .....2.F 10 | 186 01 104                                 | .....1.K 06 | 186 03 050 | .....1.E 08 |  |  |  |  |  |  |
| 166 04 007 | .....1.I 09 | 172 05 002 | .....1.G 10 | 174 04 031 | .....1.H 08 | 178 01 019 | .....1.E 07 | 181 19 001 | .....1.H 02 | 181 57 004     | .....2.F 11 | 186 01 105                                 | .....1.I 12 | 186 03 051 | .....1.E 08 |  |  |  |  |  |  |
| 166 05 009 | .....1.H 08 | 172 06 003 | .....1.H 06 | 174 04 031 | .....1.G 08 | 178 02 049 | .....2.C 18 | 181 19 002 | .....1.H 02 | 181 57 005     | .....2.F 10 | 186 01 105                                 | .....1.G 02 | 186 03 067 | .....1.C 03 |  |  |  |  |  |  |
| 166 05 011 | .....1.H 08 | 174 02 001 | .....1.I 09 | 174 04 035 | .....1.J 13 | 178 02 050 | .....2.C 18 | 181 21 017 | .....1.K 03 | 181 59 003     | .....1.I 05 | 186 01 108                                 | .....1.E 07 | 186 03 067 | .....1.C 12 |  |  |  |  |  |  |
| 166 05 012 | .....1.H 08 | 174 02 003 | .....1.H 04 | 174 04 035 | .....1.J 15 | 178 02 051 | .....2.D 04 | 181 21 018 | .....1.K 03 | 181 59 006     | .....1.I 06 | 186 01 114                                 | .....1.G 06 | 186 03 070 | .....1.J 11 |  |  |  |  |  |  |
| 166 05 055 | .....1.H 08 | 174 02 003 | .....2.C 02 | 174 04 036 | .....1.I 09 | 178 02 052 | .....2.D 04 | 181 22 004 | .....2.F 07 | 181 69 002     | .....2.F 08 | 186 01 115                                 | .....1.F 02 | 186 03 071 | .....1.I 02 |  |  |  |  |  |  |
| 166 05 056 | .....1.H 08 | 174 02 004 | .....1.H 04 | 174 04 036 | .....1.I 10 | 178 02 053 | .....2.D 04 | 181 22 005 | .....2.F 07 | 181 69 003     | .....2.F 09 | 186 01 120                                 | .....1.F 03 | 186 03 077 | .....1.G 03 |  |  |  |  |  |  |
| 166 05 059 | .....1.H 08 | 174 02 004 | .....1.H 07 | 174 04 036 | .....1.K 04 | 178 02 054 | .....2.D 04 | 181 22 006 | .....2.F 07 | 181 81 002     | .....1.J 06 | 186 01 124                                 | .....2.C 11 | 186 03 079 | .....1.C 03 |  |  |  |  |  |  |
| 166 05 061 | .....1.H 08 | 174 02 004 | .....1.G 03 | 174 04 041 | .....1.I 03 | 178 02 055 | .....2.D 08 | 181 23 006 | .....2.C 07 | 181 83 001     | .....1.I 03 | 186 01 151                                 | .....1.H 04 | 186 03 080 | .....1.C 06 |  |  |  |  |  |  |
| 166 05 089 | .....1.H 08 | 174 02 010 | .....2.D 15 | 174 04 042 | .....1.E 07 | 178 02 056 | .....2.C 18 | 181 26 002 | .....1.H 08 | 182 01 029     | .....2.D 06 | 186 01 167                                 | .....1.I 03 | 186 03 081 | .....2.C 02 |  |  |  |  |  |  |
| 166 06 009 | .....1.I 07 | 174 02 010 | .....2.D 16 | 174 04 043 | .....2.D 15 | 178 02 057 | .....2.C 18 | 181 26 003 | .....1.H 08 | 182 01 030     | .....2.D 06 | 186 01 168                                 | .....1.I 07 | 186 03 081 | .....1.K 06 |  |  |  |  |  |  |
| 166 06 011 | .....1.I 07 | 174 02 010 | .....2.D 17 | 174 04 044 | .....2.D 03 | 178 02 058 | .....2.C 18 | 181 26 004 | .....1.H 08 | 182 01 031     | .....2.D 06 | 186 01 169                                 | .....2.C 02 | 186 03 081 | .....1.J 05 |  |  |  |  |  |  |
| 166 06 013 | .....1.I 07 | 174 02 015 | .....1.J 14 | 174 04 044 | .....2.D 05 | 178 02 059 | .....2.C 18 | 181 26 005 | .....1.H 08 | 182 01 032     | .....2.D 06 | 186 01 169                                 | .....2.F 06 | 186 03 082 | .....1.J 14 |  |  |  |  |  |  |
| 166 06 014 | .....1.I 07 | 174 03 001 | .....1.I 09 | 174 04 045 | .....2.C 18 | 178 02 060 | .....2.D 04 | 181 26 011 | .....1.G 08 | 182 01 033     | .....2.D 07 | 186 01 170                                 | .....1.E 09 | 186 04 013 | .....2.F 02 |  |  |  |  |  |  |
| 166 06 015 | .....1.I 08 | 174 03 005 | .....1.E 05 | 174 04 045 | .....2.D 04 | 178 02 061 | .....2.D 04 | 181 26 024 | .....1.J 02 | 182 02 011     | .....1.J 12 | 186 01 170                                 | .....1.J 05 | 186 04 014 | .....2.F 08 |  |  |  |  |  |  |
| 166 06 016 | .....1.I 08 | 174 03 005 | .....1.E 06 | 174 04 046 | .....1.I 11 | 178 07 004 | .....2.C 13 | 181 26 034 | .....1.H 08 | 182 02 012     | .....2.C 15 | 186 01 171                                 | .....1.J 15 | 186 04 014 | .....1.G 05 |  |  |  |  |  |  |
| 166 06 017 | .....1.I 08 | 174 03 006 | .....1.F 07 | 174 04 046 | .....2.D 17 | 178 08 001 | .....1.L 08 | 181 26 035 | .....1.H 08 | 182 02 013     | .....2.C 15 | 186 01 172                                 | .....2.D 16 | 186 04 014 | .....1.G 07 |  |  |  |  |  |  |
| 166 07 004 | .....1.G 08 | 174 03 007 | .....1.F 07 | 174 04 047 | .....2.D 12 | 178 08 002 | .....1.L 08 | 181 26 036 | .....1.H 08 | 182 03 103     | .....2.D 11 | 186 01 173                                 | .....2.G 04 | 186 04 014 | .....2.F 09 |  |  |  |  |  |  |
| 166 07 005 | .....1.G 08 | 174 03 008 | .....1.F 09 | 174 04 048 | .....1.F 10 | 178 12 001 | .....1.I 03 | 181 26 037 | .....1.H 08 | 182 03 104     | .....2.D 02 | 186 01 174                                 | .....1.C 12 | 186 04 015 | .....1.L 14 |  |  |  |  |  |  |
| 166 07 008 | .....1.G 06 | 174 03 016 | .....1.C 03 | 174 04 049 | .....2.C 02 | 178 12 001 | .....1.I 12 | 181 26 038 | .....1.J 04 | 182 03 105     | .....2.D 02 | 186 01 174                                 | .....1.G 09 | 186 04 016 | .....2.D 08 |  |  |  |  |  |  |
| 166 07 010 | .....1.G 08 | 174 03 021 | .....1.G 03 | 174 04 050 | .....1.K 03 | 179 01 011 | .....1.C 07 | 181 26 039 | .....1.I 08 | 182 03 106     | .....2.D 05 | 186 01 174                                 | .....1.K 04 | 186 05 018 | .....1.F 06 |  |  |  |  |  |  |
| 166 07 011 | .....1.G 08 | 174 03 060 | .....1.I 05 | 174 04 050 | .....1.L 14 | 180 01 008 | .....1.C 04 | 181 26 040 | .....1.J 04 | 182 03 107     | .....2.D 05 | 186 01 175                                 | .....1.E 06 | 186 05 019 | .....1.F 06 |  |  |  |  |  |  |
| 166 08 002 | .....1.J 16 | 174 03 070 | .....1.J 05 | 174 04 051 | .....1.I 05 | 181 02 002 | .....2.C 02 | 181 28 026 | .....1.K 08 | 182 03 108     | .....2.D 03 | 186 01 176                                 | .....2.C 14 | 186 05 020 | .....1.G 07 |  |  |  |  |  |  |
| 166 08 006 | .....1.J 16 | 174 03 071 | .....2.D 08 | 174 04 051 | .....1.I 08 | 181 02 008 | .....2.C 02 | 181 28 027 | .....1.K 08 | 182 03 109     | .....2.D 03 | 186 01 177                                 | .....2.D 12 | 186 05 021 | .....1.G 07 |  |  |  |  |  |  |
| 166 10 003 | .....1.C 12 | 174 03 072 | .....2.D 16 | 174 04 051 | .....1.G 03 | 181 02 017 | .....2.C 02 | 181 28 027 | .....1.K 10 | 182 03 110     | .....2.D 10 | 186 01 178                                 | .....2.G 04 | 186 05 022 | .....1.G 07 |  |  |  |  |  |  |
| 166 10 005 | .....1.C 03 | 174 03 073 | .....1.H 06 | 174 04 051 | .....1.G 10 | 181 02 066 | .....1.C 10 | 181 28 027 | .....1.K 13 | 182 06 004     | .....2.D 14 | 186 01 179                                 | .....2.G 04 | 186 0      |             |  |  |  |  |  |  |

| SAMAND |     |             |        |     |             |        |     |             |  | I05<br>Fiche 2 | Numeric Index "18610 181 " TO "27801 001 " |  |  |  |
|--------|-----|-------------|--------|-----|-------------|--------|-----|-------------|--|----------------|--------------------------------------------|--|--|--|
| 186 10 | 181 | .....1.C 09 | 191 01 | 014 | .....2.D 17 | 220 01 | 001 | .....1.M 04 |  |                |                                            |  |  |  |
| 186 10 | 182 | .....1.C 09 | 191 02 | 014 | .....2.D 17 | 221 05 | 001 | .....1.I 08 |  |                |                                            |  |  |  |
| 186 10 | 183 | .....1.C 09 | 191 02 | 015 | .....2.D 17 | 221 07 | 001 | .....1.C 03 |  |                |                                            |  |  |  |
| 186 10 | 184 | .....1.C 09 | 194 01 | 008 | .....1.G 04 | 221 07 | 002 | .....1.C 03 |  |                |                                            |  |  |  |
| 186 10 | 185 | .....1.C 09 | 194 01 | 009 | .....1.G 04 | 222 01 | 015 | .....1.E 09 |  |                |                                            |  |  |  |
| 186 10 | 206 | .....1.C 09 | 194 01 | 010 | .....1.G 04 | 225 01 | 008 | .....1.J 17 |  |                |                                            |  |  |  |
| 186 10 | 207 | .....1.C 09 | 196 02 | 002 | .....1.J 13 | 225 04 | 010 | .....2.F 08 |  |                |                                            |  |  |  |
| 186 10 | 208 | .....1.C 09 | 197 01 | 010 | .....1.F 04 | 225 04 | 010 | .....2.F 10 |  |                |                                            |  |  |  |
| 186 10 | 209 | .....1.C 09 | 197 01 | 011 | .....1.F 04 | 225 04 | 010 | .....2.F 09 |  |                |                                            |  |  |  |
| 186 10 | 210 | .....1.C 09 | 197 01 | 012 | .....1.F 04 | 225 04 | 010 | .....2.F 11 |  |                |                                            |  |  |  |
| 186 10 | 211 | .....1.C 09 | 197 02 | 003 | .....1.F 08 | 225 05 | 004 | .....1.J 17 |  |                |                                            |  |  |  |
| 186 10 | 212 | .....1.C 09 | 198 02 | 005 | .....2.C 17 | 225 08 | 002 | .....2.G 04 |  |                |                                            |  |  |  |
| 186 10 | 226 | .....1.C 09 | 198 02 | 006 | .....2.C 17 | 225 08 | 003 | .....2.G 04 |  |                |                                            |  |  |  |
| 186 10 | 227 | .....1.C 09 | 200 01 | 001 | .....1.K 05 | 227 01 | 004 | .....2.C 08 |  |                |                                            |  |  |  |
| 186 10 | 228 | .....1.C 09 | 202 01 | 021 | .....2.F 08 | 227 01 | 005 | .....2.C 08 |  |                |                                            |  |  |  |
| 186 10 | 229 | .....1.C 09 | 202 01 | 021 | .....2.F 10 | 229 02 | 005 | .....1.J 17 |  |                |                                            |  |  |  |
| 186 10 | 230 | .....1.C 09 | 202 01 | 021 | .....2.F 09 | 230 01 | 009 | .....1.J 14 |  |                |                                            |  |  |  |
| 186 10 | 231 | .....1.C 09 | 202 01 | 021 | .....2.F 11 | 230 01 | 010 | .....1.J 14 |  |                |                                            |  |  |  |
| 186 10 | 232 | .....1.C 09 | 202 01 | 022 | .....2.F 02 | 230 01 | 011 | .....1.J 14 |  |                |                                            |  |  |  |
| 186 10 | 233 | .....1.C 09 | 202 01 | 023 | .....2.G 03 | 230 01 | 012 | .....2.F 07 |  |                |                                            |  |  |  |
| 186 10 | 234 | .....1.C 09 | 204 01 | 004 | .....2.F 18 | 230 01 | 013 | .....2.F 07 |  |                |                                            |  |  |  |
| 186 10 | 259 | .....1.E 05 | 205 02 | 005 | .....1.K 14 | 230 01 | 014 | .....1.J 14 |  |                |                                            |  |  |  |
| 186 10 | 260 | .....1.F 06 | 205 02 | 034 | .....2.C 18 | 230 01 | 015 | .....1.J 14 |  |                |                                            |  |  |  |
| 186 10 | 276 | .....1.F 09 | 205 02 | 035 | .....1.J 02 | 231 01 | 003 | .....1.I 05 |  |                |                                            |  |  |  |
| 186 10 | 322 | .....1.G 06 | 205 02 | 036 | .....2.G 07 | 232 01 | 012 | .....1.K 02 |  |                |                                            |  |  |  |
| 186 12 | 002 | .....1.C 06 | 205 02 | 037 | .....1.I 12 | 233 01 | 003 | .....1.F 08 |  |                |                                            |  |  |  |
| 186 16 | 001 | .....1.C 06 | 205 02 | 038 | .....1.J 04 | 234 02 | 002 | .....2.D 10 |  |                |                                            |  |  |  |
| 186 20 | 001 | .....1.I 07 | 205 02 | 039 | .....1.H 05 | 235 01 | 003 | .....2.H 02 |  |                |                                            |  |  |  |
| 186 23 | 004 | .....1.H 04 | 205 03 | 002 | .....2.F 16 | 236 01 | 004 | .....2.H 02 |  |                |                                            |  |  |  |
| 186 23 | 006 | .....1.H 05 | 205 03 | 002 | .....2.F 17 | 236 01 | 005 | .....2.H 02 |  |                |                                            |  |  |  |
| 186 24 | 002 | .....1.C 11 | 207 02 | 003 | .....1.G 09 | 237 03 | 003 | .....1.G 07 |  |                |                                            |  |  |  |
| 186 24 | 014 | .....1.E 05 | 207 02 | 003 | .....1.K 04 | 237 03 | 009 | .....1.G 06 |  |                |                                            |  |  |  |
| 186 24 | 017 | .....1.J 15 | 207 03 | 004 | .....1.C 07 | 237 03 | 010 | .....1.F 03 |  |                |                                            |  |  |  |
| 186 24 | 029 | .....2.F 16 | 208 01 | 007 | .....2.F 02 | 237 03 | 011 | .....1.L 03 |  |                |                                            |  |  |  |
| 186 24 | 029 | .....2.F 17 | 208 01 | 009 | .....2.F 04 | 237 03 | 012 | .....2.D 15 |  |                |                                            |  |  |  |
| 186 24 | 030 | .....1.M 06 | 208 01 | 010 | .....2.F 03 | 237 06 | 010 | .....2.F 13 |  |                |                                            |  |  |  |
| 188 01 | 010 | .....1.C 05 | 208 01 | 011 | .....2.F 04 | 237 06 | 011 | .....2.F 13 |  |                |                                            |  |  |  |
| 188 02 | 007 | .....1.C 05 | 208 02 | 001 | .....1.L 03 | 237 06 | 012 | .....2.F 12 |  |                |                                            |  |  |  |
| 188 03 | 006 | .....1.C 05 | 208 02 | 011 | .....1.L 03 | 237 06 | 013 | .....2.F 13 |  |                |                                            |  |  |  |
| 188 08 | 006 | .....1.C 04 | 208 02 | 012 | .....1.L 03 | 237 06 | 015 | .....2.F 13 |  |                |                                            |  |  |  |
| 188 08 | 007 | .....1.C 04 | 208 06 | 004 | .....2.F 10 | 239 02 | 001 | .....1.F 07 |  |                |                                            |  |  |  |
| 188 08 | 008 | .....1.C 04 | 208 06 | 006 | .....2.F 11 | 239 07 | 002 | .....2.F 06 |  |                |                                            |  |  |  |
| 188 08 | 009 | .....1.C 04 | 208 09 | 002 | .....2.H 02 | 244 01 | 003 | .....1.J 06 |  |                |                                            |  |  |  |
| 188 08 | 013 | .....1.C 04 | 208 10 | 001 | .....1.K 03 | 259 05 | 001 | .....2.H 02 |  |                |                                            |  |  |  |
| 188 08 | 014 | .....1.C 04 | 209 02 | 001 | .....1.J 08 | 275 01 | 002 | .....2.G 03 |  |                |                                            |  |  |  |
| 188 09 | 007 | .....1.C 04 | 209 03 | 003 | .....1.K 03 | 277 01 | 001 | .....2.H 02 |  |                |                                            |  |  |  |
| 188 09 | 008 | .....1.C 04 | 209 08 | 001 | .....1.L 06 | 278 01 | 001 | .....2.H 02 |  |                |                                            |  |  |  |
| 188 09 | 009 | .....1.C 04 | 209 08 | 002 | .....1.L 06 |        |     |             |  |                |                                            |  |  |  |
| 188 09 | 010 | .....1.C 04 | 213 01 | 007 | .....2.F 16 |        |     |             |  |                |                                            |  |  |  |
| 188 09 | 025 | .....1.C 04 | 213 01 | 008 | .....2.F 17 |        |     |             |  |                |                                            |  |  |  |
| 190 01 | 009 | .....1.C 08 | 215 01 | 006 | .....1.M 03 |        |     |             |  |                |                                            |  |  |  |
| 190 02 | 005 | .....1.C 08 | 217 01 | 008 | .....2.D 03 |        |     |             |  |                |                                            |  |  |  |
| 191 01 | 011 | .....2.D 17 | 217 01 | 009 | .....2.D 03 |        |     |             |  |                |                                            |  |  |  |
| 191 01 | 012 | .....2.D 17 | 217 02 | 004 | .....2.D 05 |        |     |             |  |                |                                            |  |  |  |
| 191 01 | 013 | .....2.D 17 | 217 02 | 005 | .....2.D 05 |        |     |             |  |                |                                            |  |  |  |

# SAMAND

**J01**  
 Fiche 2

PARTS NEW TO FICHE

|     |    |     |                                |   |     |
|-----|----|-----|--------------------------------|---|-----|
| 060 | 03 | 015 | Door Assy.-rear-LH.....        | 2 | C17 |
| 128 | 12 | 025 | Panel.-front.....              | 2 | C09 |
| 164 | 02 | 016 | Hinge.-rear door upper-LH..... | 2 | C17 |
| 181 | 56 | 006 | Bracket.-parcel shelf.....     | 2 | C10 |
| 198 | 02 | 005 | Door Panel.-rear-LH.....       | 2 | C17 |